

Standard Operating Procedure
for
Hydrocarbon Canister Sampling during Intensive
Operating Periods in CRPAQS

Prepared By:
Oregon Graduate Institute of Science and Technology
20,000 N.W. Walker Rd.
Beaverton, Oregon 97006

Acceptance and Installation Instructions

1. Open the box..note how it is stuffed with foam to be sure it arrived safely
 2. Place on a table or bench and plug in the two little transformers and the single power cord.
Get a circuit with 115 VAC...measure if possible
 3. Remove the brass... Swagelok... nuts from the inlet to the pump... and from the 4 out puts on the solenoids....(save them for return shipment)
 4. The light on the Chronrol should be on and you can turn on the on/off switch on the front of the power supply and the pump will come on
 5. Shut the pump off... its easier to concentrate on entering the program into the Chronrol... with less noise.
 6. Follow the instructions on the attached page..... they are very basic... First unlock the unit... by pressing 103 and enter the current time as directed... Then enter the program...
 7. Check the program...as listed in the attached instructions... All should...light up and audibly 'click' as the solenoids go on and off....
 8. Connect the 4 Teflon lines to the solenoids and the 5.8L canisters..IMPORTANT... use 2 wrenches a 1/2 -inch wrench to hold steady the fitting on the solenoid and a 9/16-inch wrench on the Swagelok nuts...Reason is the threaded fittings into the solenoid are easily damaged if over tightened and will leak... voiding sample.
- We have found it best to leave the cans in the shipping box and to label each Teflon line 1--2--3--4-- for their respective solenoid.....i.e solenoid #1 = circuit #1 on the Chronrol...etc. as a memory aid when attaching lines to cans and recording the sampling data.
- 9 I will send out the 25-ft line of annealed Teflon to you today...it is very 'super' clean..and inert. We are not sending a Stainless Steel line... it is to stiff to install..
 10. Very important... we 're here to talk with you about any questions...Call me at 503-621-1435 mornings and Bob at the lab 503-690-1087.

IOP Sampling Procedure

To start the VOC sampling for the CRPAQS IOP'S you will have visit the site on the day before the IOP...
In your visit you will have to do the following:

Arrive at the station after 10 AM....

1. Start the pump.
2. Open the valves on the canisters ...solenoid-circuit # 1 and #2.... these correspond to time 00-05AM and 05 to 10 AM
3. Do not open the valves on the canisters at positions # 3 and # 4...until the next day...as these correspond to times 10 to 16 (4PM) and 16 to 00 (mid-night).
4. On day one of the IOP you will have to arrive at the site before 10 AM to open the valves on canisters at positions #3 and #4 and the close the valve on canisters # 1 and # 2 (after 10 AM) and change out the used-exposed canisters for new canisters.

At this time you can open the valve to these new canisters so your visit on day 2 of the IOP can be more flexible for changing out #3 , #4, and #1, etc.

PROGRAM FOR 4 EVENT CRPAQS IOP

10/20/2000

ENTER PACIFIC **STANDARD** TIME

Press Display

Unlock Keyboard

1. 103 000

Set PST Time (i.e. 9:00 am)

1.	<input type="text" value="TIME"/>	Blank
2.	900 am	900
3.	<input type="text" value="ENTER"/>	900

PACIFIC STANDARD TIME = 9:00 am

Press Display

Enter Program

1.	1	01
2.	<input type="text" value="CIRCUIT"/>	00
3.	1	01
4.	<input type="text" value="ON"/>	000
5.	1200 am	1200
6.	<input type="text" value="OFF"/>	000
7.	500 am	500
8.	<input type="text" value="ENTER"/>	Current Time

9.	2	02
10.	<input type="text" value="CIRCUIT"/>	00
11.	2	02
12.	<input type="text" value="ON"/>	000
13.	500 am	500
14.	<input type="text" value="OFF"/>	000
15.	1000 am	1000
16.	<input type="text" value="ENTER"/>	Current Time

17.	3	03
18.	<input type="text" value="CIRCUIT"/>	00
19.	3	03
20.	<input type="text" value="ON"/>	000
21.	1000 am	1000
22.	<input type="text" value="OFF"/>	000
23.	400 pm	400.
24.	<input type="text" value="ENTER"/>	Current Time

25.	4	04
26.	<input type="text" value="CIRCUIT"/>	00
27.	4	04
28.	<input type="text" value="ON"/>	000
29.	400 pm	400.
30.	<input type="text" value="OFF"/>	000
31.	1200 am	1200
32.	<input type="text" value="ENTER"/>	Current Time

LOCK KEYBOARD

1.	<input type="text" value="LOCK"/>	Current Time
----	-----------------------------------	--------------

To: UNLOCK KEYBOARDPress Display

- | | | |
|----|-----------------|--------------|
| 1. | 103 | Current Time |
| 2. | <div>TIME</div> | Blank |
| 3. | <div>TIME</div> | Current Time |

To: CHECK PROGRAMPress Display

- | | | |
|-----|--------------------|--------------|
| 1. | 1 | 01 |
| 2. | <div>CIRCUIT</div> | 01 |
| 3. | <div>ON</div> | 1200 |
| 4. | <div>OFF</div> | 500 |
| 5. | <div>ENTER</div> | Current Time |
| | | |
| 6. | 2 | 02 |
| 7. | <div>CIRCUIT</div> | 02 |
| 8. | <div>ON</div> | 500 |
| 9. | <div>OFF</div> | 1000 |
| 10. | <div>ENTER</div> | Current Time |
| | | |
| 11. | 3 | 03 |
| 12. | <div>CIRCUIT</div> | 03 |
| 13. | <div>ON</div> | 1000 |
| 14. | <div>OFF</div> | 400. |
| 15. | <div>ENTER</div> | Current Time |
| | | |
| 16. | 4 | 04 |
| 17. | <div>CIRCUIT</div> | 04 |
| 18. | <div>ON</div> | 400. |
| 19. | <div>OFF</div> | 1200 |
| 20. | <div>ENTER</div> | Current Time |

TO: LOCK KEYBOARD

- | | | |
|----|-----------------|--------------|
| 1. | <div>LOCK</div> | Current Time |
|----|-----------------|--------------|

TO CHECK FLOW 11/21/2000

UNLOCK KEYBOARD

Press Display

1. 103 Current Time
2. Blank
3. Current Time

MAKE SURE ALL VALVES ARE CLOSED

Press Display

1. 1 01
2. Current Time
3. 1 01
4. Current Time
5. 2 02
6. Current Time
7. 2 02
8. Current Time
9. 3 03
10. Current Time
11. 3 03
12. Current Time
13. 4 04
14. Current Time
15. 4 04
16. Current Time

CONNECT FLOWMETER TO TEFLON TUBE ON VALVE "1"

CHECK FLOW

1. Turn Pump ON by turning on Power Supply

Press Display

1. 1 01
2. Current Time

Flow Should Read about 30. If it is significantly different:

Please call Bob Dalluge or Rei Rasmussen, for helpful Hints.

Adjust the flow by removing the cap , the long silver nut on the right side of the flow controller, "1/2 wrench".

Adjust the allen screw using a "5/64 allen wrench". Clockwise decreases the flow, counterclockwise increases the flow.

Replace the cap on the flow controller.

3. 1 01
4. Current Time

TO: LOCK KEYBOARD

1. Current Time

**CRPAQS VOC SAMPLES / IOP EVENTS
HYDROCARBON MEASUREMENTS**

RETURN CANISTERS TO:

**BRC / R.A. RASMUSSEN,
17010 NW SKYLINE BLVD
PORTLAND, OR 97231**

PH 503 621 1435

LOCATION: _____

Sampler # _____

Start Pump ---Open Valves ---Record Data:

DATE/TIME	S1/CAN #	S2/CAN #	S3/CAN#	S4/CAN#
1ST Day _____	_____	_____	_____	_____
2ND Day _____	_____	_____	_____	_____
3RD Day _____	_____	_____	_____	_____
4TH Day _____	_____	_____	_____	_____

Signature _____

**At end of IOP: Shut Off Pump, Install New Cans-DO NOT OPEN
THEIR VALVES, they are for the next IOP.**

**The Tags on Each Canister Need To Be Filled Out With:
Location, Date/Time, and S# / Can #.**

**Recording the S# / Can # is Especially IMPORTANT as it Identifies the
Sample Time-Interval per IOP Day. It MUST be Done on Both the
Work Sheet and the Tags on the Individual Canisters**

