

Issue

The 8857 heater control box for the humidity-controlled heater on the BAM1020 is not activating at the correct humidity.

Symptoms

The concentration measured by the BAM1020 will be increased by high humidity at the filter tape. Spikes of concentration will correlate with high RH values.

Solution

Met One recommends removing the 8857 heater control box from the system. The heater can be directly plugged into 115 or 230 depending on the model.

Contact Information

Mike Putnam

541.471.7115 x 133

service@metone.com



Met One Instruments, Inc.

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)412-4716
Website: www.metone.com Email: service@metone.com
