

Issue

The sample nozzle could be damaged in shipping.

Symptoms

Filter material would build up on the nozzle surface causing hole punching in the filter tape.

Solution

All units manufactured from the date of this bulletin forward have a Delrin sheet under the nozzle to prevent shipping damage. This sheet must be placed under the nozzle each time the BAM is moved. To receive a Delrin nozzle sheet for shipping contact Met One Instruments.

Contact Information

Mike Putnam
541.471.7115 x 133
service@metone.com



Met One Instruments, Inc.

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)412-4716
Website: www.metone.com Email: service@metone.com
