

Issue

The clock microchip used on the 3230 PCB is an obsolete part. The replacement clock required a re-layout of the 3230 PCB and a different version of the firmware.

Symptoms

No Answer.

Solution

All units manufactured from the date of this bulletin forward have a new revision of the 3230 PCB. This version is the 3230-7 PCB. All BAMs with the new 3230-7 PCB have firmware version 2.51 or higher. This version of firmware only works on units with the new 3230-7 PCB. The corresponding firmware for older revisions of the 3230 PCB use firmware version 2.31 or higher. These firmware versions (2.31 and 2.51) are identical in operation but are not interchangeable.

Contact Information

Mike Putnam
541.471.7115 x 133
service@metone.com



Met One Instruments, Inc.

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)412-4716
Website: www.metone.com Email: service@metone.com
