

## 5.8 FIELD EVALUATION OF THE EGR CONCEPT

Following development of the EGR prototype sampling system, field evaluations were performed under USEPA contracts (Williamson, et al., 1985). The Emission Gas Recycle System was used to measure total mass and particulate size fractions at three separate coal-fired power plants. The test series compared results from the EGR system with those from standard Method 17 mass train systems, conventional cyclone and impactor trains, and similar trains using another  $PM_{10}$  candidate method, SIM5 (Farthing, et al., 1985). During the first two tests, the EGR and conventional cyclone train consisted of Cyclones I and IV of the SoRI/EPA series cyclone train, followed by a 47mm glass fiber filter. For the final test of the series, a full SoRI five-stage series cyclone system was used for both systems. University of Washington Mark V impactors were also used for comparisons in all testing.

### 5.8.1 TEST NO. 1

The first field test took place at one of the twin 56 MW coal-fired boilers at a utility generating station. The plant nominally operates at minimum (half) load; however, boiler conditions occasionally changed as dictated by demand. The sampling location chosen was the ducting between an outdated, somewhat inefficient electrostatic precipitator and a retro-fitted, more efficient ESP.

The overall test was divided into two subtests. Subtest A involved the comparison of traverses performed with the EGR train and a standard Method 17 (M17) mass train. To eliminate spatial bias, a probe was configured with a cyclone set (SoRI Cyclone I, Cyclone IV and a 47mm filter) using an EGR nozzle and a collocated 47mm filter. The large diameter of this system required plant installation of six-inch ports. Three traverse points were selected which represented the maximum point-to-point velocity change accessible through the six-inch ports. The recycle rate was then adjusted to achieve isokinetic sampling at each point while maintaining the chosen constant flowrate through the cyclone set. The flowrate through the collocated 47 mm filter was adjusted at each point according to isokinetic sampling protocol.

In Subtest B, the EGR-M17 hardware described under Subtest A was used without modification. A second cyclone train, without emission gas recirculation, was used for a "near-collocated" reference. This train used identical cyclone samplers equipped with a standard nozzle rather than the EGR nozzle. The remainder of the sampling train was conventional: a heated stainless steel probe, ice bath condenser, and a commercial Method 5 control box. Both probes (three sampling trains) were inserted at right angles to each other in order to sample at the same point in the duct (within approximately four-inch nozzle-to-nozzle spacing). The duct point and nozzle for the nonrecycle train which were selected resulted in an isokinetic flowrate that was slightly greater than the flowrate calculated for a  $10\mu m D_{50}$  in the cyclone. The isokinetic flowrate rather than the  $PM_{10}$  flow rate was used for sampling. The EGR cyclone was fitted with a

smaller nozzle than the nonrecycle train. The EGR sample flowrate was adjusted to maintain isokinetic nozzle sampling. The recycle fraction was adjusted to make the cyclone flowrate identical to that used for the nonrecycle cyclone. The Method 17 sampler was operated in the usual fashion.

A total of eight valid EGR comparison tests were performed during the initial field test. Sampling runs 2 through 6 were completed as described under Subtest A. With the exception of Run 3, which was performed during a period of fluctuating boiler load, these were performed with the boiler at full load (56 MW). Runs 7 through 10 were replicates for Subtest B, all of which were run at minimum boiler conditions (28 MW).

The run parameters, along with the total mass and nominal- $PM_{10}$  loadings are shown in Table 5-1. The recycle rates (shown as percentage of the total cyclone flowrate) varied from 9.6% to 59.6% during the test series.

#### 5.8.2 TEST NO. 2

The second EGR field test was carried out at a 500 MW coal-fired power plant. The plant consisted of two 250 MW units with emission from each unit controlled by two cold-side electrostatic precipitators. The sampling location chosen was between the outlet of one ESP and the stack. Pretest surveys indicated the duct velocity averaged 60 ft/sec, with substantial velocity spread. An aerosol mass median diameter in the 7-14  $\mu m$  diameter range was expected. As previously mentioned, the cyclone trains used for the second field test were identical to those used for the first test (SoRI Cyclone I, Cyclone IV, and a 47 mm quartz-fiber backup filter). The EGR cyclone train simultaneously sampled a three-point traverse along with a standard sampling cyclone train following another candidate  $PM_{10}$  sampling protocol referred to as SIM5 (Synthetic Method 5). The SIM5 protocol was developed to provide valid emissions data for 10  $\mu m$  and smaller particles while using a fixed sampling flowrate. The method is not capable of correctly measuring emissions of particles larger than 10  $\mu m$ , consequently no valid total emissions data can be obtained using it.

The flowrates through both trains were set to produce a 10  $\mu m$  aerodynamic  $D_{50}$  through the first cyclone. The nonrecycle (SIM5) cyclone train sampled across the traverse at constant flowrate as outlined in the SIM5 protocol. By using a slightly smaller nozzle on the EGR system, the nozzle sampled isokinetically while the total cyclone flowrate was kept constant with the addition of variable amounts of recycle gas. Eight replicates of the paired measurements were initiated. However, equipment malfunctions invalidated the first two EGR runs, and the fifth EGR/SIM5 run was aborted after the boiler dropped from 240 MW to 90 MW due to plugging of a fuel feed line. The run parameters, total mass loadings, and  $PM_{10}$  mass loadings for these tests are shown in Table 5-2. As with the first field test, the samples were obtained within 10% of the isokinetic ratio. In this test series the recycle rates consistently averaged around 46%.

Table 5-1. EGR test 1 run parameters.

	<u>Sample Flow (acfm)</u>	<u>Percent Recycle</u>	<u>Percent Isokinetic</u>	<u>Boiler Load (MW)</u>	<u>Mass Loading (mg/dnm<sup>3</sup>)</u>	<u>PM<sub>10</sub> Loading (mg/dnm<sup>3</sup>)</u>
Run 2						
M17	0.67	--	164.3	56	1557 <sup>a</sup>	--
EGR	0.56	18.0	98.1		2053	453
Run 3						
M17	0.57	--	99.4	34	586	--
EGR	0.33	59.6	96.8		543	113
Run 4						
M17	0.40	--	96.1	56	2397	--
EGR	0.59	15.6	100.9		1952	391
Run 5						
M17	0.42	--	100.6	56	2077	--
EGR	0.62	15.7	107.5		1804	411
Run 6						
M17	0.48	--	107.7	56	1888	--
EGR	0.64	9.6	104.5		1808	399
Run 7						
M17	0.49	--	104.7	28	61.9	--
EGR	0.57	20.8	105.9		42.9	17.8
STD	0.66	--	89.7		46.5	18.5
Run 8						
M17	0.45	--	107.2		87.9	--
EGR	0.53	41.6	108.8	28	75.7	21.8
STD	0.67	--	102.7		57.2	21.8
Run 9						
M17	0.49	--	111.9		65.3	--
EGR	0.55	33.6	111.0	28	63.9	20.5
STD	0.74	--	107.9		67.0	28.8
Run 10						
M17	0.47	--	99.7		80.9	--
EGR	0.56	34.9	101.9	28	74.5	27.8
STD	0.74	--	100.6		60.4	26.6

<sup>a</sup>M17 control box malfunction--run deleted from test averages.

Table 5-2. EGR test 2 run parameters.

	<u>Sample Flow (acfm)</u>	<u>Percent Recycle</u>	<u>Percent Isokinetic</u>	<u>Mass Loading (mg/dnm<sup>3</sup>)</u>	<u>PM<sub>10</sub> Loading (mg/dnm<sup>3</sup>)</u>
Run 1					
EGR	0.40	38.9	111.7	-- <sup>a</sup>	110
SIM5	0.60	--	95.1	264	124
Run 2					
EGR	0.33	47.7	98.4	-- <sup>b</sup>	--
SIM5	0.61	--	94.0	213	109
Run 3					
EGR	0.34	46.5	96.5	195	94
SIM5	0.62	--	97.3	201	107
Run 4					
EGR	0.35	46.3	99.7	279	130
SIM5	0.59	--	92.4	307	138
Run 6					
EGR	0.34	48.6	99.1	115	56
SIM5	0.61	--	100.2	130	66
Run 7					
EGR	0.34	47.5	99.6	200	86
SIM5	0.60	--	94.4	207	104
Run 8					
EGR	0.36	45.3	97.1	189	79
SIM5	0.60	--	91.7	228	104

<sup>a</sup>Excessive nozzle scrape -- total mass not included in test averages.

<sup>b</sup>Invalidated run -- deleted from test averages.

### 5.8.3 TEST NO. 3

The site chosen for the third EGR field test was a 221 MW coal-fired utility boiler. Sampling took place at the inlets to two identical particulate control devices. Eight four-inch ports provided access to the duct interior on each unit. The velocity of Duct A ranged from 37 to 64 ft/sec, with a mean velocity of approximately 51 ft/sec. Duct B had a velocity range of 45 to 61 ft/sec, with an average of 53 ft/sec.

The test plan called for a concurrent EGR/nonrecycle (SIM5) test series similar to that of Test No. 2. The flowrate for each train was chosen such that the aerodynamic  $D_{50}$  for the first cyclone was 10  $\mu\text{m}$ . Across the traverse, the EGR nozzle sampled isokinetically while a constant cyclone flow rate was maintained using a variable fraction of recycle gas. The nonrecycle cyclone train once again sampled according to SIM5 protocol. In this test, full duct (12-point)  $\text{PM}_{10}$  measurements were performed rather than the three-point sample in Test 2. Each 12-point traverse involved sampling at three points in four of the eight ports. The eight ports available for sampling on each duct were grouped into two sets of four, ACEG and BDFH. Four sets of simultaneous EGR and nonrecycle (SIM5) runs were performed at the inlet to Unit A. Two traverses were performed in ports ACEG and two in ports BDFH. Two replicates were performed in Duct B using ports ACEG. The sampling hardware used for both the EGR and nonrecycle (SIM5) trains throughout this testing consisted of full SoRI Five-Stage Series Cyclone sets. The run parameters and loadings for the paired cyclone runs are shown in Table 5-3. The recycle rate averaged about 48% with little variation from run to run.

### 5.8.4 RESULTS AND CONCLUSIONS FROM COLLABORATIVE TESTS

Average particulate concentrations and 95% confidence limits from the data obtained in the three test series are summarized in Table 5-4. As can be seen, the tests covered a broad range of particulate concentrations. At every site, the EGR train and the comparison device measured particulate concentrations which agreed within the combined confidence limits of the measurements. Table 5-4 also presents the relative standard deviation (standard deviation expressed as a percentage of the mean value) of each set of runs. In two cases the relative standard deviation of the EGR is over 15% (Site 1 at low load and Site 2). At Site 2 the same degree of variation is seen in measurements with comparison devices. Since the testing coincided with a period of coal pulverizer problems, the variability is easily attributable to source instability. Some indication of source variability was also noted at Site 1 at low load, although the variance of the EGR data is greater than that seen by the other techniques. It is also interesting to note that the precision of the  $\text{PM}_{10}$  measurements is better in every case than that of total mass measurements with the same device.

The test plan for all three sites included simultaneous measurements (collocated where possible) with the EGR train and suitable comparison devices in order to minimize the effects of source temporal variability.

Table 5-3. EGR test 3 run parameters.

	<u>Sample Flow (acfm)</u>	<u>Percent Recycle</u>	<u>Percent Isokinetic</u>	<u>Sampling Duct</u>	<u>Mass Loading (mg/dnm<sup>3</sup>)</u>	<u>PM<sub>10</sub> Loading (mg/dnm<sup>3</sup>)</u>
Run 1						
EGR	0.30	48.4	101.3	A	3630	744
SIM5	0.60	--	97.2	A	4090	776
Run 2						
EGR	0.31	47.9	100.8	A	3570	791
SIM5	0.58	--	99.4	A	2920	659
Run 3						
EGR	0.32	44.0	98.9	A	2740	749
SIM5	0.51	--	105.1	A	3750	650
Run 4						
EGR	0.30	48.4	101.6	A	3810	752
SIM5	0.57	--	98.5	A	3830	660
Run 5						
EGR	0.31	49.1	99.4	B	3830	814
SIM5	0.56	--	120.8	B	3270	756
Run 6						
EGR	0.31	52.2	101.1	B	4330	969
SIM5	0.57	--	105.9	B	3680	794

Table 5-4. Average particulate concentrations observed in EGR test series

		Total Mass		PM <sub>10</sub>	
	No. of Runs	Average Loading (mg/dnm <sup>3</sup> )	Relative Standard Deviation (%)	Average Loading (mg/dnm <sup>3</sup> )	Relative Standard Deviation (%)
<u>Site 1</u>					
High boiler load					
M17 mass train	3	2120 (±638) <sup>a</sup>	12.1	--	--
EGR cyclone train	4	1904 (±192)	6.3	413 (±44)	6.7
Low boiler load					
M17 mass train	4	74 (±20)	16.8	--	--
EGR cyclone train	4	65 (±24)	23.4	22 (±6.7)	19.1
Std. cyclone train	4	57 (±12)	13.2	23 (±7.5)	19.7
<u>Site 2</u>					
EGR cyclone train	6	196 (±72)	29.7	92 (±26)	7.1
SIM5 cyclone train	7	221 (±51)	24.9	107 (±23)	6.4
<u>Site 3</u>					
EGR cyclone train	6	3650 (±546)	14.3	803 (±90)	10.7
SIM5 cyclone train	6	3590 (±444)	11.8	716 (±70)	9.3

<sup>a</sup>  
95% confidence intervals are indicated for each mean particulate loading.

Table 5-5 contains a paired run analysis of the test data. The entries in Table 5-5 represent means and 95 percent confidence limits of individual run percentage differences for the paired measurements of total particulate mass or  $PM_{10}$  concentration. The percentage differences between the EGR and SIM5 values are relative to the mean of the two concentrations. No consistent trend is seen between the EGR and comparison measurements, and the differences typically do not exceed the 95% significance level.

In summary, the EGR train continues to be a promising technique for source particulate measurements. Further development of the technique should include correction of the few design deficiencies discovered during these tests, adaptation of the EGR concept to a cascade impactor for more detailed size distribution measurements, and further field validation of the concept. It is believed that the method has excellent potential to satisfy the requirements of a  $PM_{10}$  reference method.

Table 5-5. Percentage difference between EGR cyclone train and reference device in paired runs.

	<u>Number of Runs</u>	<u>Total Mass</u>	<u><math>PM_{10}</math></u>
Site 1 (Method 17)	8	-11.5±8.3	--
Site 1 (Nonrecycle cyclone)	4	9.0±28.7	-8.3±27.4
Site 2 (SIM5 cyclone)	5	-9.3±8.4	-15±6.5
Site 3 (SIM5 cyclone)	6	1.6±20.0	11.4±9.7

a

Quoted values represent the mean and 95 percent confidence limits of the difference between the EGR concentration and the comparison device concentration on individual runs, expressed as a percentage of the overall mean reference concentration.



## SECTION 6

### FIELD DEMONSTRATION

A field demonstration of the hardware and techniques described in the three protocols was carried out in Sacramento during the week of January 13, 1986. The demonstrations included actual field sampling and explanations of the equipment and techniques in the laboratory.

The number of samples and the extent to which the protocols could be followed in detail were limited by problems in locating a suitable source, and, once a source was decided upon, by problems in the source operation.

Initially, the source to be used for the field demonstration was a petroleum coke fired boiler operated by the Avon Refinery which was located near Concord, CA. The sampling equipment and personnel arrived at that site on the morning of Monday, 1/13 and equipment setup was begun. However, before setup was complete, the sampling ports were found to be restricted in their internal diameters so that the samplers for two of the three methods could not be inserted into the duct. Both the  $PM_{10}$  (EGR) and Five-Stage Cyclone samplers are designed to work through four inch pipe size or larger ports, but four inch ports must be completely unobstructed. The impactors can be inserted through somewhat smaller ports. The sampling ports at the Avon site were four inch pipe nipples, but they contained 1/8 to 3/16 inch weld beads around their inner circumferences and had been mounted off center on four inch holes cut into the ducting. The weld beads and the lips which resulted from the off center mounting of the nipples made insertion of the  $PM_{10}$  and cyclone samplers impossible. Therefore, the equipment and personnel returned to Sacramento while an alternate site was sought.

On Tuesday, 1/14 a pilot plant gasifier was selected as the field site. The gasifier is operated as a research unit by the State of California at its central steam plant in Sacramento. The material to be gasified is typically wood slash and/or municipal refuse. Emission testing was already underway on the gasifier for other purposes at this time and the methods demonstrations had to be carried out in a way that would not interfere with those tests. The availability of the gasifier for testing was limited by the amount of fuel which was on hand. Sufficient fuel was on hand for only two to three hours of operation, consequently the sampling associated with the methods demonstrations had to take place concurrent with the ongoing emissions tests.

Equipment setup for sampling at the gasifier stack was begun early on 1/14 in preparation for testing on 1/14 and 1/15. Unfortunately, a fan bearing failed on the gasifier, and the day was lost for sampling while repairs were made. Thursday, 1/16 had been reserved for laboratory demonstrations which could not be rescheduled because of conflicts with other activities of the attending personnel. Thus the field sampling was finally limited by fuel availability and other circumstances to two periods of about one hour each on the morning of Wednesday 1/15.

A total of four six-inch ports had been installed on the stack, of which two were free for the demonstration. The four ports were installed in single plane, making simultaneous traverses through all four impossible. Because of

the limited fuel, all sampling for the emission tests and the methods demonstrations had to take place concurrently. The ongoing emissions testing program had priority; therefore the three demonstration systems had to sample through only two ports and do so in a way that would not interfere with the traverses which were being made through the other two. As a consequence, the demonstration runs were made as single point samples in one quadrant of the stack rather than as full traverses as specified by the protocols.

Sampling took place during the first period of gasifier operation with all three of the methods. The two one-hour periods of gasifier operation were separated by too short a period of time to permit the  $PM_{10}$  sampler to be cleaned up and readied for another run so only one sample<sub>10</sub> was obtained with it. A single run which spanned both periods of gasifier operation was made with the Five-stage Cyclone sampler. The latter is intended to collect material for chemical analysis and a single large sample is more useful for that purpose than two smaller samples. In any case, there would not have been enough time to recover a sample and prepare for a second run in the interval between the two test burns. Two impactor runs were made, one during each period of gasifier operation.

The impactor from the first run was opened and inspected on site at the steam plant shortly after the run was completed to check on stage loadings. These were thought to be too high on the basis of visual inspection and the second run was shortened to one third of the sampling duration used in the first. Even with the reduced sampling time, the catches on three of the stages from the second run were larger than the limits called for in the protocol but they were probably not so large as to invalidate the results.

The collected particulate matter was left in the samplers overnight so that they could be used in the laboratory demonstrations on the 16th. They were then unloaded as part of the lab demonstration. The cyclone samples were recovered by washdowns using methylene chloride as called for by the protocol and preserved for possible chemical analyses so no results can be reported from that run. The demonstration was not to include actual analyses but the samples were saved for possible analysis at a later time at the discretion of the ARB. Results are included here for the two impactor runs and the  $PM_{10}$  run. The total concentrations from those three runs were calculated to be 730, 938, and 863 mg/dnm3 for the first and second impactor runs and the  $PM_{10}$  run respectively. The concentrations for particles smaller than  $10\mu m$  were respectively 568, 797, and 820 mg/dnm3.

Because of the severe overloading in the first impactor run, the results from it should be discounted insofar as the size distribution is concerned. The concentration of particles smaller than  $10\mu m$  from the  $PM_{10}$  sampler is valid (subject to the uncertainty resulting from its being from a single point sample). However, some part of the cyclone catch (particles larger than  $10\mu m$ ) from that run was lost while showing the sample and sampler during the lab demonstration. Therefore the total concentration from the  $PM_{10}$  sample is low by an unknown amount.

The mass median diameter of the emissions as measured in the second impactor run was  $2.5\mu\text{m}$  on an aerodynamic diameter basis and the distribution was approximately log-normal with a sigma-g of about 4. The data suggest that the distribution was really trimodal with the bulk of the emissions in a mode centered at about  $2.5\mu\text{m}$ . The remainder of the emissions would then fall in two lower concentration modes; one centered near  $25\mu\text{m}$  and one near  $0.3\mu\text{m}$ . However, with only one run, and that possibly flawed by overloading, the reality of the latter modes is open to question. Printouts from the  $\text{PM}_{10}$  (EGR) and impactor data reduction programs are given in Figures 6-1, 6-2, and 6-3. These include both the raw data and the final results. Plots of the size distribution results from the second impactor run are given in Figures 6-4 through 6-6.

EXHAUST GAS RECIRCULATION  
DATA REDUCTION  
VERSION 3.3    FEBRUARY 1986

TEST ID. CODE: CARB EGR1  
TEST LOCATION: GASSIFIER OUTLET  
TEST SITE:        SACRAMENTO/CALIFORNIA  
TEST DATE:        1-15-86  
OPERATOR(S):      RSMartin

\*\*\*\*\* ENTERED RUN DATA \*\*\*\*\*

<b>TEMPERATURES</b> T(STK): 310.1 F T(RCL): 323.4 F T(LFE): 60.9 F T(DGM): 56.6 F	<b>SYSTEM PRESSURES</b> DH(ORI): 1.14 INWG DP(TOT): 1.69 INWG P(INL): 5.23 INWG DP(RCL): 1.69 INWG DP(PTO): 0.30 INWG	<b>MISCELLANEA</b> P(BAR): 30.02 INHG DP(STK): 0.00 INWG V(DGM): 10.007 FT3 TIME: 42.00 MIN % CO2: 12.10 % O2: 6.30 NO2 (IN): 0.1853
<b>WATER CONTENT</b> ESTIMATE: 16.9 % OR CONDENSER: 0.0 ML COLUMN: 0.0 GM	<b>RAW MASSES</b> CYCLONE 1: 12.5 MG FILTER: 237.4 MG IMPINGER RESIDUE: 0.0 MG	<b>BLANK VALUES</b> CYC RINSE: 0.0 MG FILTER HOLDER RINSE: 0.0 MG FILTER BLANK: 0.0 MG IMPINGER RINSE: 0.0 MG
<b>CALIBRATION VALUES</b> CP(PITOT): 0.830 DH0(ORI): 10.980 M(TOT LFE): 0.2298 B(TOT LFE): -.0058 M(RCL LFE): 0.0948 B(RCL LFE): -.0007 DGM GAMMA: 0.9940		

\*\*\*\*\* REDUCED DATA \*\*\*\*\*

STACK VELOCITY (FT/SEC) STACK GAS MOISTURE (%) SAMPLE FLOWRATE (ACFM) TOTAL FLOWRATE (ACFM) RECYCLE FLOWRATE (ACFM) PERCENT RECYCLE ISOKINETIC RATIO (%)	37.11 16.9 0.4263 0.6687 0.2501 36.2 102.2
(UM)    (%)    (MG/DNCF)    (GR/ACF)    (GR/DCF)    (LB/DSCF) (PARTICULATE)	
CYCLONE 1	9.44    95.0    43.2    0.01075    0.01882    2.69457
BACKUP FILTER	---    ---    819.6    0.20420    0.35742    51.175
PARTICULATE TOTAL	---    ---    862.8    0.21495    0.37623    53.870

Figure 6-1. Data and results from the PM10 sampling run during the ARB demonstration.

\*\*\*\*\*IMPACTOR VERSION 4.1\*\*\*\*\*

\*\*\*\*\* INPUT DATA \*\*\*\*\*

1) PART. DIAMETER CLASSICAL AERODYNAMIC  
2) DATE OF TEST: 1/15/86  
3) TIME OF TEST: 0740  
4) LOCATION OF TEST: GASSIFIER STACK  
5) TEST NUMBER 0  
6) TEST TYPE OUTLET  
7) RUN NUMBER: CARB1-FILE NAME: T0RCARB1.OT  
8) RUN REMARKS: OVERLOADED  
10) IMPACTOR TYPE: CARB HIFLO  
PC-3-4-5-7-9-11  
  
9) WATER VAPOR 16.90% (KEYBOARD)  
CO2 12.10% CO 1.00%  
O2 6.30% N2 80.60%  
12) ORIFICE ID (OPTIONAL): .130 NOT IN FILE  
13) SUBSTRATE MATERIAL: AP. H ON SS

1) GAS METER VOL 8.868 CUBIC FEET  
2) IMPACTOR DELTA P .00 IN. HG.  
3) ORIFICE DELTA P .00 INCHES H2O  
4) STACK PRESSURE .00 INCHES H2O  
5) BAROMETRIC PRES 30.02 INCHES HG  
6) STACK TEMP 323 DEGREES F  
7) METER TEMP 53 DEGREES F  
8) IMPACTOR TEMP 323 DEGREES F  
9) SAMPLE TIME 20.00 MINUTES  
10) AVG GAS VEL 36.14 FEET/SEC  
11) ORIFICE PRES .00 INCHES HG  
12) NOZZLE DIA .250 INCHES  
13) MAX PART DIA 100.0 MICRONS  
14) WATER VOLUME .0 CC  
15) METER FACTOR 1.0148

MASS GAIN OF STAGE 1 41.15 MG  
MASS GAIN OF STAGE 2 30.06 MG  
MASS GAIN OF STAGE 3 34.77 MG  
MASS GAIN OF STAGE 4 30.00 MG  
MASS GAIN OF STAGE 5 20.23 MG  
MASS GAIN OF STAGE 6 13.35 MG  
MASS GAIN OF STAGE 7 11.32 MG  
MASS GAIN OF FILTER 12.79 MG

MASS GAIN OF BLANK SUBSTRATE .21  
MASS GAIN OF BLANK FILTER .14

Figure 6-2a. Data from the first impactor run made during the ARB demonstration.

\*\*\*\*\* RESULTS \*\*\*\*\*

TEST NUMBER: 0 RUN NUMBER: CARB1

ACTUAL FLOW RATE .826 CFM  
 FLOW RATE AT STANDARD CONDITIONS .465 CFM  
 PERCENT ISOINETIC 111.810 %  
 VISCOSITY 219.8E-06GM/CM SEC  
 CALCULATED IMPACTOR DELTA P = 5.48 IN. HG

STAGE	CUNN. CORR.	DP (CLAS AERO)	DP (IMP AERO)	CUM FREQ.	RE. NO.	VxD50 UM-M/S
1	1.025	9.576	9.694	78.684	1410	29.5
2	1.061	3.912	4.029	63.142	612	27.2
3	1.116	2.060	2.176	45.147	252	18.2
4	1.201	1.191	1.305	29.637	320	20.9
5	1.397	.614	.726	19.213	475	23.7
6	1.767	.338	.450	12.371	650	23.6
7	2.461	.196	.307	6.5865	1219	26.5

STAGE CUT DIAMETERS BASED ON THEORETICAL VALUES OF STAGE CONSTANTS

TOTAL MASS CONCENTRATION = 7.30E+02 MG/DRY NORMAL CUBIC METER

SPLINE FIT ON CLASSICAL AERODYNAMIC DIAMETER BASIS

PARTICLE DIA. (MICRONS)	CUMFR (STDDEV)	CUMFR (PERCENT)	CUM.MASS (MG/DRY N.CU.METER)	DM/DLOGD
.100	- 2.0431	2.05	1.50E+01	6.62E+01
.159	- 1.6761	4.69	3.42E+01	1.31E+02
.251	- 1.3401	9.01	6.57E+01	1.79E+02
.398	- 1.0697	14.24	1.04E+02	1.91E+02
.631	- .8583	19.54	1.43E+02	2.03E+02
1.000	- .6389	26.15	1.91E+02	3.01E+02
1.585	- .3281	37.14	2.71E+02	4.92E+02
2.512	.0303	51.21	3.74E+02	5.00E+02
3.981	.3459	63.53	4.64E+02	3.87E+02
6.310	.5982	72.51	5.29E+02	2.78E+02
10.000	.8038	78.93	5.76E+02	9.58E+01
15.850	.9069	81.78	5.97E+02	1.23E+02
25.120	1.1011	86.46	6.31E+02	2.34E+02
39.810	1.6361	94.91	6.92E+02	3.49E+02
63.100	3.7630	99.99	7.30E+02	5.62E+00
100.00	1000000	100.00	7.30E+02	0.00E+00
158.50	1000000	100.00	7.30E+02	0.00E+00
251.20	1000000	100.00	7.30E+02	0.00E+00
398.10	1000000	100.00	7.30E+02	0.00E+00
631.00	1000000	100.00	7.30E+02	0.00E+00

\*\*\* INHALABLE PARTICULATE MATTER \*\*\*

CUM MASS LESS THAN 1.000 MICRON: 190.76 MG/DNM3 ( 26.15 %)  
 CUM MASS LESS THAN 2.512 MICRON: 373.65 MG/DNM3 ( 51.21 %)  
 CUM MASS LESS THAN 10.000 MICRON: 575.86 MG/DNM3 ( 78.93 %)  
 CUM MASS LESS THAN 15.850 MICRON: 596.68 MG/DNM3 ( 81.78 %)  
 NOTE: DIAMETERS FOR INHALABLE PARTICULATE MATTER ARE  
 ON CLASSICAL AERODYNAMIC BASIS.

Figure 6-2b. Results of the first impactor run made during the ARB demonstration.

\*\*\*\*\*IMPACTOR VERSION 4.1\*\*\*\*\*

\*\*\*\*\* INPUT DATA \*\*\*\*\*

1) PART. DIAMETER CLASSICAL AERODYNAMIC  
2) DATE OF TEST: 1/15/86  
3) TIME OF TEST: 0948  
4) LOCATION OF TEST: GASSIFIER STACK  
5) TEST NUMBER 0  
6) TEST TYPE OUTLET  
7) RUN NUMBER: CARB2-FILE NAME: T0RCARB2.OT  
8) RUN REMARKS: SHORT RUN  
10) IMPACTOR TYPE: CARB HIFLO  
PC-3-4-5-7-9-11

9) WATER VAPOR 16.40% (KEYBOARD)  
CO2 12.10% CO 1.00%  
O2 6.30% N2 80.60%  
12) ORIFICE ID (OPTIONAL): .130 NOT IN FILE  
13) SUBSTRATE MATERIAL: AP. H ON SS

1) GAS METER VOL 3.036 CUBIC FEET  
2) IMPACTOR DELTA P .00 IN. HG.  
3) ORIFICE DELTA P .00 INCHES H2O  
4) STACK PRESSURE .00 INCHES H2O  
5) BAROMETRIC PRES 30.02 INCHES HG  
6) STACK TEMP 310 DEGREES F  
7) METER TEMP 55 DEGREES F  
8) IMPACTOR TEMP 310 DEGREES F  
9) SAMPLE TIME 7.00 MINUTES  
10) AVG GAS VEL 36.14 FEET/SEC  
11) ORIFICE PRES .00 INCHES HG  
12) NOZZLE DIA .250 INCHES  
13) MAX PART DIA 100.0 MICRONS  
14) WATER VOLUME .0 CC  
15) METER FACTOR 1.0148

MASS GAIN OF STAGE 1 12.90 MG  
MASS GAIN OF STAGE 2 16.92 MG  
MASS GAIN OF STAGE 3 19.15 MG  
MASS GAIN OF STAGE 4 15.71 MG  
MASS GAIN OF STAGE 5 7.76 MG  
MASS GAIN OF STAGE 6 5.17 MG  
MASS GAIN OF STAGE 7 5.01 MG  
MASS GAIN OF FILTER 3.60 MG

MASS GAIN OF BLANK SUBSTRATE .26  
MASS GAIN OF BLANK FILTER .18

*Figure 6-3a. Data from the second impactor run made during the ARB demonstration.*

\*\*\*\*\* RESULTS \*\*\*\*\*

TEST NUMBER: 0 RUN NUMBER: CARB2

ACTUAL FLOW RATE .787 CFM  
 FLOW RATE AT STANDARD CONDITIONS .453 CFM  
 PERCENT ISOKINETIC 106.493 %  
 VISCOSITY 217.2E-06GM/CM SEC  
 CALCULATED IMPACTOR DELTA P = 5.02 IN. HG

STAGE	CUNN. CORR.	DP (CLAS AERO)	DP (IMP AERO)	CUM FREQ.	RE. NO.	VX050 UM-M/S
1	1.024	9.760	9.876	84.992	1384	28.6
2	1.059	3.990	4.105	65.210	601	26.5
3	1.111	2.107	2.221	42.781	247	17.8
4	1.191	1.222	1.334	24.436	315	20.4
5	1.377	.633	.742	15.531	466	23.2
6	1.720	.350	.459	9.7008	638	23.2
7	2.354	.205	.314	4.0608	1197	26.3

STAGE CUT DIAMETERS BASED ON THEORETICAL VALUES OF STAGE CONSTANTS

TOTAL MASS CONCENTRATION = 9.38E+02 MG/DRY NORMAL CUBIC METER

SPLINE FIT ON CLASSICAL AERODYNAMIC DIAMETER BASIS

PARTICLE DIA. (MICRONS)	CUMFR (STDDEV)	CUMFR (PERCENT)	CUM.MASS (MG/DRY N.CU.METER)	DM/DLOGD
----------------------------	-------------------	--------------------	---------------------------------	----------

.100	- 2.5728	.51	4.74E+00	3.65E+01
.159	- 2.0394	2.07	1.94E+01	1.25E+02
.251	- 1.5598	5.94	5.57E+01	2.23E+02
.398	- 1.2201	11.12	1.04E+02	2.31E+02
.631	- 1.0149	15.51	1.45E+02	1.94E+02
1.000	- .8196	20.62	1.93E+02	3.34E+02
1.585	- .4655	32.08	3.01E+02	7.46E+02
2.512	- .0123	49.51	4.64E+02	8.08E+02
3.981	.3887	65.12	6.11E+02	6.44E+02
6.310	.7351	76.89	7.21E+02	4.67E+02
10.000	1.0476	85.26	8.00E+02	2.35E+02
15.850	1.2766	89.91	8.44E+02	2.09E+02
25.120	1.5947	94.46	8.86E+02	2.19E+02
39.810	2.2519	98.78	9.27E+02	1.53E+02
63.100	4.4991	100.00	9.38E+02	3.55E-01
100.00	1000000	100.00	9.38E+02	0.00E+00
158.50	1000000	100.00	9.38E+02	0.00E+00
251.20	1000000	100.00	9.38E+02	0.00E+00
398.10	1000000	100.00	9.38E+02	0.00E+00
631.00	1000000	100.00	9.38E+02	0.00E+00

\*\*\* INHALABLE PARTICULATE MATTER \*\*\*

CUM MASS LESS THAN 1.000 MICRON: 193.49 MG/DNM3 ( 20.62 %)  
 CUM MASS LESS THAN 2.512 MICRON: 464.48 MG/DNM3 ( 49.51 %)  
 CUM MASS LESS THAN 10.000 MICRON: 799.89 MG/DNM3 ( 85.26 %)  
 CUM MASS LESS THAN 15.850 MICRON: 843.56 MG/DNM3 ( 89.91 %)  
 NOTE: DIAMETERS FOR INHALABLE PARTICULATE MATTER ARE  
 ON CLASSICAL AERODYNAMIC BASIS.

Figure 6-3b. Results of the second impactor run made during the ARB demonstration.







Figure 6-4. Particle size distribution results on a cumulative percentage basis as obtained from the second impactor run of the demonstration testing.






Figure 6-6. Particle size distribution results on a cumulative mass concentration basis from the second impactor run of the demonstration testing.



## REFERENCES

- Aldina, G.L. and J.A. Jahnke. APTI Course 450 Source Sampling for Particulate Pollutants. EPA 450/2-79-006, U.S. Environmental Protection Agency, Research Triangle Park, NC, December 1979. 202 pp.
- Ayer, H.E., and J.M. Hochstrasser. Cyclone Discussion. In: Aerosol Measurement, D.A. Lundgreen, et. al., eds. University Presses of Florida, Gainesville, FL, 1979. pp 70-79.
- Beeckmans, J.M. Analysis of the Cyclone As A Size Selective Aerosol Sampler. In: Aerosol Measurement, D.A. Lundgren, et. al., eds. University Presses of Gainesville, FL. 1979. pp 56-69.
- Beers, Y. Introduction to the Theory of Error. 2nd Edition. Addison-Wesley, Inc., Reading, MA. 1957.
- Brink, J.A., Jr. Cascade Impactor for Adiabatic Measurements. Industrial and Engineering Chemistry 50:4(645-648), 1958.
- Chan, T., and M. Lippman. Particle Collection Efficiencies of Air Sampling Cyclones: An Empirical Theory. Environ Sci. Technol. 11(4): 377-382, 1977.
- Cheng, Yung-Sung and Hsu-Chi Yeh. Particle Bounce in Cascade Impactors. Environ. Sci. Technol., 13:1392-1396, 1979.
- Cooper, Douglas W. Problems (and Solutions) in Signing Emissions from Scrubbers. In Proceedings of the Workshop on Sampling, Analysis, and Monitoring of Stack Emissions (Dallas, Texas, October, 1975) EPRI SR-41, Electric Power Research Institute, Palo Alto, CA, 1976. p. 295-316.
- Cushing, K.M. Particulate Sampling in Process Streams in the Presence of Sulfur Oxides. In Workshop Proceedings on Primary Sulfate Emissions from Combustion Sources. Vol. I. EPA-600/9-78-020a, U.S. Environmental Protection Agency, RTP, NC, 1978.
- Cushing, K.M., G.E. Lacey, J.D. McCain, and W.B. Smith. Particulate Sizing Techniques for Control Device Evaluation: Cascade Impactor Calibrations. EPA-600/2-76-280 (NTIS PB262849), U.S. Environmental Protection Agency, RTP, NC, 1976. 94 pp.
- Cushing, K.M., J.D. McCain, and W.B. Smith. Experimental Determination of Sizing Parameters and Wall Losses of Five Source-Test Cascade Impactors. Environ. Sci. Technol. 13(6):726-731, 1979.
- Dahneke, B. The Capture of Aerosol Particles by Surfaces. J. Colloid Interface Sci., 37(2):342, 1971.
- Davies, C.N. The Separation of Airborne Dust and Particles, Proc. Inst. Mech. Engng. 1(B): 185-198, 1952.

- Farthing, William E. Impactor Behavior at Low Stage Re., Aerosol Science and Technology, 2(2):242, 1983.
- Farthing, W.E., D.H. Hussey, W.B. Smith, and R.R. Wilson, Jr. Sampling Charged Particles with Cascade Impactors. EPA-600/7-79-027, U.S. Environmental Protection Agency, Cincinnati, OH, January 1979. 79 pp.
- Farthing, William E., and Ashley D. Williamson. A Unified View of Inertial Impactors and Cyclones. Presented at 1985 Annual Meeting of AAAR, Albuquerque, NM.
- Farthing, W.E., A.D. Williamson, J.D. McCain, and T.E. Ward. Evaluation of Protocols for Size-Specific Emission Measurements. Presented at the 78th Annual Meeting of the Air Pollution Control Association, Detroit, MI. 1985. Paper 85-14-3.
- Felix, L.G., and McCain, J.D. Errors in Recovered Particle Size Distributions Caused by Sampling with Bent Nozzles. Paper presented at 74th Annual Meeting of the Air Pollution Control Association, Philadelphia, PA, June 1981.
- Felix, L.G., G.I. Clinard, G.E. Lacey, and J.D. McCain. Inertial Cascade Impactor Substrate Media for Flue Gas Sampling. EPA-600/7-77-060 (NTIS PB276583), U.S. Environmental Protection Agency, RTP, NC, 1979. 89 pp.
- Felix, L.G., D.H. Hussey, and J.D. McCain. Development, Design, and Operation of a Cascade Impactor to Collect Aerosol Samples for Wavelength Dispersive X-Ray Fluorescence Analysis. SoRI-EAS-81-569, final report for EPA Contract No. 68-02-2992, T.E. Ward Project Officer for U.S. Environmental Protection Agency, RTP, NC, October, 1982.
- Flagan, Richard C. Compressible Flow Inertial Impactors. J. of Colloid and Interface Science, 87(1):291-299, 1982.
- Fuchs, N.A. The Mechanics of Aerosols, Pergamon Press, NY, 1964.
- Harris, D.V. and L. Beddingfield. Isokinetic Sampling With Fixed Flow Rate Devices Using Exhaust Gas Recirculation. Presented at the Third EPA Symposium on Advances in Particulate Sampling and Measurement, Daytona Beach, FL. 1981.
- Hering, S.Y., R.C. Flagan, and S.K. Friedlander. Design and Evaluation of a New Low-Pressure Impactor Part 1. American Chemical Society 12(6):667-673, 1978.
- Hodgman, C.D., ed. Handbook of Chemistry and Physics. 41st Ed., Chemical Rubber Publishing Co., Cleveland, OH, 1959. pp. 2188-2192.
- Hochstrasser, J.M. The Investigation and Development of Cyclone Dust Collector Theories for Application to Miniature Cyclone Presamplers. Ph. D Dissertation, University of Cincinnati, 1976.
- Johnson, J.W., G.I. Clinard, L.G. Felix, and J.D. McCain. A Computer-Based Cascade Impactor Data Reduction System. EPA-600/7-78-042 (NTIS PB285433), U.S. Environmental Protection Agency, RTP, NC, 1978. 601 pp.

- Jordan, D.W. The Adhesion of Dust Particles. British J. Applied Phys. Suppl., 3:S, 1954.
- Knapp, Kenneth T. The Effects of Nozzle Losses on Impactor Sampling. Paper No. 6 in Proceedings: Advances in Particle Sampling and Measurement (Datona Beach, FL, October 1979). EPA-600/9-80-004, W.B. Smith, Editor, U.S. Environmental Protection Agency, RTP, NC, 1980. pp. 101-106.
- Knight, G. Tentative Specifications for Respirable Dust Sampling. In correspondence to ACGIH Aerosol Hazards Committee, January 28, 1976.
- Lawless, P.A. Analysis of Cascade Impactor Data for Calculating Particle Penetration. EPA-600/7-78-187, U.S. Environmental Protection Agency, RTP, NC, 1978. 44 pp.
- Lee, K.W., J.A. Greseke, and W.H. Piispanen. Evaluation of Cyclone Performance in Different Gases. Atmospheric Environment, 19(6): 847-852, 1985.
- Leith, D., and W. Licht. The Collection Efficiency of Cyclone Type Particle Collection - A New Theoretical Approach. In AIChE Symp. Ser. 68, 1972. pp 196-206.
- Löffler, F. The Adhesion of Dust Particles to Fibrous and Particulate Surfaces. Staub-Reinhalt Luft (English ed.), 28(11):29, 1968.
- Marple, V.A. A Fundamental Study of Inertial Impactors, Ph.D. Dissertation, University of Minnesota, Minneapolis, MN, 1970.
- Marple, V.A. and Liu, B.Y.H. Characteristics of Laminar Jet Impactors. Environ. Sci. Technol. 8(7):648-654, 1974.
- Martin, Robert M. Construction Details of Isokinetic Source-Sampling Equipment. U.S. Environmental Protection Agency, RTP, NC. Air Pollution Control Office Pub. No. APTD-0581, April, 1971. 32 pp.
- McCain, Joseph D., James W. Ragland. Calibration of the Soviet SIB-2 Submicron Impactor. Special Report, Project 4181-50, SoRI-EAS-82-070, January, 1982.
- McCain, J.D., G.I. Clinard, L.G. Felix, and J.W. Johnson. A Data Reduction System for Cascade Impactors. Paper No. 11 in Proceedings: Advances in Particle Sampling and Measurement (Ashville, NC, May 1978). W.B. Smith, Compiler, EPA/7-79-065, U.S. Environmental Protection Agency, RTP, NC, 1979. pp. 228-259.
- McCain, J.D., L.G. Felix, and W.E. Farthing. Steps to Void Particle Size Data From Emissions Sources. In: Quality Assurance for Environmental Measurements, ASTM STP 867. J.K. Taylor and T.W. Stanley, Eds., American Society for Testing and Materials, Philadelphia, 1985, pp 147-159.

McCain, J.D., unpublished project report 1986.

Mercer, T.T., and R.G. Stafford. Impaction from Round Jets. Ann. Occup. Hyg., 12:41, 1969.

Peters, Edward T. and Jeffrey W. Adams. Evaluation of Stationary Source Particulate Measurement Methods. EPA-600/2-77-026, U.S. Environmental Protection Agency, RTP, NC, 1977. 61 pp.

Quality Assurance Handbook for Air Pollution Measurement Systems Volume III - Stationary Source Specific Methods. EPA-600/4-77-027b, U.S. Environmental Protection Agency, RTP, NC, 1977.

Rao, Arshanapalli Kishan. An Experimental Study of Inertial Impactors. Ph.D. Thesis, University of Minnesota, Minneapolis, MN, 1975. 195 pp.

Rosin, P., E. Rammner, and W. Intelman. Principles and Limits of Cyclone Dust Removal. Z. Ver. dt. Ing., 76:433-437, 1932.

Saltzman, B.E., and J.M. Hochstrasser. Design and Performance of Miniature Cyclones for Respirable Aerosol Sampling. Environ Sci. Technol, 17:418-424, 1983.

Smith, W.B., and R.R. Wilson, Jr. Development and Laboratory Evaluation of a Five-Stage Cyclone System. EPA 600/7-78-008 (NTIS PB 279084), U.S. Environmental Protection Agency, RTP, NC, 1978. p 66.

Smith, W.B., D.B. Harris, and R.R. Wilson, Jr. A Five-Stage Cyclone System for In Situ Sampling. Environ. Sci. and Technol., 13(11): 1387-1392, 1979.

Smith, Wallace B., K.M. Cushing, J.W. Johnson, C.T. Parsons, A.D. Williamson, and R.R. Wilson, Jr. Sampling and Data Handling Methods for Inhalable Particulate Sampling. EPA-600/7-82-036, U.S. Environmental Protection Agency, RTP, NC, May 1982. 297 pp.

Soo, S.L. Some Basic Aspects of Cyclone Separators. Proc. of 1st Intl. Conf. on Particle Technol., IIT Research Inst., 1973. pp 9-16.

Title 40 Code of Federal Regulations Part 60, Appendix A - Reference Methods, U.S. General Services Administration, Office of the Federal Register, National Archives and Records Service, July, 1984.

Von Lehmden, D.J., and A.C. Nelson, Jr. Quality Assurance Handbook for Air Pollution Measurement Systems. Vol. I. Principles. EPA-600/9-76-005 (NTIS PB254658), U.S. EPA, Environmental Monitoring and Support Laboratory, RTP, NC, 1976. 180 pp.

Wilke, C.R. A Viscosity Equation for Gas Mixtures. J. Chem. Phys. 18(4):517-519, 1950.



Williamson, A. D., R. S. Martin, D. B. Harris, and T. E. Ward. Design and Characterization of an Isokinetic Sampling Train for Particle Size Measurements Using Exhaust Gas Recirculation. Presented at the 77th Annual Meeting of the Air Pollution Control Association, San Francisco, CA. 1984. Paper 84-56-5.

Williamson, A. D., R. S. Martin, and S. S. Dawes. Operations Manual for Exhaust Gas Recirculation (EGR) Sampling Train. Draft Report SORI-EAS-68-02-3118, Southern Research Institute, Birmingham, AL. 1984.

Williamson, A. D., R. S. Martin, and T. E. Ward. Development of A Source PM<sub>10</sub> Sampling Train Using Emission Gas Recycle (EGR). Presented at the 78th Annual Meeting of the Air Pollution Control Association, Detroit, MI. 1985. Paper 85-14.2.

Williamson, A. D., D. L. Iozia, P. V. Bush, W. E. Farthing, J. D. McCain, W. B. Smith. Development, Application, and Support of Particulate Sampling Procedures. Third Annual Report (1982). SORI-EAS-83-348. Southern Research Institute.



## APPENDIX

This Appendix provides a summary of the information gathered in the literature survey described in Section 2 of the report. The presentation format we have used was chosen because it facilitates comparison between the various instruments. The first table defines abbreviations used in the remaining tables and the second gives address information for the different manufacturers. Table A-3 presents equipment arranged alphabetically by manufacturer, while Table A-4 is sorted by "instrument type" code (sampling method). All the information given in Table A-3 is also contained in Table A-4 but is sorted differently. The last two tables are also sorted by sampling method and provide additional information on each of the instruments. For clarity, each instrument has been given a unique "Key Number" which appears in the first column of each table. Paragraphs in Section 2 of the report discuss the various sampling and measurement methods used in the tables.

Each instrument has been identified by a code (use code) which indicates how it may be used to characterize an industrial source. These six usage codes are as follows: FG:I for Flue Gas: In-situ operation; FG:E for Flue Gas: Extractive Techniques; AAA for Ambient Airborne Aerosol monitor, used in conjunction with a sample extraction/dilution system (DIL); L:AR for off-line (laboratory only) techniques involving airborne redispersion of the particulate from a bulk sample; L:LS for off-line techniques involving suspension of the particulate in a nonsoluble liquid; and L:Oth for off-line techniques other than those covered by airborne redispersion or suspension in a liquid. An additional code MA, is used to identify "Major Accessory" items used in conjunction with a given sizing method. The use code of most significance to the reader will probably be "FG:I" (Flue Gas: In-situ). The other codes identify instrumentation which can provide some information but are generally inadequate by themselves to characterize a source. The pricing information listed herein is for general information only. The exact price is set by the vendor and depends on the options selected. The pricing information shown was obtained by telephone in April 1985. The information is presented in the following six tables:

Table A-1:	Nomenclature
Table A-2:	Manufacturer's Address List
Table A-3:	Manufacturer's Model Numbers
Table A-4:	Instrument Type Sorted: Description
Table A-5:	Instrument Type Sorted: More Description
Table A-6:	Instrument Type Sorted: Specifications

## Comments

-----  
Use Codes (Measurement Environment for the Instrument):

FG:I Flue Gas: Insitu operation  
 FG:E Flue Gas: Extractive Techniques used  
 AAA Ambient Airborn Aerosol monitor (useful with Dilution)  
 L:AR Laboratory only: Airborn Redispersion from Bulk Powder  
 L:LS Laboratory Only: Liquid Suspension of the particulate  
 L:Oth Laboratory Only: Other technique, Image Analysis,etc.  
 MA Major Accesory to a Primary Sizing Inst.(Data An.,etc)

## Inst. Type: Codes Used:

AT Aerodynamic Transport (Laser Doppler Velocity technique  
 for sizing)  
 AV Alternate Vender; see primary vender for data specifics.  
 CET Centrifugal Separation (Bahco and Spiral Centrifuge)  
 CNC Condensation Nucli Counter (No sizing, conc. only )  
 CSED Centrifugal Sedimentation  
 CYC Cyclone sizing systems (centrifugal separation)  
 DB Diffusion Battery, screen, tube,plate,etc. (needs a  
 second inst. to measure concentration )  
 EM Eletrical Mobility ( segrates by size but needs a  
 second inst. to measure concentration-CNC,  
 electrometer, etc.)  
 GSED Gravitational Sedimentation  
 I:A Impactor accesories ( Percollectors, etc. )  
 I:CI Inertial Separation - Cascade Impactor (normal and low  
 pressure)  
 IAN Image Analysis System (from photo micrograph or Video of  
 SEM or TEM w/wo EDX for elemental chemistry by size  
 MA Major accesory to the sizing instrument, data reduction-  
 pulse heighth analysis, etc.  
 MT17 Method 17 Mass Train ( no oven, in-situ ), for use in  
 running Impactors or Cyclones  
 Misc Miscellaneous sizing techniques not included by the other  
 Misc codes  
 O:A (OPC) Optical Particle Counter, for Aerosols (airborn),  
 time averaged light scattering, scattered intensity  
 O:FD Optical: Fraunhofer Diffraction pattern analysis, light  
 scattering, spatial distribution  
 O:L (OPC) Optical Particle Counter, for liquid suspensions,  
 time averaged light scattering, scattered intensity  
 O:LB Optical: Light blockage  
 O:PC Optical: Photon Correlation Spectroscopy (time dependent  
 light scattering based on Brownian Motion)  
 PHA Pulse Heighth Analysis Inst. MCA's,DAS (Data Aquisition  
 Systems-printed,magnetic tape, BCD for Micros,etc.)  
 RP Resistivity Pulse (Electrical sensing zone, Coulter

## Comments

-----  
Principle

SIV Screen Sieving (manual and automated)

ZZZ Manufacturer's Name, code used to sort Mfg. to bottom.

## Other Abbreviations Used In Text:

ch channel

CRM Clean Room Monitoring Inst, off the shelf

CRT Cathode Ray Tube, ie. Computer Monitor or for  
Oscilloscope

DNA Data NOT available from product literature.

DR Data Reduction / Data Analysis

EDS Energy Dispersive Spectromerty

Fr Fraction, the number of size fractions the instrument  
gives data on (includes the filter).

Imp Impactor

LAS Laser Aerosol Spectrometer

LPC Laser Particle Counter

## MANUFACTURER'S ADDRESS LIST

COMPANY NAME (DIV OF)			
PARENT COMPANY			
P.O. BOX			
STREET ADDRESS			
CITY (ZIP)			
		Brookhaven Instruments Corp.	
		Equipark Industrial Complex	
		200 Thirteenth Ave.	
		Ronkonkoma, NY	11779
		California Measurements, Inc.	
		150 E. Montecito Ave.	
		Sierra Madre, CA	91024
Accurex Div of		Canberra Industries, Inc.	
Andersen Group		One State Street	
4215 Wendell Drive		Meriden, CT	06450
Atlanta, GA	30336		
Air Pollution Technology Inc.		Climet Instruments Co.	
5191 Santa Fe St.		Div. of Wehr Corp.	
San Diego, CA	92109	P.O. Box 151	
		1320 W. Colton Ave.	
Andersen Samplers Div. of		Redlands, CA	92373
Andersen Group			
4215 Wendell Drive		Coulter Electronics, Inc.	
Atlanta, GA	30336	P.O. Box 2145	
		590 West Twentieth St.	
Artek Systems Corp.		Hialeah, FL	33012-0145
Farmingdale, NY			
ATM Corporation		Coulter Electronics Inc.	
Sonic Sifter Division		2140 New Market Parkway, Suite 120	
645 S. 94th Place		Marietta, GA	33067
West Allis, WI	53214		
Bausch & Lomb		ETC (Energy Technology Consultants)	
Analytical Products Div, Dpt. 8224		4758 Old William Penn Highway	
820 Linden Ave		Murrysville, PA	15668
Rochester, NY	14625		
Belfort Instrument Co.		Environment One Corp.	
Subsidiary of TransTechnology Corp.		2773 Balltown Rd.	
727 South Wolfe Street		Schenectady, NY	12309
Baltimore, MD	21231		
Berkeley Controls Inc.		Faley International Corp.	
Div. of Telonic Berkeley Inc.		P.O. Box 669	
P.O. Box 277		EL Toro, CA	92630
2825 Laguna Canyon Rd.		Fisher Foundry, George, Inc.	
Laguna Beach, CA	92652	407 Hodley St.	
		Holly, Michigan	48442

## MANUFACTURER'S ADDRESS LIST

Flow Sensor Div. of Anderson Group 4215 Wendell Drive Atlanta, GA	30336	Leeds & Northrup Co. Unit of General Signal Microtrac Div. 3000 Old Roosevelt Blvd. St. Petersburg, FL	33702
General Electric Ordnance Systems #1 River Rd., Bldg. 85-16B Schenectady, NY	12345	LeMont Scientific, Inc. 2011 Pine Hall Drive, Science Park State College, PA	16801
Gilson Company, Inc P.O. Box 677 Worthington, OH	43085	Malvern Instruments Inc. 187 Oaks Road Framingham, MA	01701
Hiac/Royco Instruments Div. 141 Jefferson Dr. Menlo Park, CA	94025	Marco Scientific, Inc. 1055 Sunnyvale-Saratoga Rd. #8 Sunnyvale, CA	94087
Horiba Instruments, Inc. 1021 Duryea Ave. Irvine, CA		Micromeritics Instrument Corp. 5680 Goshen Springs Road Norcross, GA	30093
In Tox 1712 Virginia N.E. Albuquerque, NM	87110	Nikon	
J.B. Systems P.O. Box 2405 La Grange, GA	30241	Munhall Co., The 5655 N. High St. Worthington, OH	43085
Joyce-Loebl Div. of Vickers Instruments Inc. Riverview Business Park No. 27 P.O. Box 99 300 Commercial St. Malden, MA	02148	Nuclear Data Inc. Golf and Meacham Roads Schaumburg, IL	60196
Kanomax International Corp. 2-1, Shimizu, Suita Osaka, Japan		Nutech Corp. 2806 Cheek Road Durham, NC	27704
Leeds & Northrup Co. Unit of General Signal Research Division Dickerson Road North Wales, PA	19454	Optomax Inc. 9 Ash St., Rt. 130 Hollis, NH	03049

## MANUFACTURER'S ADDRESS LIST

---

Particle Data, Inc. Box 265 (111 Hahn) Elmhurst, IL	60126	Varian Inc. Vaarian Palo Alto Vacuum Div. Palo Alto, CA	94303
Particle Measuring Systems Inc. 1855 South 57th Court Boulder, CO	80301	Wyatt Technology P.O. Box 3003 Santa Barbara, CA	93130
Pollution Control Systems Corp. 4530 Union Bay Place N.E. Seattle, Washington	98105	Zeiss One Zeiss Drive Thornwood, NY	10594
Polytec Optronics, Inc. 22651 Lambert St. Unit 108 El Toro, CA	92630	Zoltek Corporation 3101 McKelvey Rd. St Louis, MO	63044
Research Appliance Co. Div. of Andersen Group 4215 Wendell Drive Atlanta, GA	30336		
Sierra Instruments Div. of Andersen Group 4215 Wendell Drive Atlanta, GA	30336		
SDL (Spectron Development Laboratories) 3303 Harbor Blvd., Suite G-3 Costa Mesa, CA	92626		
Spectrex Corp. 3594 Haven Ave. Redwood City, CA	94063		
Sandia National Laboratories Livermore, CA	94550		
TSI Incorporated P.O. BOX 43394 St Paul, MN	55164		
Unitron, Inc. 175 Express St. Plainview, NY	11803		



Table A-3: Manufacturer's Model Numbers

PAGE: 1 of 4

KEY No.	Vender/Model No.	Other Numbers:	DESCRIPTION/Comments	Key Parameters	Inst. Type Code	Use Code	Quote x 1000
0001	Information on		CODES, column headings, etc is found in	HELP-VENDERS.DAT	ZZZ	ZZZ	
0100	* Accurex:				ZZZ	ZZZ	
0110	SASS				ZZZ	ZZZ	
0200	* Air Pollution Tech.		Cyclone Set, Extractive, High Flowrate	4 Fr(F,1->10 ),complete train;acc. Ogm.	CYC	FG:E	26.5
0210	APT HTP Impactor				ZZZ	ZZZ	
0300	* Andersen Samplers		Special Purpose Impactor,High Temp&Pres	7 Fr(F,.18->25 ),1000F, 10Atm	I:CI	FG:I	7.0
0310	Mark III Impactor	#50-800	Multi Jet Cascade Impactor,Iso. Stk Smp	9 Fr(F,0.4-> 10)	ZZZ	ZZZ	
0320	HCSS Impactor	#70-900	High Grain Loading Imp.,Inlet, gm/stage	4 Fr(F,1.5-> 11), several grams per stg	I:CI	FG:I	4.2
0330	Right Angle Pre.Co	#50-160	AV, see Flow Sensor #55-690	Alternate Vender (AV), see Flow S.55-690	I:CI	FG:I	5.9
0340	Preparator,St.	#50-150	Inline Impactor Precollector	1 Fr( 12.2 at 0.5 SCFM), several grams	I:A	AV	1.6
0350	Low Pressure Imp	#20-900	Amb. Low Pressure Impactor	14 Fr(F,.08-> 35) 5 LP stages, AMBIENT	I:CI	AAA	5.3
0360	Emission Param. An	#T 1050	Mass Train, for running Impactors,etc.	Std. Method 5/17 Train, 3/4 SCFM	MT17	MA	7.1
0370	Universal Stack Sp	#GII-200	Mass Train, for running Impactors,etc.	Std. Method 5/17 Train, 3/4 SCFM	MT17	MA	7.7
0400	* Artek Systems Corp.				ZZZ	ZZZ	
0410	Image Analysis		Image Analysis	Image Analysis	IAN	L:Oth	IAN
0500	* ATM				ZZZ	ZZZ	
0510	L3P Sonic Sifter		Automated screen sieving,5 screens	5 Fr( 5 ->850), any mesh, dry	SIV	L:Oth	4.0
0600	* Bausch & Lomb:				ZZZ	ZZZ	
0610	Omnicon 3500		Image Analysis	Image Analysis	IAN	L:Oth	74.5
0620	EM-2		SEM/FDS Interface, Elem. Chem. by size	Morphology Classes (el. chem vs size)	MA	MA	25.0
0700	* Berkely Controls Inc				ZZZ	ZZZ	
0710	C-2000 QCM Cascade		Amb. Impactor, Quartz Crystal Microbal.	11 Fr( .05-> 35), QCM, AMBIENT	I:CI	AAA	10.5
0800	* Brookhaven Instr.:				ZZZ	ZZZ	
0810	BI-90		OPC (P Cor.), liquidborn	FitFr(.005->5)	O:PC	L:LS	22.5
0900	* Calif. Measurements				ZZZ	ZZZ	
0910	PC-202 QCM		Amb. Impactor, Quartz Crystal Microbal.	10 Fr( .05-> 25), QCM, AMBIENT	I:CI	AAA	15.2
0920	MPS-3		Amb. Impactor,deposits ash on SEM stud	3 Fr( .05-> .3), for SEM, AMBIENT	I:CI	AAA	
1000	* Canberra				ZZZ	ZZZ	
1010	MCA Series 35+	3502	MCA 4K channels, w/options 3541 & 3575	Full Spectrum MCA	PHA	MA	7.6
1100	* Climent:				ZZZ	ZZZ	
1110	Model 226		OPC remote sensor, Airborn, Req. 8040	16 Fr( .3-> 20)	ZZZ	ZZZ	
1120	Model 8040		OPC acc., MCA 24Ch, Data R. & print		O:A	AAA	4.9
1130	Model 8060		Optical Part. Ct.,Airborn,CleanRoomMont	6 Fr( .3-> 10)	PHA	MA	7.9
1200	* Coulter:				O:A	AAA	7.5
1210	TA II L/3 Plus		Volume Displacement of Electrolyte	16 Fr(0.3->800),selectable	ZZZ	ZZZ	
1220	Coulter AccuComp		Data Analysis for TA/II L/3 Coul. ctr.	Includes Apple comp. & DR software	RP	L:LS	28.1
1230	N4-128/MD		OPC (P Cor.), liquidborn	65 Fr(.003->3)	MA	MA	
1300	* Energy Technology				O:PC	L:LS	
1310	CCSEM (Test Lab)		test lab: chem. by size & Morph.; SEM	Monolayer by dilute liquid suspension	ZZZ	ZZZ	.250
1400	* Environment One :				IAN	L:Oth	
1410	Rich 200 CNC		Pulsed Flow Condensation Nuclei Counter	0 Fr(.002 -> 1) Pulsed Flow,Conc. only	CNC	AAA	7.8
1420	Diffusion Denuder		Diffusion Battery, Tubular	1 Fr(.005 -> .1) Threshold type	DB	AAA	2.5
1500	* Faley Internat.:				ZZZ	ZZZ	
1510	Status 2100		Optical Part. Ct.,Airborn,CleanRoomMont	2 Fr( .5-> 5)	ZZZ	ZZZ	
1520	Status 4000		Optical Part. Ct.,Airborn,CRM, 1 ACFM	5 Fr( .3-> 5)	O:A	AAA	4.0
1530	Status 5000		Optical Part. Ct.,Airborn,CleanRoomMont	5 Fr( .3-> 5)	O:A	AAA	10.0
1540	FP-303 Opt.		Printer plotter acc. for Faley OPC's	Print & plot only, MCA in sensor pkg.	O:A	AAA	7.5
					MA	MA	1.5

Table A-3: Manufacturer's Model Numbers

PAGE: 2 of 4

KEY No.	Vender/Model No.	Other Numbers:	DESCRIPTION/Comments	Key Parameters	Inst. Type Code	Use Code	\$ Quote x 1000
1550	KD-01 Diluter		10:1 Diluter for use with any OPC		MA	MA	.8
1600	* Fisher Foundry Inc.				ZZZ	ZZZ	
1610	BAHCO Classifier	No. 6000	ASME PTC-28 procedure for Terminal Vel.	8 Fr(2.2' -> 54)	CET	L:AR	9.1
1700	* Flow Sensor Div.				ZZZ	ZZZ	
1710	Mark 3	#55-500	Multi Jet Cascade Impactor, Iso. Stk Smp	9 Fr(F,.5 -> 10)	I:CI	FG:I	5.3
1720	Mark 4	#55-530	Multi Jet Cascade Impactor, Iso. Stk Smp	8 Fr(F,.5 -> 7)	I:CI	FG:I	5.8
1730	Right Angle Pre-Co	#55-690	Right Angle Impactor Precollector	1 Fr( 11 at 0.5 SCFM), several grams	I:A	FG:I	1.6
1740	6-Stage Cyclone	#65-600	Cyclone Set w/ SORI 1,2,3,4,5,F	Alternate Vender (AV), see Sierra 285-K	CYC	FG:I	7.6
1750	4-Stage Cyclone	#65-610	Cyclone Set w/ SORI 1, 3, 5,F	Alternate Vender (AV), see Sierra 283-2K	CYC	FG:I	4.7
1760	3-Stage Cyclone	#65-620	Cyclone Set w/ SORI 1, 5,F	3 Fr(F,.3 ->10 ),10gm/stg. SORI design	CYC	FG:I	1.1
1800	* General Electric Ord				ZZZ	ZZZ	
1810	CNC-2		Pulsed Flow Condensation Nuclei Counter	0 Fr(.001 -> .1) Pulsed Flow, Conc. only	CNC	AAA	10.3
1900	* Gilson:				ZZZ	ZZZ	
1910	Gilson Sieve Shaker	SS-8R	Priced w/Mesh 60,100,200,& 325 + SV8 P	Holds 8 sieves at a time	SIV	L:Oth	1.3
1920	Comp-sieve Anal.Sy	CP-2	Electronic Bal. System for Autom. Sieve	Inc. Computer, DR software, & print/plot	MA	MA	7.8
1930	ATM sonic Sifter	AT-3	(see ATM) alt. Vender	Alternate Vender (AV), see ATM	SIV	L:Oth	4.0
1940	Laser Particle Cou	SA-1000	OPC (F Dif.), liquidborn	1 Fr( 1->100), Threshold Control	O:L	L:LS	10.2
1950	Particle Profile	SAA-3	Data analysis Acc. for SA-1000	16 ch MCA, DR software & hardware	PHA	MA	7.9
1960	Fritsch Pipette CF	SA-50	Manual Centrifugal Sedimentation Sizing	10 Fr(.05 -> 5) Manual, Liquid suspen.	CSED	L:LS	7.0
1970	Cyclosizer Analyzer	SA-150	Liquid Suspension, Cyclone Set	Amb., Liquid susp. 5 Fr(11->44)	CYC	L:LS	22.8
1975	Bahco Classifier	SA-160	(see Fisher Foundry, Bahco) alt. Vendr	Alternate Vender (AV), see Fisher Found.	CET	AV	10.4
1980	Infrasizer, Gilson	SA-180	Air Elutriation dev., powder separation	7 Fr(F,10->100), 100 gm/hr rate	Misc	L:AR	6.4
1985	Photo Micron Sizer	#SA-2000S	Automated Spirometer, Centrifugal Sedim	many Fr(.01->500) Liquid Suspension	CSED	L:LS	20.9
1990	Andreassen S. Pipet	#SA-40	Glassware for Manual Sedimentation Ext.	Manual technique (1-> 100), Stokes Law	GSED	L:LS	.1
2000	* HIAC/Royco:				ZZZ	ZZZ	
2010	Model 4100	Main Frame	OPC acc., MCA 6Ch, Data R. & print	full data analysis, .3um->600um setable	PHA	MA	6.6
2020	Model 4101 System	w/sensor 1100	OPC (scatter), airborn; CRM, 4100 w/sen.	1100 Sensor, 6 Fr(.5->20) 1cfm	O:A	AAA	7.7
2030	Model 4102 System	w/sensor 1200	OPC (scatter), airborn; CRM, 4100 w/sen.	1200 Sensor, 6 Fr(.5->20), 1cfm or .01cfm	O:A	AAA	8.7
2040	Model 4130 System	w/sensor 1000A	OPC (scatter), airborn; CRM, 4100 w/sen.	1000 Sensor, 6 Fr(.3->15) 1cfm	O:A	AAA	14.0
2050	Model 5100	(stand alone)	Optical Part. Ct., Airborn, CRM stand al.	stand alone, .25-10um, 1cfm,	O:A	AAA	9.8
2051	(cont)	cont.			O:A	AAA	cont.
2060	Model 4103 System	w/sensor 3000	OPC (scatter), liquidborn; 4100 w/sen.	3000 Sensor, 6Fr( 1->300), batch	O:L	L:LS	17.0
2070	Model 4113 System	w/sensor 346	OPC (scatter), liquidborn; 4100 w/sen.	346B Sensor, 6Fr(0.4->25), batch	O:L	L:LS	8.5
2080	HIAC 4300	Main Frame	OPC acc., MCA 32Ch, Data R. & print	full data analysis, 1-9000um setable	PHA	MA	22.9
2085	HIAC 4313 System	w/sensor 346	OPC (scatter), liquidborn; 4300 w/sen.	346B Sensor, 32Fr(0.4->25)	O:LB	L:LS	27.9
2090	NICOMP Model 270		OPC (P Cor.), liquidborn	64 Fr(.005->3), CRT	O:PC	L:LS	22.0
2100	* Horiba:				ZZZ	ZZZ	
2110	CAPA-500 Spirom.		Automated Spirometer, Centrifugal Sedim	many Fr(.02->100) Liquid Suspension	CSED	L:LS	4.8
2200	* In Tox:				ZZZ	ZZZ	
2210	5-Series Cyclone		Cyclone Set w/ SORI 1,2,3,4,5,F	Alternate Vender (AV), see Sierra 285-K	CYC	FG:I	32.4
2221	DB 02-1900		Screen Diffusion Battery	10 Fr(.003 -> .3)	DB	AAA	4.0
2300	* Joyce/Loebl(England				ZZZ	ZZZ	
2310	Disk Centrifuge 4	#7AA5300	Automated Spirometer, Centrifugal Sedim	many Fr(.01-> 60) Liquid Suspension	CSED	L:LS	2.6
2320	DCF Data An. Pkg.	F910001	Software & Interface Hardware for Apple	Major Acc for Disk Centrifuge	MA	MA	
2330	Apple Ite Comp.	F665463	Computer, hardware only, w/ printer	Major Acc for Disk Centrifuge	MA	MA	

Table A-3: Manufacturer's Model Numbers

PAGE: 3 of 4

KEY No.	Vender/Model No.	Other Numbers:	DESCRIPTION/Comments	Key Parameters	Inst. Type Code	Use Code	\$ Quote x 1000
2400 *	Leeds & Northrup:				ZZZ	ZZZ	
2410	Microtrac 7995-10		OPC (F Dif.), liquidborn	13 Fr(0.7->125)	O:FD	L:LS	33.3
2420	7995-30Small Part.		OPC (F Dif. & side scattering), liquidb.	16 Fr(.12-> 42)	O:FD	L:LS	33.9
2500 *	Leeds & North. Res				ZZZ	ZZZ	
2510	Stack Part. Monit.		Optical Particle Counter, Airborn ,Stk.	5 Fr(1.2-> 20),Outlets	O:FD	FG:I	QUOTE
2600 *	Lemont:				ZZZ	ZZZ	
2610	DA-10		Image Analysis	Image Analysis / EDS	IAN	L:Oth	57.0
2700 *	Malvern:				ZZZ	ZZZ	
2710	2600D Spray D Any		OPC (F Dif.), airborn w/acc. for liquid	16 Fr(0.5->1800)	O:FD	AAA	28.0
2720	Autosizer II		OPC (P Cor.), liquidborn	32 Fr(.01-> 3)	O:PC	L:LS	22.5
2730	Model 3600E		OPC (F Dif.), liquidborn	Cross Reference (CR) to 2600D for spec.	O:FD	L:LS	29.5
2800 *	Marco Scientific:				ZZZ	ZZZ	
2810	Granulometer		OPC (F Dif.), liquidborn	16 Fr(1.0->192)	O:FD	L:LS	33.0
2900 *	Belfort				ZZZ	ZZZ	
2910	Belfort 1502	MRI Model 1502	Multi Jet Cascade Impactor,Iso. Stk Smp	8 Fr(F,.5 -> 9)	I:CI	FG:I	2.1
3000 *	Micromeritics:				ZZZ	ZZZ	
3010	Sedigraph 5000ET		Automated Sedimentation Sizing,X-ray	21 Fr( .1 ->100) Liquid Suspension	GSED	L:LS	23.8
3100 *	Munhall Co. ,The:				ZZZ	ZZZ	
3120	Image Any. System		Image Analysis	Image Analysis	IAN	L:Oth	IAN
3200 *	Nicon				ZZZ	ZZZ	
3210	Magiscan 2		Image Analysis	Image Analysis	IAN	L:Oth	IAN
3300 *	Nuclear Data Inc.				ZZZ	ZZZ	
3310	ND 62 MCA		MCA 4K channels, w/CMOS	Full Spectrum MCA	PHA	MA	5.9
3400 *	Nutech Corp.				ZZZ	ZZZ	
3410	Nutech 2010		Mass Train, for running Impactors,etc.	Std. Method 5/17 Train, 3/4 SCFM	MT17	MA	6.3
3420	Nutech 220-2	220-2	Mass Train, for running Impactors,etc.	Mth. 6 Control Box, for Low Flow Imp.	MT17	MA	1.7
3500 *	Optomax:				ZZZ	ZZZ	
3510	Image Any. System		Image Analysis	Image Analysis	IAN	L:Oth	IAN
3600 *	Particle Data Inc.:				ZZZ	ZZZ	
3610	180LSD/ADC-80XY/KP		Volume Displacement of Electrolyte	128Fr(0.3->1900)selectable	ZZZ	ZZZ	
3700 *	Particle Measuring				ZZZ	ZZZ	
3710	FPSSS	FPSSS-100	Optical Particle Counter, Airborn ,Stk.	60 Fr( .4->11 )	O:A	FG:I	46.0
3720	LPC-101		Optical Part. Ct.,Airborn,CRM	4 Fr( .1->10 )	O:A	AAA	13.5
3730	LAS-250X-CRT		Optical Part. Ct.,Airborn,CRM	16 Fr( .2->12 )	O:A	AAA	15.3
3800 *	Pollution Control				ZZZ	ZZZ	
3810	Mark 3		Multi Jet Cascade Impactor,Iso. Stk Smp	8 Fr(F,.3 -> 10)	I:CI	FG:I	3.0
3820	Mark 5		Multi Jet Cascade Impactor,Iso. Stk Smp	12 Fr(F,.2 -> 20)	I:CI	FG:I	3.9
3830	Mark 10		Sys w/regular pressure & low press. Imp	28 Fr(F,.05-> 20), stk sampler,6 Low P S	I:CI	FG:I	21.1
3840	Mark 20B		Sys w/regular pressure & low press. Imp	15 Fr(F,.05-> 20), stk sampler,6 Low P S	I:CI	FG:I	21.1
3850	MARK 8		High Grain loading Imp.,Inlets, gm/stag	DNA Fr(F, -> )	I:CI	FG:I	QUOTE
3860	Right Angle Pre.Co		Right Angle Impactor Precollector	1 Fr( DNA at 0. SCFM), several grams	I:A	FG:I	1.3
3870	BCURRA Cyc.		Used as a Right Angle Impactor Precoll.	1 Fr(5um at 0.5 ACFM, 212F),several gm	I:A	FG:I	1.5
3900 *	Polytec Optonics				ZZZ	ZZZ	
3910	HN-15 Karlsruhe		Optical Part. Ct.,Airborn, research	64 Fr(0.5-> 20)	O:A	AAA	
4000 *	Research Applance		Mass Train, for running Impactors,etc.	Std. Method 5/17 Train, 3/4 SCFM	ZZZ	ZZZ	
4010	RAC Stacksampl	#201108			MT17	MA	7.8

Table A-3: Manufacturer's Model Numbers

PAGE: 4 of 4

KEY No.	Vender/Model No.	Other Numbers:	DESCRIPTION/Comments	Key Parameters	Inst. Type Code	Use Code	\$ Quote x 1000
4100 *	Sierra Inst. DAG		Multi Jet Cascade Impactor,Iso. Stk Smp	7 Fr(F, .9-> 14)	ZZZ	ZZZ	2.9
4110	Model 226		Multi Jet Cascade Impactor,Iso. Stk Smp	9 Fr(F, .3-> 18)	I:CI	FG:I	3.8
4120	Model 228		Sys w/regular pressure & low press. Imp	11 Fr(F,.09-> 28), stk sampler, 2Low PS	I:CI	FG:I	4.7
4130	Model 2210		Cyclone Set w/ SORI 1,2,3,4,5,F	6 Fr(F, .3 -> 10),10gm/stg. SoRI design	CYC	FG:I	7.1
4140	Cyclade 285-X		Cyclone Set w/ SORI 10, 1,2,3,4,5,F	7 Fr(F, .7 -> 15),10gm/stg. SoRI design	CYC	FG:I	8.6
4150	Cyclade 286-1K		Cyclone Set w/ SORI 9,1,2,3,4,5,F	4 Fr(F, .3 -> 10),10gm/stg. SoRI design	CYC	FG:I	8.8
4160	Cyclade 286-2K		Cyclone Set w/ SORI 1 3, 5,F	1 Fr( 9.2 at 0.25SCFM), several grams	I:A	FG:I	0.8
4170	Cyclade 283-2K		Cyclone design Impactor precollector		ZZZ	ZZZ	
4180	Model 220 CP		Sample Extraction Dilution System	Stk Sampling, Amb.-700F,15:1-2000:1	DIL	MA	QUOTE
4200 *	Southern Res. Inst.	UPPS Diluter	OPC (F Dif.), liquidborn	16 Fr(0.5->100)	O:FD	L:LS	
4210	SEDS		PHA for ILI 1000 ,w/apple Iie	PHA & DR , 17 ch MCA	PHA	MA	
4250 *	Spectrex:		OPC (Dual ), spray droplet type	DNA Fr(.5-> 25),cross stk.w/focused view	O:FD	FG:I	QUOTE
4260	ILI 1000	#6700000	Elec. Aerosol Size Analy. w/o DR system	(Cross Ref.to EAA 3930 Sy for specs.)	EM	AAA	20.8
4270	PPA-4	#6700810	EAA 3030 w/ Apple soft. & computer	10 Fr(.003 ->1.0)	EM	AAA	29.7
4300 *	Spectron Dev. Lab.:		DB, switching valves,& CNC w/o Apple	10 Fr(.005 -> .2)	DB	AAA	26.1
4310	Particle Sizing Interferometer		EMC(Electro.MobilityClass),CNC,& Apple	32 Fr(.01 ->1.0)	EM	AAA	42.0
4400 *	TSI:		Aerodynamic Particle Sizer w/o computer	48 Fr(.5 -> 15)	AT	AAA	29.5
4405	EAA 3030	#3030	Data Reduction Hardware/Soft. for APS	computer & software	MA	MA	8.9
4410	EAA	3930 Sy	Continuous Flow Conden. Nuclei Counter	0 Fr(.01 -> 1) Cont. Flow,Conc. only	CNC	AAA	17.0
4420	DB/CNC	#3931	Screen Diffusion Battery, opt. Switch V	10 Fr(.005 -> .2)	DB	AAA	4.9
4430	DMPS/C	#3932	Lab Diluter, accessory to the APS 33	100:1 or 20:1, 5 lpm total output	DIL	MA	3.7
4440	APS 33	Sy #3300I	Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4445	IBM-XT(DR for APS)	#3900XT	Image Analysis	Image Analysis	IAN	L:Oth	IAN
4450	CNC	3020	Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4460	DB	3040	Image Analysis	Image Analysis	IAN	L:Oth	IAN
4470	Diluter 3302		OPC (F Dif.), liquidborn	16 Fr(0.6-> 50)	O:FD	L:LS	17.0
4500 *	Unitron		Data Analysis, etc for DAWN	computer & software	PHA	MA	2.5
4510	Model 1A1000		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4600 *	Varian:		Image Analysis	Image Analysis	IAN	L:Oth	IAN
4610	Image Any. System		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4700 *	Wyatt Technology		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4710	Dawn Model B		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4720	Columbia MPC	#1600-IV	Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4800 *	Zeiss:		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4810	IBAS		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4900 *	Zoltec:		Image Analysis	Image Analysis	ZZZ	ZZZ	IAN
4910	Brink Model C		Impactor,Low Flow (Inlet, High Loading)	8 Fr(F,.5 -> 9 )	I:CI	FG:I	2.9

Table A-4: Instrument Type Sorted: Description

PAGE: 1 of 3

KEY No.	Inst. Type Code	Use Code	Manufacturer	Vender/Model No.	Other Numbers:	\$ Quote x 1000	DESCRIPTION/Comments	Key Parameters
4440 AT	AAA	AAA	TSI:	APS33	SY		29.5 Aerodynamic Particle Sizer w/o computer	48 Fr(.5 -> 15)
1975 CET	AV	AV	Gilson	Bahco Classifier	#33001		10.4 (see Fisher Foundry, Bahco) alt. Vender	Alternate Vender (AV), see Fisher Found.
1610 CET	L:AR	L:AR	Fisher Foundry Inc.	BAHCO Classifier	SA-160		9.1 ASME PTC-28 procedure for Terminal Vel.	8 Fr(2.2 -> 54)
1410 CNC	AAA	AAA	Environment One	Rich 200 CNC	No.6000		7.8 Pulsed Flow Condensation Nuclei Counter	0 Fr(.002-> 1) Pulsed Flow, Conc. only
1810 CNC	AAA	AAA	General Electric Ord	CNC-2			10.3 Pulsed Flow Condensation Nuclei Counter	0 Fr(.001-> .1) Pulsed Flow, Conc. only
4450 CNC	AAA	AAA	TSI:				17.0 Continuous Flow Condens. Nuclei Counter	0 Fr(.01 -> 1) Cont. Flow, Conc. only
1960 CSED	L:LS	L:LS	Gilson	CNC	3020	#3020	7.0 Manual Centrifugal Sedimentation Sizing	10 Fr(.05 -> 5) Manual, Liquid susp.
1985 CSED	L:LS	L:LS	Gilson	Fritsch Pipette CF	SA-50		20.9 Automated Spirometer, Centrifugal Sedim	many Fr(.01->500)Liquid Suspension
2110 CSED	L:LS	L:LS	Gilson	Photo Micron Sizer	#SA-2000S		22.0 Automated Spirometer, Centrifugal Sedim	many Fr(.02->100)Liquid Suspension
2310 CSED	L:LS	L:LS	Horiba:	CAPA-500 Spirom.			32.4 Automated Spirometer, Centrifugal Sedim	many Fr(.01->60)Liquid Suspension
0110 CYC	FG:E	FG:E	Joyce/Loebl(England)	Disk Centrifuge 4	#7AA5300		26.5 Cyclone Set, Extractive, High Flowrate	4 Fr(F,1->10),complete train;acc. Ogm.
1740 CYC	FG:I	FG:I	Accurex:	SASS			7.6 Cyclone Set w/ SORI	Alternate Vender (AV), see Sierra 285-K
1750 CYC	FG:I	FG:I	Flow Sensor Div.	6-Stage Cyclone	#65-600		4.7 Cyclone Set w/ SORI	Alternate Vender (AV), see Sierra 285-K
1760 CYC	FG:I	FG:I	Flow Sensor Div.	4-Stage Cyclone	#65-610		1.1 Cyclone Set w/ SORI	Alternate Vender (AV), see Sierra 285-K
2210 CYC	FG:I	FG:I	In Tox:	3-Stage Cyclone	#65-620		4.8 Cyclone Set w/ SORI	Alternate Vender (AV), see Sierra 285-K
4140 CYC	FG:I	FG:I	In Tox:	5-Series Cyclone			7.1 Cyclone Set w/ SORI	Alternate Vender (AV), see Sierra 285-K
4150 CYC	FG:I	FG:I	Sierra Inst. DAG	Cyclade 285-K			8.6 Cyclone Set w/ SORI	6 Fr(F, .3 -> 10), 10gm/stg. SORI design
4160 CYC	FG:I	FG:I	Sierra Inst. DAG	Cyclade 285-1K			9.1 Cyclone Set w/ SORI	7 Fr(F, .7 -> 15), 10gm/stg. SORI design
4170 CYC	FG:I	FG:I	Sierra Inst. DAG	Cyclade 286-2K			8.8 Cyclone Set w/ SORI	7 Fr(F, 1.0 -> 15), 10gm/stg. SORI design
1970 CYC	L:LS	L:LS	Sierra Inst. DAG	Cyclade 283-2K			4.7 Cyclone Set w/ SORI	4 Fr(F, .3 -> 10), 10gm/stg. SORI design
1420 DB	AAA	AAA	Gilson	Cyclosizer Analyzer	SA-150		22.8 Liquid Suspension, Cyclone Set	Amb., Liquid susp. 5 Fr(11->44)
2221 DB	AAA	AAA	Environment One	Diffusion Denuder			2.5 Diffusion Battery, Tubular	1 Fr(.005 -> .1) Threshold type
4420 DB	AAA	AAA	In Tox:	DB 02-1900			DNA Screen Diffusion Battery	10 Fr(.003 -> .3)
4460 DB	AAA	AAA	TSI:	DB/CNC	3931 Sy	#3931	26.1 DB, switching valves, & CNC w/o Apple	10 Fr(.005 -> .2)
4210 DIL	MA	MA	Southern Res. Inst.	SEDS	3040	#3040	4.9 Screen Diffusion Battery, opt. Switch V	10 Fr(.005 -> .2)
4470 DIL	MA	MA	TSI:	Diluter	3302		QUOTE Sample Extraction Dilution System	Stk Sampling, Amb.-700F, 15:1-2000; 1
4405 EM	AAA	AAA	TSI:	EAA	3030	#3030	3.7 Lab Diluter, accessory to the APS 33	100:1 or 20:1, 5 lpm total output
4410 EM	AAA	AAA	TSI:	DMPs/C	3932 Sy	#3932	20.8 Elec. Aerosol Size Analy. w/o DR system	(Cross Ref.to EAA 3930 Sy for specs.)
4430 EM	AAA	AAA	TSI:	Andreasen S. Pipet	#SA-40		29.7 EAA 3030 w/ Apple soft. & computer	10 Fr(.003 -> 1.0)
1990 GSED	L:LS	L:LS	Gilson	Sedigraph 5000ET			42.0 EMC(Electro.MobilityClass),CNC, & Apple	32 Fr(.01 -> 1.0)
0330 I:A	AV	AV	Micromeritics:	Right Angle Pre.Co	#50-160		.1 Glassware for Manual Sedimentation Ext.	Manual technique (1-> 100), Stokes Law
0340 I:A	FG:I	FG:I	Andersen Samplers	Right Angle Pre.Co	#50-150		23.8 Automated Sedimentation Sizing, X-ray	21 Fr(.1 -> 100) Liquid Suspension
1730 I:A	FG:I	FG:I	Andersen Samplers	Preseparator, St.	#55-690		1.6 AV, see Flow Sensor #55-690	Alternate Vender (AV), see Flow S.55-690
3860 I:A	FG:I	FG:I	Flow Sensor Div.	Right Angle Pre.Co			1.1 Inline Impactor Precollector	1 Fr( 12.2 at 0.5 SCFM), several grams
3870 I:A	FG:I	FG:I	Pollution Control	Right Angle Pre.Co			1.6 Right Angle Impactor Precollector	1 Fr( 11 at 0.5 SCFM), several grams
4180 I:A	FG:I	FG:I	Sierra Inst. DAG	BCUPRA Cyc.			1.3 Right Angle Impactor Precollector	1 Fr( DNA at 0. SCFM), several grams
0350 I:CI	AAA	AAA	Andersen Samplers	Model 220 CP			1.5 Used as a Right Angle Impactor Precoll.	1 Fr(5um at 0.5 ACFM, 212F), several gm
0710 I:CI	AAA	AAA	Berkely Controls In	Low Pressure Imp	#20-900		0.8 Cyclone design Impactor precollector	1 Fr( 9.2 at 0.25SCFM), several gm
0910 I:CI	AAA	AAA	Calif. Measurements	PC-202 QCM			5.3 Amb. Low Pressure Impactor	14 Fr(F,.08-> 35) 5 lp stages, AMBIENT
0920 I:CI	AAA	AAA	Calif. Measurements	MPS-3			10.5 Amb. Impactor, Quartz Crystal Microbal.	11 Fr( .05-> 35), QCM, AMBIENT
0210 I:CI	FG:I	FG:I	Air Pollution Tech.	APT HTP Impactor			15.2 Amb. Impactor, Quartz Crystal Microbal.	10 Fr( .05-> 25), QCM, AMBIENT
0310 I:CI	FG:I	FG:I	Andersen Samplers	Mark III Impactor			DNA Amb. Impactor, deposits ash on SEM stud	3 Fr( .05-> .3), for SEM, AMBIENT
0320 I:CI	FG:I	FG:I	Andersen Samplers	HCSS Impactor			7.0 Special Purpose Impactor, High Temp&Pres	7 Fr(F,.18->25 ), 1000F, 10Acm
1710 I:CI	FG:I	FG:I	Flow Sensor Div.	Mark 3			4.2 Multi Jet Cascade Impactor, Iso. Stk Smp	9 Fr(F,0.4-> 10)
1720 I:CI	FG:I	FG:I	Flow Sensor Div.	Mark 4			5.9 High Grain Loading Imp., Inlet, gm/stage	4 Fr(F,1.5-> 11), several grams per stg
							5.3 Multi Jet Cascade Impactor, Iso. Stk Smp	9 Fr(F,.5 -> 10)
							5.8 Multi Jet Cascade Impactor, Iso. Stk Smp	8 Fr(F,.5 -> 7)

Table A-4: Instrument Type Sorted: Description

PAGE: 2 of 3

KEY No.	Inst. Type Code	Use	Manufacturer	Vender/Model No.	Other Numbers: x 1000	DESCRIPTION/Comments	Quote \$	Key Parameters
2910	I:CI	FG:I	Belfort	Belfort 1502	MRI Model 1502	2.1 Multi Jet Cascade Impactor,Iso. Stk Smp	2.1	8 Fr(F,.5 -> 9)
3810	I:CI	FG:I	Pollution Control	Mark 3		3.0 Multi Jet Cascade Impactor,Iso. Stk Smp	3.0	8 Fr(F,.3 -> 10)
3820	I:CI	FG:I	Pollution Control	Mark 5		3.9 Multi Jet Cascade Impactor,Iso. Stk Smp	3.9	12 Fr(F,.2 -> 20)
3830	I:CI	FG:I	Pollution Control	Mark 10		21.1 Sys w/regular pressure & low press. Imp	21.1	28 Fr(F,.05-> 20), stk sampler,6 Low P S
3840	I:CI	FG:I	Pollution Control	Mark 20B		21.1 Sys w/regular pressure & low press. Imp	21.1	15 Fr(F,.05-> 20), stk sampler,6 Low P S
3850	I:CI	FG:I	Pollution Control	MARK 8		QUOTE High Grain loading Imp.,Inlets, gm/stag		DNA Fr(F,.1 -> 10)
4110	I:CI	FG:I	Sierra Inst. DAG	Model 226		2.9 Multi Jet Cascade Impactor,Iso. Stk Smp	2.9	7 Fr(F,.9-> 14)
4120	I:CI	FG:I	Sierra Inst. DAG	Model 228		3.8 Multi Jet Cascade Impactor,Iso. Stk Smp	3.8	9 Fr(F,.3-> 18)
4130	I:CI	FG:I	Sierra Inst. DAG	Model 2210		4.7 Sys w/regular pressure & low press. Imp	4.7	11 Fr(F,.09-> 28), stk sampler,2 Low P S
4910	I:CI	FG:I	Zoltec:	Brink Model C		2.9 Impactor,Low Flow (Inlet, High Loading)	2.9	8 Fr(F,.5 -> 9)
0410	I:CI	FG:I	Artek Systems Corp	Image Analysis		IAN Image Analysis		Image Analysis
0610	I:CI	FG:I	Bausch & Lomb:	Omnicon 3500		74.5 Image Analysis		Image Analysis
1310	I:CI	FG:I	Energy Technology	CCSEM (Test Lab)		57.0 Image Analysis		Image Analysis / EDS
2610	I:CI	FG:I	Lemont:	DR-10		IAN Image Analysis		Image Analysis
3120	I:CI	FG:I	Munhall Co. ,The:	Image Any. System		IAN Image Analysis		Image Analysis
3210	I:CI	FG:I	Nikon	Magiscan 2		IAN Image Analysis		Image Analysis
3510	I:CI	FG:I	Optomax:	Image Any. System		IAN Image Analysis		Image Analysis
4510	I:CI	FG:I	Unitron	Model 1A1000		IAN Image Analysis		Image Analysis
4610	I:CI	FG:I	Varian:	Image Any. System		IAN Image Analysis		Image Analysis
4810	I:CI	FG:I	Zeiss:	IBAS		IAN Image Analysis		Image Analysis
0620	MA	MA	Bausch & Lomb:	EM-2		25.0 SEM/EDS Interface, Elem. Chem. by size		Morphology Classes (el. chem vs size)
1220	MA	MA	Coulter:	Coulter AccuComp		DNA Data Analysis for TA/II L/3 Coul. ctr.		Includes Apple comp. & DR software
1540	MA	MA	Faley Internat.:	FP-303 Opt.		1.5 Printer plotter acc. for Faley OPC's		Print & plot only, MCA in sensor pkg.
1550	MA	MA	Faley Internat.:	KD-01 Diluter		.8 10:1 Diluter for use with any OPC		
1920	MA	MA	Gilson	Comp-sieve Anal.Sy	CP-2	7.8 Electronic Bal. System for Autom. Sieve		Inc. Computer,DR software,& print/plot
2320	MA	MA	Joyce/Loebl(England	DCF Data An. Pkg.	F910001	4.0 Software & Interface Hardware for Apple		Major Acc for Disk Centrifuge
2330	MA	MA	Joyce/Loebl(England	Apple ITe Comp.	F665463	2.6 Computer, hardware only,w/ printer		Major Acc for Disk Centrifuge
4445	MA	MA	TSI:	ISM-XT(DR for APS)	#3900XT	8.9 Data Reduction Hardware/Soft. for APS		computer & software
0360	MTI 7	MA	Andersen Samplers	Emission Param. An	#T 1050	7.1 Mass Train, for running Impactors,etc.		Std. Method 5/17 Train, 3/4 SCFM
0370	MTI 7	MA	Andersen Samplers	Universal Stack Sp	#GII-200	7.7 Mass Train, for running Impactors,etc.		Std. Method 5/17 Train, 3/4 SCFM
3410	MTI 7	MA	Nutech Corp.	Nutech 2010		6.3 Mass Train, for running Impactors,etc.		Std. Method 5/17 Train, 3/4 SCFM
3420	MTI 7	MA	Nutech Corp.	Nutech 220-2		1.7 Mass Train, for running Impactors,etc.		Mth. 6 Control Box, for Low Flow Imp.
4010	MTI 7	MA	Research Applience	RAC StackSampler	#201108	7.8 Mass Train, for running Impactors,etc.		Std. Method 5/17 Train, 3/4 SCFM
1980	Misc	L:AR	Gilson	Infrasizer,Gilson	SA-180	6.4 Air Elutriation dev., powder separation		7 Fr(F,.10->100), 100 gm/hr rate
1110	O:A	AAA	Climent:	Model 226		4.9 OPC remote sensor, Airborn, Req. 8040		16 Fr( .3-> 20)
1130	O:A	AAA	Climent:	Model 8060		7.5 Optical Part. Ct.,Airborn,CleanRoomMont		6 Fr( .3-> 10)
1510	O:A	AAA	Faley Internat.:	Status 2100		4.0 Optical Part. Ct.,Airborn,CleanRoomMont		2 Fr( .5-> 5)
1520	O:A	AAA	Faley Internat.:	Status 4000		10.0 Optical Part. Ct.,Airborn,CRM, 1 ACFM		5 Fr( .3-> 5)
1530	O:A	AAA	Faley Internat.:	Status 5000		7.5 Optical Part. Ct.,Airborn,CleanRoomMont		5 Fr( .3-> 5)
2020	O:A	AAA	HIAC/Royco:	Model 4101 System	w/sensor 1100	7.7 OPC (scatter),airborn,CRM, 4100 w/sen.		1100 Sensor,6 Fr(.5->20) 1cfm
2030	O:A	AAA	HIAC/Royco:	Model 4102 System	w/sensor 1200	8.7 OPC (scatter),airborn,CRM, 4100 w/sen.		1200 Sensor,6 Fr(.5->20).1cfm or .01cfm
2040	O:A	AAA	HIAC/Royco:	Model 4130 System	w/sensor 1000A	14.0 OPC (scatter),airborn,CRM, 4100 w/sen.		1000 Sensor,6 Fr(.3->15) 1cfm
2050	O:A	AAA	HIAC/Royco:	Model 5100	(stand alone)	9.8 Optical Part. Ct.,Airborn,CRM stand al.		stand alone,.25-10um,1cfm,
2051	O:A	AAA	HIAC/Royco:	(cont)		cont.		cont.
3720	O:A	AAA	Particle Measuring	LPC-101		13.5 Optical Part. Ct.,Airborn,CRM		4 Fr( .1->10 )
3730	O:A	AAA	Particle Measuring	LAS-250X-CRT		15.3 Optical Part. Ct.,Airborn,CRM		16 Fr( .2->12 )

Table A-4: Instrument Type Sorted: Description

PAGE: 3 of 3

KEY No.	Inst. Type Code	Use Code	Manufacturer	Vender/Model No.	Other Numbers:	\$ Quota x 1000	DESCRIPTION/Comments	Key Parameters
3910 O:A	AAA		Polytec Optonics	HN-15 Karlsruhe			DNA Optical Part. Ct. Airborn, research	64 Fr(0.5-> 20)
3710 O:A	FG:I		Particle Measuring	FPSSS	FPSSS-100		46.0 Optical Particle Counter, Airborn, Stk.	60 Fr( .4->11 )
2710 O:FD	AAA		Malvern:	2600D Spray D Any			28.0 OPC (F Dif.), airborn w/acc. for liquid	16 Fr(0.5->1800)
2510 O:FD	FG:I		Leeds & North. Res	Stack Part. Monit.			QUOTE Optical Particle Counter, Airborn, Stk.	5 Fr(1.2-> 20), Outlets
4310 O:FD	FG:I		Spectron Dev. Lab.:	Particle Sizing Interferometer			QUOTE OPC (Dual ), spray droplet type	DNA Fr(.5-> 25), cross stk.w/focused view
2410 O:FD	L:LS		Leeds & Northrup:	Microtrac 7995-10			33.3 OPC (F Dif.), liquidborn	13 Fr(0.7->125)
2420 O:FD	L:LS		Leeds & Northrup:	7995-30Small Part.			33.9 OPC (F Dif. & side scattering), liquidb.	16 Fr(.12-> 42)
2730 O:FD	L:LS		Malvern:	Model 3600E			29.5 OPC (F Dif.), liquidborn	Cross Reference (CR) to 2600D for spec.
2810 O:FD	L:LS		Marco Scientific:	Granulometer			33.0 OPC (F Dif.), liquidborn	16 Fr(1.0->192)
4260 O:FD	L:LS		Spectrex:	ILI 1000	#6700000		? OPC (F Dif.), liquidborn	16 Fr(0.5->100)
4710 O:FD	L:LS		Wyatt Technology	Laser Model B			17.0 OPC (F Dif.), liquidborn	16 Fr(0.6-> 50)
1940 O:L	L:LS		Gilson	Dawn Model B			10.2 OPC (F Dif.), liquidborn	1 Fr( 1->100), Threshold Control
2060 O:L	L:LS		HIAC/Royco:	Laser Particle Cou	SA-1000		? OPC (scatter), liquidborn; 4100 w/sen.	3000 Sensor, 6Fr( 1->300), batch
2070 O:L	L:LS		HIAC/Royco:	Model 4103 System	w/sensor 3000		17.0 OPC (scatter), liquidborn; 4100 w/sen.	346B Sensor, 6Fr(0.4->25), batch
2085 O:LB	L:LS		HIAC/Royco:	Model 4113 System	w/sensor 346		22.9 OPC (scatter), liquidborn; 4300 w/sen.	346B Sensor, 32Fr(0.4->25)
0810 O:PC	L:LS		HIAC/Royco:	HIAC 4313 System	w/sensor 346		DNA OPC (P Cor.), liquidborn	FitFr(.005->5)
1230 O:PC	L:LS		Brookhaven Instr.:	BI-90			DNA OPC (P Cor.), liquidborn	65 Fr(.003->3)
2090 O:PC	L:LS		Coulter:	N4-128/MD			27.9 OPC (P Cor.), liquidborn	64 Fr(.005->3), CRT
2720 O:PC	L:LS		HIAC/Royco:	NICOMP Model 270			7.6 MCA 4K channels, w/options 3541 & 3575	32 Fr(.01-> 3)
1010 PHA	MA		Autosizer II		3502		7.9 OPC acc., MCA 24Ch, Data R. & print	Full Spectrum MCA
1120 PHA	MA		Canberra	MCA Series 35+			7.9 Data analysis Acc. for SA-1000	
1950 PHA	MA		Climent:	Model 8040			6.6 OPC acc., MCA 6Ch, Data R. & print	
2010 PHA	MA		Gilson	Particle Profile	SA-3		8.5 OPC acc., MCA 32Ch, Data R. & print	16 ch MCA, DR software & hardware
2080 PHA	MA		HIAC/Royco:	Model 4100	Main Frame		5.9 MCA 4K channels, w/CMOS	full data analysis, 1-9000um setable
3310 PHA	MA		HIAC/Royco:	HIAC 4300	Main Frame		? PHA for ILI 1000, w/Apple IIe	Full Spectrum MCA
4270 PHA	MA		Nuclear Data Inc.	ND 62 MCA			2.5 Data Analysis, etc for DAWN	PHA & DR, 17 ch MCA
4720 PHA	MA		Spectrex:	PPA-4	#6700810		28.1 Volume Displacement of Electrolyte	computer & software
1210 RP	L:LS		Wyatt Technology	Columbia MPC	#1600-IV		20.4 Volume Displacement of Electrolyte	16 Fr(0.3->800),selectable
3610 RP	L:LS		Coulter:	TA II L/3 Plus			4.0 Automated screen sieving, 5 screens	128Fr(0.3->1900)selectable
0510 SIV	L:LS		Particle Data Inc.:	180LSD/ADC-80XY/KP			1.3 Priced w/Mesh 60,100,200,& 325 + SV8 P	5 Fr( 5 ->850), any mesh, dry
1910 SIV	L:Oth		ATM	L3P Sonic Sifter			4.0 (see ATM) alt. Vender	Holds 8 sieves at a time
1930 SIV	L:Oth		Gilson	Gilson Sieve Shaker	SS-8R			Alternate Vender (AV), see ATM
			Gilson	ATM sonic Sifter	AT-3			

Table A-5: Instrument Type Sorted: More Description

PAGE: 1 of 3

KEY No.	Inst. Type	Use Code	Vender/Model No.	Comments ( 1 of 3 )	Comments continued ( 2 of 3 )	Comments continued ( 3 of 3 )
4440 AT	AAA	SY	APS 33	(.5, .54, .58, -> 15 by 1.075 ratio)		
1975 CET	AV		BARCO Classifier	AV		AV
1610 CET	L:AR		BARCO Classifier	(2.2, 3.5, 7, 13, 21, 36, 48, 54) for	1.0 gm/cc. Terminal Settling Velocity	
1410 CNC	AAA		Rich 200 CNC	Sizing must be performed by a separate	instrument (DB,EM,etc.).	
1810 CNC	AAA		CNC-2	Sizing must be performed by a separate	instrument (DB,EM,etc.).	
4450 CNC	AAA		CNC	Sizing must be performed by a separate	instrument (DB,EM,etc.).	
1960 CSED	L:LS		Fritch Pipette CF	Conc. by dry weight, size by run time and radius at Pipette point. Extends Andreasen Pipet method into submicron range.		
1985 CSED	L:LS		Photo Micron Sizer	Import,Seihin, Computer controlled centrifuge,Concentration by photo-extention.	Size is operator selectable.	
2110 CSED	L:LS		CAPA-500 Spirom.	Import,Japan. Computer controlled centrifuge,Concentration by photo-extention.	Size is operator selectable.	
2310 CSED	L:LS		Disk Centrifuge 4	Import,England. Computer controlled centrifuge,Concentration by photo-extention.	Size is operator selectable.	
0110 CYC	FG:E		SASS	3 cyc set + F, 4 SCFM (10.3,1,F) with an organics module (\$ +8.3K) accessory	Source Assessment Sampling System	
1740 CYC	FG:I		6-Stage Cyclone	AV		
1750 CYC	FG:I		4-Stage Cyclone	AV		
1760 CYC	FG:I		3-Stage Cyclone	1.0 ACFM, 300F (F, .57, 7.5)		
2210 CYC	FG:I		5-Series Cyclone	AV		
4140 CYC	FG:I		Cyclade 285-K	1.0 ACFM, 300F (F, .57, 1.1, 2.7, 3.5)	7.5)	
4150 CYC	FG:I		Cyclade 286-1K	0.8 ACFM, 300F (F, .73, 1.3, 2.5, 4.2)	8.5, 15); 15um IP	
4160 CYC	FG:I		Cyclade 286-2K	0.5 ACFM, 300F (F, 1.0, 2.2, 4.5, 6.0)	11, 15); 15um IP	
4170 CYC	FG:I		Cyclade 283-2K	1.0 ACFM, 300F (F, .57, 2.7, 7.5)		
1970 CYC	L:LS		Cyclosizer Analyzr	0.5 SCFM liquid (11, 15, 23, 33, 44)		
1420 DB	AAA		Diffusion Denuder	Adjust flow to change D50.		
2221 DB	AAA		DB 02-1900	Screen DB, Stainless Steel		
4420 DB	AAA		DB/CNC	Includes DB 3040, Switching Valve 3042,, and CNC 3020		
4460 DB	AAA		DB	Used with DB/CNC System 3931, screen DB's		
4210 DIL	MA		SEDS	Prototype system designed for stk. sampling use. Extracts, dilutes and conditions sample for amb.inst. (.01-1.5 micron)		
4470 DIL	MA		Diluter 3302	Lab diluter (Amb.) intended as an accessory for the APS 33 for high concentration	CR	
4405 EM	AAA		EAA 3030	Cross Reference (CR)		
4410 EM	AAA		EAA	0.14 SCFM(.0042, .0075, .0133, .024,.042	.075, .013, .24, .42, .75)	
4430 EM	AAA		DMPS/C	Includes Electrostatic Classifier 3071,	CNC 3020 for low concentrations and computer hardware/data analysis pkg 3900-71.	
1990 GSED	L:LS		Andreasen S. Pipet	Extract dilute liquid suspension at different time intervals, dry and weigh.	Qty of extract. sets qty of size cuts.	
3010 GSED	L:LS		Sedigraph 5000ET	(.3, .4, .5, .6, .7, .8, .9, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 20, 30, 40, 50), conc by X-ray attenuation		
0330 I:A	AV		Right Angle Pre.Co	AV		AV
0340 I:A	FG:I		Preseparator,St.	Designed for Loadings > 1 gr/SCF, Inline		
1730 I:A	FG:I		Right Angle Pre.Co	Designed for Loadings > 1 gr/SCF, Right		
3860 I:A	FG:I		Right Angle Pre.Co	Designed for Loadings > 1 gr/SCF, Right		
3870 I:A	FG:I		BCURRA Cyc.		Angle, SORI/EPA design.	
4180 I:A	FG:I		Model 220 CP	Designed for Loadings > 1 gr/SCF, Right	Angle, SORI/EPA design.	
0350 I:CI	AAA		Low Pressure Imp	0.1 SCFM (F,.08, .11, .23, .52, .9, 1.4,	2.0, 3.3, 6.6, 10.5, 15.7, 21.7, 35) Mfg	
0710 I:CI	AAA		C-2000 QCM Cascade	0.01SCFM (F,.07, .13, .22, .40, .63, 1.1	2.1, 4.3, 8.8, 18, 35) Mfg	Crystal Microbalance
0910 I:CI	AAA		PC-202 QCM	0.01SCFM (F,.05, .1, .2, .4, .8, 1.6,3.2,	6.4, 12.5, 25) Mfg	Crystal Microbalance
0920 I:CI	AAA		MPS-3	0.07SCFM (F,.05, .3, 2) Mfg		
0210 I:CI	FG:I		AFT HTP Impactor	0.5 ACFM,1200F(F,.18, .28, .43, .61,.92,	1.2, 2.1, 3.1, 4.8, 7.2), Mfg Data	
0310 I:CI	FG:I		Mark III Impactor	0.5 SCFM (F,.42, .78, 1.2, 2.2, 4.3,	5.9, 9.3, 9.9) Ref.18	
0320 I:CI	FG:I		HCS Impactor	0.5 SCFM (F, 1.5, 5.8, 11) SORI Cyc #3,	Bulk Samples, Inlet Loadings	
1710 I:CI	FG:I		Mark 3	0.5 SCFM (F,.52, .90, 1.3, 2.2, 3.0, 4.3,	6.8, 10.2) Ref 18, Built in Preseparator	(10.2 um)
1720 I:CI	FG:I		Mark 4	0.5 SCFM (F,.52, .90, 1.3, 2.2, 3.0, 4.3,	6.8, 10.2) Ref 18, same as Mark 3 except uses	right angle Preseparator, not built in
2910 I:CI	FG:I		Belfort 1502	0.5 SCFM (F,.52, .69, 1.1, 2.2, 4.8, 9.0,	9.0) Ref 18, stage 1 & 2 cut at 9.0	Metrology Res.Inc. was bought by Belfort
3810 I:CI	FG:I		Mark 3	0.5 SCFM (F,.30, .67, 1.6, 1.8, 4.4,10.1,	10.1) Ref 18, stage 1 & 2 cut at 10.1	Univ. of Washington design



Table A-5: Instrument Type Sorted: More Description

PAGE: 2 of 3

KEY No.	Inst. Type Code	Use Code	Vendor/Model No.	Comments ( 1 of 3 )		Comments continued ( 2 of 3 )		Comments continued ( 3 of 3 )	
				Comments ( 1 of 3 )		Comments continued ( 2 of 3 )		Comments continued ( 3 of 3 )	
3820	I:CI	FG:I	Mark 5	0.5 SCFM (F.,21, .28, .36, .46, .62, .80		1.05, 1.5, 2.8, 5.6, 32) Mfg., U of W,		Stages interchangeable with Mark 3	
3830	I:CI	FG:I	Mark 10	0.2 SCFM (F, DNA ) Inlets, Low Flow,		High Loadings, custom order.			
3840	I:CI	FG:I	Mark 208	2.0 SCFM (F, DNA ) Outlets,high Flow,		Low Loadings, custom order.			
3850	I:CI	FG:I	MARK 8	DNA SCFM (F, DNA ) Inlets,HCSS type,		High Capacity Stack Sampler			
4110	I:CI	FG:I	Model 226	0.25SCFM (F.,9, 1.7, 2.5, 4.1, 11, 14)		Ref. 18			
4120	I:CI	FG:I	Model 228	0.25SCFM (F.,3, .5,9, 1.7, 2.7, 4.4,11		18 ) Mfg. Data			
4130	I:CI	FG:I	Model 2210	0.1 SCFM (F.,09, .35, .57, .86, 1.5, 2.7		4.2, 6.9, 17, 28 ) Mfg Data			
4910	I:CI	FG:I	Brink Model C	.03 SCFM (F.,47,.78, 1.1, 2.3, 3.7, 5.4		9.2 ) Ref. 18, Low Flow, Inlets, High		Loading collection stages available.	
0410	IAN	L:Oth	Image Analysis						
0610	IAN	L:Oth	Omnicon 3500						
1310	IAN	L:Oth	CCSEM (Test Lab)						
2610	IAN	L:Oth	DA-10						
3120	IAN	L:Oth	Image Any. System						
3210	IAN	L:Oth	Magiscan 2						
3510	IAN	L:Oth	Image Any. System						
4510	IAN	L:Oth	Model 1A1000						
4610	IAN	L:Oth	Image Any. System						
4810	IAN	L:Oth	IBAS						
0620	MA	MA	EM-2						
1220	MA	MA	Coulter AccuComp						
1540	MA	MA	FP-303 Opt.						
1550	MA	MA	KD-01 Diluter						
1920	MA	MA	Comp-sieve Anal.Sy						
2320	MA	MA	DCF Data An. Pkq.						
2330	MA	MA	Apple Iie Computer						
4445	MA	MA	IBM-Xt(DR for APS)						
0360	MT17	MA	Emission Param. An						
0370	MT17	MA	Universal Stack Sp						
3410	MT17	MA	Nutech 2010						
3420	MT17	MA	Nutech 220-2						
4010	MT17	MA	RAC Stacksamplr						
1980	Misc	L:AR	Infrasizer/Gilson						
1110	O:A	AAA	Model 226						
1130	O:A	AAA	Model 8060						
1510	O:A	AAA	Status 2100						
1520	O:A	AAA	Status 4000						
1530	O:A	AAA	Status 5000						
2020	O:A	AAA	Model 4101 System						
2030	O:A	AAA	Model 4102 System						
2040	O:A	AAA	Model 4130 System						
2050	O:A	AAA	Model 5100						
2051	O:A	AAA	(cont)						
3720	O:A	AAA	LPC-101						
3730	O:A	AAA	LAS-250X-CRT						
3910	O:A	AAA	HN-15 Karlsruhe						
2710	O:FD	FG:I	FPSSS						
2710	O:FD	FG:I	2600D Spray D Any						
2510	O:FD	FG:I	Stack Part. Monit.						

Table A-5: Instrument Type Sorted: More Description

PAGE: 3 of 3

KEY Type No.	Inst. Code	Vendor/Model No.	Comments ( 1 of 3 )	Comments continued ( 2 of 3 )	Comments continued ( 3 of 3 )
4310 O:FD	FG:I	Particle Sizing In	Argonne Lab., Dual Optics (ratio & interferometry), PROTOTYPE, 1978 Denver EPA		conf. Transfer and Utilization of ...
2410 O:FD	L:LS	Microtrac 7995-10	(.7->125 by x1.414 steps)		
2420 O:FD	L:LS	7995-30Small Part.	(.12, .17, .24, .34 by 2nd optics sys.,		
2730 O:FD	L:LS	Model 3600E	Same as 2600D but designed for liquid		
2810 O:FD	L:LS	Granulometer	(1, 1.5, 2, 3, 4, 6, 12, 16, 24),		
4260 O:FD	L:LS	ILI 1000	16 ch MCA by Acc. PPA-4, multiangle		
4710 O:FD	L:LS	Dawn Model B	Laser, multi angle scattering, Acc.:		
1940 O:L	L:LS	Laser Particle Cou	(see Major Acc.: SAA-3 for 16 ch MCA)		
2060 O:L	L:LS	Model 4103 System	Model number is a pkg. 4100 + sensor		
2070 O:L	L:LS	Model 4113 System	Model number is a pkg. 4100 + sensor		
2085 O:LB	L:LS	HIAC 4313 System	Model number is a pkg. 4300 + sensor		
0810 O:PC	L:LS	BI-90	fitted curves, unimodal		
1230 O:PC	L:LS	M4-128/MD	5 ranges (13 div/range) .04->.15,		
2090 O:PC	L:LS	NICOMP Model 270	(Fitted curves, multimodal, includes		
2720 O:PC	L:LS	Autosizer II	32 pt fitted curve		
1010 PHA	MA	MCA Series 35+			
1120 PHA	MA	Model 8040	Multiplex 40 ext. sensor (particles,		
1950 PHA	MA	Particle Profile	(1, 5, 10, -> 75 by 5 um steps )		
2010 PHA	MA	Model 4100	Multiplex ext. sensors (particles,		
2080 PHA	MA	HIAC 4300	Multiplex ext. sensors (particles,		
3310 PHA	MA	ND 62 MCA			
4270 PHA	MA	PPA-4	w/ILI 1000: (1-> 17 in 1 um steps)		
4720 PHA	MA	Columbia MPC			
1210 RP	L:LS	TA II L/3 Plus	Select orifice, 16 ch for this orifice		
3610 RP	L:LS	180LSD/ADC-80XY/KP	Select orifice, 124 ch for this orifice		
0510 SIV	L:Oth	L3P Sonic Sifter			
1910 SIV	L:Oth	Gilson Sieve Shaker			
1930 SIV	L:Oth	ATM sonic Sifter			

Table A-6: Instrument Type Sorted: Specifications

PAGE: 1 of 3

KEY No.	Inst. Code	Inst. Use Code	----Size Resolution-----					----Concentration Information-----			-Sampling- Rate (SCFM)			Nominal Flow Rate (SCFM)			-Nozzle- Sizes (in.)			Port Req. (in.)	Max. Temp. (Deg F)	Weight (lb)	Power (amp)
			#of Size	UF	FINE	MBD	COARS	E Basis	Dia. A,P,O	Mass Basis (mg/M3)	min.	max.	min.	max.	min.	max.	min.	max.	min.				
4440 AT	AAA	AAA	47	0	25	16	6	0	0	N/A	AV	AV	AV	AV	AV	AV	N/A	N/A	N/A	Amb	DNA	10	10
1975 CFT	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV
1610 CFT	L:AR	L:AR	8	0	1	2	5	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	140	14	14
1410 CMC	AAA	AAA	NONE	0	0	0	0	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	35	2	2
1810 CMC	AAA	AAA	NONE	0	0	0	0	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	67	4	4
4450 CMC	AAA	AAA	NONE	4	5	1	0	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	30	2	2
1960 CSED	L:LS	L:LS	10	4	5	1	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	100	~10	~10
1985 CSED	L:LS	L:LS	DNA	0	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	200	~10	~10
2110 CSED	L:LS	L:LS	DNA	0	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	110	~10	~10
2310 CSED	L:LS	L:LS	DNA	0	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	66	~10	~10
0110 CVC	FG:I	FG:I	3	0	1	1	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	200(4)	40	40
1740 CVC	FG:I	FG:I	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV
1750 CVC	FG:I	FG:I	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV
1760 CVC	FG:I	FG:I	2	0	1	1	0	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	4	15	15
2210 CVC	FG:I	FG:I	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV
4140 CVC	FG:I	FG:I	5	0	3	2	0	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	7	15	15
4150 CVC	FG:I	FG:I	6	0	3	2	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	9	15	15
4160 CVC	FG:I	FG:I	6	0	2	2	2	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	8	15	15
4170 CVC	FG:I	FG:I	3	0	2	1	0	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	5	15	15
1970 CVC	L:LS	L:LS	5	0	0	0	0	Other	Other	LAB	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	800	~5	~5
1420 DB	AAA	AAA	Many	10	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	8	N/A	N/A
2221 DB	AAA	AAA	10	10	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	10	N/A	N/A
4420 DB	AAA	AAA	10	10	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	100(3)	5	5
4460 DB	AAA	AAA	10	10	0	0	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	10	N/A	N/A
4210 DIL	MA	MA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1000(4)	40	40
4470 DIL	MA	MA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	20	10	10
4405 EM	AAA	AAA	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	Amb	100(2)	10	10
4410 EM	AAA	AAA	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	Amb	200(4)	10	10
4430 EM	AAA	AAA	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	CR	Amb	200(4)	10	10
1990 GSED	L:LS	L:LS	32	22	9	1	0	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	150	20	20
3010 GSED	L:LS	L:LS	21	1	8	7	5	Other	Other	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	0	0
0330 I:A	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	AV	Amb	1	0	0
0340 I:A	FG:I	FG:I	1	0	0	0	1	AV	AV	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	N/A	N/A
1730 I:A	FG:I	FG:I	1	0	0	0	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	N/A	N/A
3860 I:A	FG:I	FG:I	1	0	0	0	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	N/A	N/A
3870 I:A	FG:I	FG:I	1	0	0	0	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	N/A	N/A
4180 I:A	FG:I	FG:I	1	0	0	0	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	1	N/A	N/A
0350 I:CI	AAA	AAA	13	3	4	2	4	A	A	DNA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	15	<5	<5
0710 I:CI	AAA	AAA	15	3	4	2	2	A	A	.005	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	15	<5	<5
0910 I:CI	AAA	AAA	10	3	3	2	2	A	A	.001	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	34	10	10
0920 I:CI	AAA	AAA	3	1	2	0	0	A	A	DNA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	7	10	10
0210 I:CI	FG:I	FG:I	6(11)	2	5	4	0	A	A	DNA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	10	15	15
0310 I:CI	FG:I	FG:I	8	0	4	3	1	A	A	DNA	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	10	15	15
0320 I:CI	FG:I	FG:I	3	0	0	2	1	A	A	High	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	10	15	15

Table A-6: Instrument Type Sorted: Specifications

PAGE: 2 of 3

KEY No.	Inst. Type Code	Use Code	Vender/Model No.	-----Size Resolution-----					--- Concentration Information ---				-Sampling- Rate (SCPM)		Nominal Flow Rate (SCPM)	-Nozzle - Size (in.)		Port Req. (in.)	Max. Temp. (Deg F)	Weight (lb)	Power (amp)	
				#of Size Cuts	UF 0->.3	FINE .3->.3	MED .3->10	COARSE >10	Dia. Basis A,P,O	- Mass Basis- (mg/M3)	min.	MAX.	min.	MAX.		min.	Max					
1710	I:CI	PG:I	Mark 3	8	0	5	2	1	A		N/A	N/A	.1	.75	.5	1/8	1/2	3	820	5	15	
1720	I:CI	PG:I	Mark 4	7	0	5	2	0			N/A	N/A	.1	.75	.5	1/8	1/2			5	15	
2910	I:CI	PG:I	Belfort 1502	7	0	4	3		A		DNA	N/A	.2	1.0	.5	1/8	1/2	3	450	3.5	15	
3810	I:CI	PG:I	Mark 3	7	1	3	1	2	A		DNA	N/A	.02	1.2	.5	3/16	1/2	3	450	9	15	
3820	I:CI	PG:I	Mark 5	11(13)	2	8	2	1	A		DNA	N/A	.02	1.0	.5	3/16	1/2	3	450	15	15	
3830	I:CI	PG:I	Mark 10	27	DNA	DNA	DNA	DNA	A		?	N/A	.1	.2	.2	1/8	1/4	4	450	<50	20	
3840	I:CI	PG:I	Mark 20B	14	DNA	DNA	DNA	DNA	A		?	N/A	?	?	2.0	?		4	450	<50	20	
3850	I:CI	PG:I	MARK 8	DNA	DNA	DNA	DNA	DNA	A		DNA	N/A					?	3	450	<15	15	
4110	I:CI	PG:I	Model 226	6	0	3	1	2	A		DNA	N/A	.04	.35	.25	3/32	1/2	3	820	4	15	
4120	I:CI	PG:I	Model 228	8		5	1	2	A		DNA	N/A	.04	.35	.25	3/32	1/2	3	820	4.5	15	
4130	I:CI	PG:I	Model 2210	10	1	5	2	2	A		DNA	N/A	.04	.35	.25	3/32	1/2	3	820	5	15	
4910	I:CI	PG:I	Brink Model C	8	0	4	3	0	A		DNA	N/A	.02	.05	.03	3/32	1/2	3	820	10	10	
0410	I:AN	L:Oth	Image Analysis	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Amb	Heavy	High
0610	I:AN	L:Oth	Omnicon 3500	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
1310	I:AN	L:Oth	CCSEM (Test Lab)	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2610	I:AN	L:Oth	DA-10	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
3120	I:AN	L:Oth	Image Any. System	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
3210	I:AN	L:Oth	Magiscan 2	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
3510	I:AN	L:Oth	Image Any. System	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
4510	I:AN	L:Oth	Model 1A1000	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
4610	I:AN	L:Oth	Image Any. System	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
4810	I:AN	L:Oth	IBAS	Many	N/A	N/A	N/A	N/A	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
0620	MA	MA	EM-2	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Heavy	High
1220	MA	MA	Coulter AccuComp	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	20	<5
1540	MA	MA	FP-303 Opt.	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	10	<5
1550	MA	MA	KD-01 Diluter	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	5	0
1920	MA	MA	Comp-sieve Anal.Sy	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	20(3)	<5
2320	MA	MA	DCF Data An. Pkg.	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A		<5
2330	MA	MA	Apple Iie Comp.	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A		<5
4445	MA	MA	IBM-XT(DR for APS)	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	40	<5
0360	MT17	MA	Emission Param. An	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	.3	1.5	.75	N/A	N/A	N/A	3	820	100	N/A
0370	MT17	MA	Universal Stack Sp	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	.3	1.5	.75	N/A	N/A	N/A	3	820	100	N/A
3410	MT17	MA	Nutech 2010	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	.3	1.5	.75	N/A	N/A	N/A	3	820	100	N/A
3420	MT17	MA	Nutech 220-2	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	.01	.08	.04	N/A	N/A	N/A	N/A	820		N/A
4010	MT17	MA	RAC Stacksmplr	N/A	N/A	N/A	N/A	N/A	N/A		N/A	N/A	.3	1.5	.75	N/A	N/A	N/A	3	820	100	N/A
1980	Misc	L:AR	Infrasizer,Gilson	6	0	0	0	6	Other		N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	200	<5
1110	O:A	AAA	Model 226	16	0	8	7	1	0		DNA	DNA	.25	1	.25	N/A	N/A	N/A	N/A	N/A	45	<5
1130	O:A	AAA	Model 8060	6	0	4	1	1	0		DNA	DNA	.01	.01	.01	N/A	N/A	N/A	N/A	N/A	46	<5
1510	O:A	AAA	Status 2100	2	0	1	1	0	0		DNA	DNA	.01	.01	.01	N/A	N/A	N/A	N/A	N/A	16	<5
1520	O:A	AAA	Status 4000	5	1	3	1	0	0		DNA	DNA	.02	.02	.02	N/A	N/A	N/A	N/A	N/A	55	<5
1530	O:A	AAA	Status 5000	5	1	3	1	0	0		DNA	DNA	.02	.02	.02	N/A	N/A	N/A	N/A	N/A	24	<5
2020	O:A	AAA	Model 4101 System	6	selectable				0		DNA	DNA	.01	.1	.1	N/A	N/A	N/A	N/A	N/A	64	<5
2030	O:A	AAA	Model 4102 System	6	selectable				0		DNA	DNA	.01	.1	.1	N/A	N/A	N/A	N/A	N/A	64	<5
2040	O:A	AAA	Model 4130 System	6	selectable				0		DNA	DNA	.01	.1	.1	N/A	N/A	N/A	N/A	N/A	71	<5
2050	O:A	AAA	Model 5100	6	2	2	2	0	0		DNA	DNA	.01	.1	.1	N/A	N/A	N/A	N/A	N/A	50	<5



