

Final Report

On

Development of Species Profiles for Selected Organic Emission Sources

Volume I: Oil Field Fugitive Emissions

Prepared by

Albert C. Censullo, Ph.D.  
Chemistry Department  
California Polytechnic State University

Contract no. A832-059

Development of Species Profiles for  
Selected Organic Emission Sources

April 30, 1991

California Polytechnic State University

Prepared for California Air Resources Board

Albert C. Censullo, Ph. D.

Final Report  
on  
*Development of Species Profiles for Selected Organic Emission Sources*

Volume I : Oil Field Fugitive Emissions

Prepared by  
Albert C. Censullo, Ph. D.  
Chemistry Department  
California Polytechnic State University

## **ABSTRACT**

This project involved the characterization of fugitive emissions from three source categories. Category 1 sources comprised emissions from California oil production facilities. Site selection criteria were developed, and resulted in the generation of a prioritized list of locations where emissions from light, medium and heavy crude petroleum operations would be sampled. At each site, samples from wellhead, pipeline, processing and storage systems were obtained. Specific components for sampling were pre-screened for positive hydrocarbon emissions using a portable hydrocarbon analyzer. The sampling methodology involved collection of 38 samples in evacuated stainless steel canisters. Detailed emission species profiles were determined by gas chromatography, with flame ionization detection. Peak identification was based on retention times, as well as separate gas chromatographic runs using a mass selective detector.

Category 2 and 3 sources included exhaust from utility and heavy-duty engines. The selection of 20 samples, based on estimates of engine populations in California, was described. The design and fabrication of a portable exhaust dilution system was discussed. Diluted exhaust from selected engines was sampled simultaneously for hydrocarbons and aldehydes. Diesel engines were additionally sampled for higher hydrocarbons. Hydrocarbon species were collected into evacuated stainless steel canisters. Aldehydes were absorbed into midjet impingers containing DNPH/acetonitrile. High molecular weight hydrocarbons from Diesel exhaust were adsorbed in sorbent tubes filled with XAD-2 resin. Hydrocarbons were speciated by gas chromatographic techniques, as with Category 1 sources. Analysis of DNPH-aldehyde derivatives was performed using high performance liquid chromatography. Extracts from the XAD-2 resin were analyzed by gas chromatography, using a mass selective detector.

## DISCLAIMER

The statements and conclusions in this report are those of the contractor and not necessarily those of the California Air Resources Board. The mention of commercial products, their source or use in connection with material reported herein is not to be construed as either an actual or implied endorsement of such products.

## TABLE OF CONTENTS

|                                       |    |
|---------------------------------------|----|
| I. Introduction .....                 | 1  |
| II. Category 1 Sources.....           | 1  |
| A. Site Selection Criteria .....      | 1  |
| B. Component Selection Criteria ..... | 10 |
| C. Sampling Methodology .....         | 10 |
| 1. Sampling Fittings .....            | 10 |
| 2. Sampling for Sumps and Pits.....   | 21 |
| 3. Sampling from Storage Tanks.....   | 25 |
| D. Quality Assurance.....             | 27 |
| E. Analytical Methodologies .....     | 27 |
| F. Oil Field Sampling .....           | 28 |
| 1. Kern River field .....             | 28 |
| 2. Elk Hills field .....              | 28 |
| 3. Belridge Field.....                | 29 |
| 4. Cat Canyon Field.....              | 29 |
| 5. Ventura Field .....                | 29 |
| 6. Wilmington Field.....              | 30 |
| 7. West Coyote Field .....            | 30 |
| 8. Other.....                         | 30 |
| G. Format For Results.....            | 30 |
| H. Results.....                       | 33 |
| I. Discussion of Results .....        | 45 |
| III. References Cited .....           | 50 |

APPENDIX A - Key Personnel Contacts..... 51

APPENDIX B - Photographs of Selected Sampling Sites ..... 52

APPENDIX C -Protocol for Sampling Emissions from Oil Production Facilities ..... 56

APPENDIX D - Analytical Methodololgy and Calibration..... 60

## LIST OF FIGURES

|   |    |
|---|----|
| Figure 1 - Project Personnel .....                            | 2  |
| Figure 2 - Category 1 Sources.....                            | 3  |
| Figure 3 - API Gravity.....                                   | 5  |
| Figure 4 - California Oil Fields .....                        | 6  |
| Figure 5 - Size of Major Oil Fields.....                      | 7  |
| Figure 6 - Previous Studies .....                             | 11 |
| Figure 7 - Oil Production Components .....                    | 12 |
| Figure 8 - Component Distribution.....                        | 13 |
| Figure 9 - Detailed Component Categories.....                 | 15 |
| Figure 10 - Fugitive Emissions Sampling Plan.....             | 17 |
| Figure 11 - Literature Sampling System.....                   | 18 |
| Figure 12 - Schematic Sampling for Valves and Flanges.....    | 19 |
| Figure 13 - Teflon Bag Construction .....                     | 20 |
| Figure 14 - Stainless Steel Canister Design .....             | 22 |
| Figure 15 - Flux Chamber Design.....                          | 23 |
| Figure 16 - Valve Latching Circuit.....                       | 24 |
| Figure 17 - Critical Orifice Design .....                     | 26 |
| Figure 18 - Representative Chromatogram.....                  | 34 |
| Figure 19 - Hydrocarbon Classification by Carbon Number ..... | 35 |



## LIST OF TABLES

|   |    |
|---|----|
| Table 1 - API Gravity of Selected Fields .....                | 4  |
| Table 2 - Major California Oil Producers.....                 | 8  |
| Table 3 - Sampling Matrix for Oil Production Facilities ..... | 9  |
| Table 4 - Incidence of Leaks .....                            | 14 |
| Table 5 - Oil Field Sampling Sites.....                       | 16 |
| Table 6 - Format for Oil Field Results .....                  | 32 |
| Table 7 - Kern River Summary.....                             | 37 |
| Table 8 - Elk Hills Summary.....                              | 38 |
| Table 9 - Belridge Summary .....                              | 39 |
| Table 10 - Cat Canyon Summary.....                            | 40 |
| Table 11 - Ventura Field Summary.....                         | 41 |
| Table 12 - Wilmington Field Summary .....                     | 42 |
| Table 13 - West Coyote Summary .....                          | 43 |
| Table 14 - Sample Database Format.....                        | 44 |
| Table 15 - Sampling Variability.....                          | 46 |
| Table 16 - Methane Sensitivity Analysis Results .....         | 47 |
| Table 17 - Oil Field Summary .....                            | 48 |
| Table 18 - Oil Field Summary by Type of Crude.....            | 49 |

## **SUMMARY**

In accordance with the Request for Proposal issued by the California Air Resources Board, this project involved the characterization of hydrocarbon and aldehyde emissions from a variety of sources. This report deals with Task 1 of that project, the development of a plan for sampling and analysis, as well as the Task 2 implementation of the approved sampling plan. Sources to be sampled were divided into three categories:

Category 1 - Oil Production Fugitive Emissions

Category 2 - Utility Engine Exhaust

Category 3 - Farm and Heavy-Duty Engine Exhaust

### **CATEGORY 1 SOURCES**

As originally proposed, 38 samples from this category were to be collected and analyzed. The numerous components in an oil production field were segregated into "systems". These systems were classified as wellhead, pipeline, processing and storage. Each of these systems is progressively farther from the well than the preceding system. A sampling matrix was developed, consisting of various systems in fields producing light, medium and heavy crude oil. Samples from two secondary sumps were collected from a flux chamber in SUMMA electropolished, evacuated stainless steel canisters. Storage tank headspace samples were collected in evacuated steel canisters. Samples from other systems were obtained by isolating the selected component(s) with a Teflon shroud, and collecting the shroud effluent in evacuated steel canisters. Additional samples from several sources were taken by direct connection of the evacuated canisters to pipe fittings in the distribution lines, using Teflon tubing. Analysis for desired hydrocarbon constituents were performed using a variety of validated chromatographic methods.

### **CATEGORY 2 AND 3 SOURCES**

Using estimates of engine populations in California, a ranking of these sources was developed. Classification was based on engine type, rather than equipment type. A total of 12 samples from Category 2, and 8 samples from Category 3 was recommended for sampling. Sampling for these sources involved dilution of the engine exhaust in a portable mini-tunnel. Hydrocarbons were collected in evacuated stainless steel canisters, while aldehydes were derivatized in DNPH/acetonitrile filed midjet impingers.. High molecular weight hydrocarbons were adsorbed in XAD-2 sorbent tubes. Hydrocarbon analysis were performed using gas chromatographic methods. Aldehyde derivatives were analyzed using high performance liquid chromatography. Extracts from XAD resin were analyzed by GC-MS. Details on this portion of the study are reported separately, in Volume II of this report.

## Final Report, Task 1

### **I. Introduction**


The general objective of this project was "to develop improved hydrocarbon species profiles for oil production equipment, and exhaust from utility and heavy-duty equipment". (ARB RFP, Feb. 1988). These species profiles, when multiplied by the appropriate emission rate factors, will yield detailed information on the mass emission rates for specific compounds. This report is divided into two volumes. The first volume deals with Category 1 sources (Oil Field Fugitive Emissions). The second volume discusses all aspects of Category 2 and 3 sources (Engine Tests). To address the various technical aspects of the project, a team of researchers was assembled. Team personnel, and their primary responsibilities, are shown in Figure 1.

### **II. Category 1 Sources**

#### A. Site Selection Criteria

Efforts in this category were aimed at extracting hydrocarbon profiles from a variety of fugitive emission sources associated with petroleum production operations (Figure 2). There are several classification methods by which California oil production facilities may be grouped. The first of these methods involves classification by type of oil produced. Table 1 illustrates how the American Petroleum Institute (API) gravity may be used to divide crude oil production into light, medium and heavy categories. API gravity is inversely related to the specific gravity of the oil, as shown in Figure 3. Examination of the distribution of oil fields in California (Figure 4) reveals another potential classification scheme. There are three regions in which oil fields appear to cluster: the Salinas Valley (Coastal), the San Joaquin Valley, and the Los Angeles Basin. Figure 5 contains information on the size of the major oil fields in California. It was certainly desirable to have the major fields be included in this study. Thus, the Ventura, Elk Hills and Wilmington fields were targeted for further investigation. While there may be variations in API gravity within a given field, an estimate of the average composition of various fields was developed (Table 2). Moving to a list of major oil producers in California (Table 3), contacts were initiated with personnel from Shell, Chevron, Bechtel, Texaco, Union Oil, and THUMS Long Beach Company. Details of key personnel contacted will be found in Appendix A. Discussions with these people helped clarify the nature and API gravity produced in a large number of lease fields. Combining the information on crude oil type with location produced a sampling matrix, shown in Table 4. The ARB-approved work plan allowed for sampling and analysis of 38 Category 1 Sources. The use of budgeted funds to collect all samples in duplicate did not appear to be an efficient method of quality assurance. Instead, we collected replicates from a single component in a test field. Results from the analyses of these samples provided an estimate of uncertainty in the entire sampling/analysis chain.

**Figure 1 - Personnel**



**Figure 2 - Category 1 Sources**

- Tanks
- Pipeline valves / fittings from  $\left\{ \begin{array}{l} \text{light} \\ \text{medium} \\ \text{heavy} \end{array} \right\}$  crude
- Sumps and pits


Table 1 - - API GRAVITY OF SELECTED FIELDS

| 0.85 ' from bottom<br>FIELD | BASIN       | API <sup>0</sup> |
|-----------------------------|-------------|------------------|
| Cat Canyon                  | Coastal     | 4                |
| Midway-Sunset (shallow)     | San Joaquin | 12               |
| San Ardo                    | Coastal     | 12               |
| Kern River                  | San Joaquin | 13               |
| McKittrick Main Area        | San Joaquin | 15               |
| Santa Maria Valley          | Coastal     | 16               |
| Torrance                    | LA          | 16               |
| Wilmington (shallow)        | LA          | 18               |
| Whitter                     | LA          | 18               |
| Richfield                   | LA          | 22               |
| Coyote East                 | LA          | 22               |
| Montebello                  | LA          | 22               |
| Huntington Beach            | LA          | 24               |
| Belridge South              | San Joaquin | 25               |
| Elk Hills                   | San Joaquin | 25               |
| Inglewood                   | LA          | 26               |
| Midway-Sunset (deep)        | San Joaquin | 26               |
| Long Beach                  | LA          | 27               |
| Coyote West                 | LA          | 28               |
| Coalinga Nose               | San Joaquin | 32               |
| Dominguez Hills             | LA          | 32               |
| Rosecrans                   | LA          | 32               |
| Wilmington (deep)           | LA          | 32               |
| Santa Fe Springs            | LA          | 33               |
| Montebello (deep)           | LA          | 36               |
| Kettleman Hills             | San Joaquin | 38               |
| Coles Levee                 | San Joaquin | 40               |
| Rio Bravo                   | San Joaquin | 40               |
| Paloma                      | San Joaquin | 50               |

**Figure 3 - API Gravity**

$$^{\circ}\text{API} = \frac{141.5}{\text{specific gravity}} - 131.5$$

| $^{\circ}\text{API}$ | specific gravity | Example     |
|----------------------|------------------|-------------|
| 10                   | 1.000            | water       |
| 20                   | 0.934            | heavy crude |
| 30                   | 0.876            | light crude |



MAP OF  
CENTRAL & SOUTHERN CALIFORNIA  
SHOWING OIL & GAS FIELDS

Figure 4 - California Oil Fields



Figure 5 -

Figure 5 - Size of Major Oil Fields

# CALIFORNIA'S GIANT OIL FIELDS

(Fields with ultimate recovery of 100 million barrels or more)

| FIELD                            | YEAR<br>DISCOVERED | CUMULATIVE<br>PRODUCTION<br>(MMbbl) | ESTIMATED<br>RESERVES<br>(MMbbl)<br>(12/31/87) | 1987<br>PRODUCTION<br>(MMbbl) | PRODUCING<br>WELLS<br>(1987) |
|----------------------------------|--------------------|-------------------------------------|--|-------------------------------|------------------------------|
| 1. Wilmington                    | 1932               | 2,351,472                           | 526,686  | 32,108                        | 3,055                        |
| 2. Pico River-Sunset             | 1932               | 1,591,312                           | 430,645  | 57,761                        | 5,875                        |
| 3. Elk Hills                     | 1939               | 1,158,042                           | 789,674  | 45,661                        | 7,220                        |
| 4. Buena Vista Beach             | 1920               | 1,060,187                           | 77,874   | 6,058                         | 598                          |
| 5. Long Beach                    | 1921               | 907,115                             | 20,313   | 2,583                         | 415                          |
| 6. Ventura                       | 1919               | 887,658                             | 101,367  | 7,279                         | 570                          |
| 7. Elk Hills                     | 1911               | 854,146                             | 618,599  | 40,512                        | 1,117                        |
| 8. Coalinga                      | 1920               | 743,232                             | 182,516  | 10,215                        | 1,035                        |
| 9. Buena Vista                   | 1920               | 743,232                             | 182,516  | 10,215                        | 1,035                        |
| 10. Belridge, South              | 1911               | 612,000                             | 494,942  | 63,562                        | 6,163                        |
| 11. Santa Fe Springs             | 1919               | 612,295                             | 9,959  | 1,930                         | 166                          |
| 12. Coalinga, East, Extension    | 1928               | 497,452                             | 18,655   | 1,253                         | 82                           |
| 13. Kettleman North Dome         | 1928               | 456,485                             | 1,130  | 184                           | 31                           |
| 14. San Ardo                     | 1947               | 403,452                             | 124,230  | 4,333                         | 146                          |
| 15. Area-Orinda                  | 1880               | 381,491                             | 56,659   | 2,320                         | 198                          |
| 16. Inglewood                    | 1924               | 343,006                             | 57,042   | 3,078                         | 126                          |
| 17. Cat Canyon                   | 1908               | 285,509                             | 49,490   | 2,940                         | 612                          |
| 18. Dominguez                    | 1923               | 268,794                             | 8,052  | 2,607                         | 117                          |
| 19. McKittrick                   | 1896               | 264,032                             | 91,445   | 2,480                         | 1,067                        |
| 20. Point Peco                   | 1926               | 256,653                             | 43,645   | 7,034                         | 1,300                        |
| 21. Coyote, West                 | 1909               | 249,205                             | 8,317  | 430                           | 126                          |
| 22. Guyana, South                | 1949               | 217,567                             | 7,426  | 519                           | 105                          |
| 23. Torrance                     | 1922               | 210,358                             | 37,204   | 1,681                         | 366                          |
| 24. Dos Cuadras Offshore         | 1968               | 203,204                             | 63,352   | 5,044                         | 141                          |
| 25. Seal Beach                   | 1924               | 202,242                             | 14,951   | 946                           | 176                          |
| 26. Santa Maria Valley           | 1924               | 196,202                             | 42,148   | 1,902                         | 185                          |
| 27. Coyote, East                 | 1909               | 191,494                             | 36,459   | 6,388                         | 1,144                        |
| 28. McKittrick                   | 1917               | 191,187                             | 10,403   | 6,516                         | 164                          |
| 29. Richfield                    | 1919               | 188,369                             | 28,971   | 1,612                         | 227                          |
| 30. Lost Hills                   | 1910               | 172,551                             | 67,292   | 5,293                         | 1,755                        |
| 31. Kern Front                   | 1912               | 171,524                             | 57,265   | 1,702                         | 493                          |
| 32. Occidental-Levee, North      | 1914               | 159,800                             | 13,194   | 1,392                         | 124                          |
| 33. Rincon                       | 1927               | 147,625                             | 17,110   | 1,164                         | 244                          |
| 34. South Mountain               | 1916               | 145,216                             | 12,821   | 741                           | 371                          |
| 35. Edison                       | 1928               | 132,961                             | 28,117   | 1,529                         | 836                          |
| 36. Beverly Hills                | 1900               | 119,710                             | 44,420   | 2,213                         | 121                          |
| 37. Rio Bravo                    | 1938               | 115,897                             | 1,344  | 470                           | 346                          |
| 38. Fruitvale                    | 1936               | 112,476                             | 2,001  | 256                           | 35                           |
| 39. Grealey                      | 1909               | 108,076                             | 13,753   | 625                           | 120                          |
| 40. Coyote, East                 | 1928               | 105,276                             | 2,608  | 365                           | 7                            |
| 41. Elwood                       | 1927               | 96,010                              | 5,756  | 261                           | 263                          |
| 42. Round Mountain               | 1931               | 95,208                              | 46,630   | 1,945                         | 43                           |
| 43. San Miguelito                | 1966               | 45,411                              | 31,919   | 2,686                         | 119                          |
| 44. Carpinteria Offshore (total) | 1912               | 82,485                              | 45,459   | 2,430                         | 550                          |
| 45. Belridge, North              | 1959               | 78,378                              | 122,522  | 9,587                         | 321                          |
| 46. Poso Creek                   | 1920               | 78,005                              | 25,091   | 836                           | 462                          |
| 47. Poso Creek Offshore          | 1974               | 74,721                              | 33,750   | 7,946                         | 73                           |
| 48. Yo-June                      | 1976               | 33,704                              | 180,568  | 6,650                         | 61                           |
| 49. Beta Offshore                |                    |                                     |  |                               |                              |

NOTE: If future reserve estimates are revised upwards, Torba Linda field may be included on the list. The cumulative production for this field is 83,163 MMbbl, and estimated reserve is 11,618 MMbbl.




Table 2 -

## THIRTY LARGEST OIL PRODUCERS IN CALIFORNIA - 1987\*

| PRODUCER  | OIL PRODUCTION (Mbb1) |
|---|-----------------------|
| 1. Shell Western E. & P. Inc. (1)+                                  | 85,902                |
| 2. Texaco, Inc. (2)   | 48,492                |
| 3. Bechtel Petroleum Operations Inc. (4) a/                         | 40,654                |
| 4. Chevron U.S.A. Inc. (3)  | 40,057                |
| 5. Mobil Oil Corporation (6)  | 22,127                |
| 6. THUMS Long Beach Company (5)                                     | 20,953                |
| 7. Santa Fe Energy Company (9)                                      | 16,320                |
| 8. Tenneco Oil Company (8)  | 16,177                |
| 9. Union Oil Company of California (7)                              | 15,835                |
| 10. Sun Oil Company (10)  | 10,732                |
| 11. ARCO Oil and Gas Company (11)                                   | 6,980                 |
| 12. Celeron Oil and Gas Company (15)                                | 4,716                 |
| 13. Union Pacific Resources Company (14) b/                         | 2,994                 |
| 14. Exxon Corporation (16)  | 2,731                 |
| 15. Berry Petroleum Company (NA) c/                                 | 2,517                 |
| 16. Conoco, Inc. (17)   | 2,275                 |
| 17. M. E. Whittier Corporation (18)                                 | 2,259                 |
| 18. Long Beach Oil Development Company (19)                         | 1,844                 |
| 19. McFarland Energy Inc. (22)                                      | 1,023                 |
| 20. Cities Service Oil Company (21)                                 | 881                   |
| 21. Tannehill Oil Company (NA)                                      | 805                   |
| 22. Mission Resources (20)  | 726                   |
| 23. Occidental Petroleum Corporation (25)                           | 672                   |
| 24. Powerine Oil Company (Operator for the City of Long Beach) (24) | 670                   |
| 25. West Newport Oil Company (26)                                   | 661                   |
| 26. Mobil Exploration & Production, North America, Inc. (27)        | 638                   |
| 27. Petro-Lewis Corporation (13)                                    | 506                   |
| 28. Signal Hill Petroleum (30)                                      | 440                   |
| 29. Chase Production Company (NA)                                   | 416                   |
| 30. Barto/Signal Petroleum Inc. (NA)                                | 403                   |

\* Does not include federal OCS figures. Also, total production from unitized operations is credited to the unit operators and not allocated to the other unit participants; therefore, production figures are overstated for unit operators and understated for other unit participants.

+ Numbers in parentheses indicate last years rankings.

a/ Production shown for Bechtel Petroleum Operations Inc. includes Chevron U.S.A. Inc.'s portion of Elk Hills production, which was 8,841 Mbb1., and is not included in Chevron's total.

b/ Formerly listed as Champlin Petroleum Company.

c/ Includes figures formerly reported separately under Berry & Ewing, Berry Holding Co., Berry Ventures, Big Ten Oil Co., Ethel D. Co., and Berry Oil Co.

Table 3 - Sampling Matrix for Oil Production Facilities

| Site           | # of samples | Operator      | Basin       | Oil type    | Preferred,<br>alternate |
|----------------|--------------|---------------|-------------|-------------|-------------------------|
| 1. Santa Maria | 4            | Union Oil     | Coastal     | Heavy       | preferred               |
| 2. Ventura     | 4            | Chevron       | Coastal     | Heavy       | preferred               |
| 3. San Ardo    | 4            | Texaco        | Coastal     | Heavy, sour | alternate               |
| 4. Coyote West | 6            | Chevron       | LA          | Medium      | preferred               |
| 5. Wilmington  | 6            | THUMS         | LA          | Heavy       | preferred               |
| 6. Elk Hills   | 8            | Bechtel (DOE) | San Joaquin | Light       | preferred               |
| 7. Bellridge   | 8            | Shell         | San Joaquin | Light       | preferred               |
| 8. Kern River  | 8            | Texaco        | San Joaquin | Medium      | alternate               |

## B. Component Selection Criteria

Once suitable sites had been identified, selection of the mix of components to sample became the next consideration. Using previous related studies (Figure 6) as a starting point, an inventory of possible components was generated (Figure 17). The distribution of various components is shown in Figure 8. Reported incidence of leaks for these components is shown in Table 5. A Rockwell study categorized components into 9 types, and 51 styles (Figure 9). It became apparent that the 38 budgeted samples could not be selected on a component basis. An alternative approach is to consider the numerous components arranged into systems of varying complexity and function. Within each system, the nature of fugitive emissions from various components will be identical (or at least very similar). For example, the composition of fugitive emissions from a leaking gate valve at the wellhead will be the same as the emissions leaking from a flange a few inches away. Consider the same valve/flange combination at a storage tank. The emissions will now reflect the composition of the tank's contents. Systems to be sampled include wellhead, pipeline, processing and storage. Discussions with ARB at the 2/9/89 meeting confirmed that this approach should yield data compatible with the project's goal. At each site identified in the previous section, components from each system would be sampled, up to the amount of samples allotted per site. This process allowed for more efficient use of the limited number of samples budgeted for analysis than would be possible in a component-driven sample selection process. Table 6 represents a summary of all oil field samples collected.

## C. Sampling Methodology

The general steps involved in sampling fugitive emissions are outlined in Figure 10. Facility maps, and piping and instrumentation drawings will provide an estimate of where the maximum density of components to be sampled are located. Previous studies have indicated that usually these drawings are either not available or not current enough to be useful. Consequently, we performed final component selection on-site, using a rapid screening method to identify potential components. Oil field personnel at each site provided assistance in locating sampling sites meeting our selection criteria. Each selected component was tested using a Gastech Analyzer to verify the presence of hydrocarbons. The component would then be sampled, subject to conforming to the desired systems and sample numbers at the site. Sample characteristics, including temperature, size, estimated leak rate (from soap leak test), and condition were recorded. At least 3 photographs were taken of each component sampled. These showed the component in isolation, its location in a system, and the sampling device used. Appendix B shows some selected sampling setups.

### 1. Sampling Fittings

While there is no "standard" method for sampling components of varying sizes and shapes for fugitive emissions, past studies have isolated the desired component, using a "shroud" of inert sheeting. An example of such a sampling system is shown in Figure 11. If the component has a leak rate in excess of 1 liter/minute, the emission will purge and inflate the shroud in a reasonably short period of time. This "direct" approach will not work for small leaks. An "indirect" method for sampling small leaks involves capturing the emission with a stream of dilution air. Previous studies have used ambient air for dilution. This required an independent analysis of ambient air for each component sampled. The proposed sampling system to be used in this study is illustrated in Figure 12. The component shrouds were fabricated from Teflon (FEP) bags. A quantity of 12" x 12" and 24" x 36" bags were prepared, as illustrated in Figure 13. A cylinder of ultra-zero air (<0.1 ppm hydrocarbons) was used for the source of dilution. A size 3 cylinder holding 30 cubic feet at 2000 PSI, and weighing less than 30 pounds was

**Figure 6 - Previous Oil Production Fugitive Emission Studies**

- 1. RADIAN CORP (EPA) , 1978**
- 2. EMSI (ROCKWELL) , 1979**
- 3. KVB (ARB) , 1980**
- 4. ERT (WOGA) , 1983**
- 5. EMSI (MIN. MGMT. CORP) , 1988**

## Figure 7 - Oil Production Components

### Oil Production Equipment

#### I. Tanks

##### A. Storage

- Fixed roof
- Floating roof
- Internal floating cover
- Variable space

##### B. Surge

##### C. Flotation

##### D. Vapor recovery

##### E. Wash

#### II. Pipeline Valves and Flanges

##### A. Valves

- Gate
- Ball
- Plug
- Globe
- Needle
- Check
- Butterfly
- Relief

##### B. Flanges

- Raised face
- Flat face
- API ring
- Access

#### III. Sumps and Pits

##### A. Cleanout sumps

##### B. Produced water sumps

##### C. Sucker rod pits

##### D. Well cellars

**Figure 8 - COMPONENT DISTRIBUTION**




Table 4 - INCIDENCE OF LEAKS

(From 1979 EMSI Study)

|              | Number of<br>Components<br>Tested | Percent<br>Leaking |
|--------------|-----------------------------------|--------------------|
| Valves       | 9427                              | 6.4                |
| Flanges      | 54,694                            | 2.8                |
| Tank Hatches | 170                               | 2.4                |
| Seals        | 474                               | 30.6               |
| Pits         | 26                                | 100                |



Figure 9 - Detailed Component Categories

| <u>Component Types</u> |    |                       | <u>Systems</u> |
|------------------------|----|-----------------------|----------------|
| 1                      | VL | Valve                 | 1 Well head    |
| 2                      | CN | Connection            | 2 Pipelines    |
| 3                      | SG | Sight Glass           | 3 Processing   |
| 4                      | MT | Meter                 | 4 Storage      |
| 5                      | HA | Hatch                 |                |
| 6                      | SP | Seal Packing          |                |
| 7                      | DI | Diaphragm             |                |
| 8                      | SM | Sealing Mechanism     |                |
| 9                      | PP | Sump, Pile, Pit, Etc. |                |

| <u>Component Styles</u> |    |      |                            |      |    |      |                               |
|-------------------------|----|------|----------------------------|------|----|------|-------------------------------|
| 1- 1                    | VL | GATE | Gate                       | 5- 1 | HA | FLFF | Flanged                       |
| 1- 2                    | VL | MULT | Multi-Directional          | 5- 2 | HA | FLGA | Flat, Soft Gasket             |
| 1- 3                    | VL | BALL | Ball                       | 5- 3 | HA | THIF | Thief                         |
| 1- 4                    | VL | PLUG | Plug                       | 6- 1 | SP | RERO | Reciprocating Rod             |
| 1- 5                    | VL | GLBE | Globe                      | 6- 2 | SP | ROSH | Rotating Shaft                |
| 1- 6                    | VL | NDLE | Needle                     | 6- 3 | SP | MESL | Mechanical Seal               |
| 1- 7                    | VL | CHCK | Check                      | 6- 4 | SP | WLHD | Wellhead, Stuffing Box        |
| 1- 8                    | VL | BTFY | Butterfly                  | 7- 1 | DI | VLOP | Valve Operator                |
| 1- 9                    | VL | RELF | Relief                     | 7- 2 | DI | OPRS | Differential Pressure Sensing |
| 1-10                    | VL | CHOK | Choke                      | 8- 1 | SM | GATE | Gate                          |
| 1-11                    | VL | BEAN | Bean Choke                 | 8- 2 | SM | MULT | Multi-Directional             |
| 2- 1                    | CN | FLFF | Raised or Flat Face Flange | 8- 3 | SM | BALL | Ball                          |
| 2- 2                    | CN | FLRI | Ring Flange                | 8- 4 | SM | PLUG | Plug                          |
| 2- 3                    | CN | FLBO | Flanged Bonnet             | 8- 5 | SM | GLBE | Globe                         |
| 2- 4                    | CN | THRD | Threaded                   | 8- 6 | SM | NDLE | Needle                        |
| 2- 5                    | CN | GRVD | Grooved                    | 8- 7 | SM | CHCK | Check                         |
| 2- 6                    | CN | FRIC | Friction                   | 8- 8 | SM | BTFY | Butterfly                     |
| 2- 7                    | CN | GASK | Gasket                     | 8- 9 | SM | RELF | Relief                        |
| 2- 8                    | CN | UNIN | Union                      | 8-10 | SM | CHOK | Choke                         |
| 2- 9                    | CN | LAND | Landing Flange             | 8-11 | SM | BEAN | Bean                          |
| 2-10                    | CN | TUBE | Tubing                     | 9- 1 | PP | OPSU | Open Sump (Produced Water)    |
| 2-11                    | CN | ORIN | O-Ring                     | 9- 2 | PP | CLSU | Closed Sump                   |
| 2-12                    | CN | FLGA | Flat, Soft Gasket          | 9- 3 | PP | WLCL | Well Cellar                   |
| 3- 1                    | SG | GLSS | Glass Type                 | 9- 4 | PP | COSU | Clean-out Sump                |
| 4- 1                    | MT | FLOW | Flow                       | 9- 5 | PP | OPTK | Open Roofed Tank              |
| 4- 2                    | MT | TURB | Turbine Type Flow          |      |    |      |                               |


Table 5- Oil Field Sampling Sites

| <u>sample #</u>    | <u>API<sup>o</sup></u> | <u>location</u>    | <u>method</u>     | <u>comments</u>                   |
|--------------------|------------------------|--------------------|-------------------|-----------------------------------|
| <b>Kern River</b>  |                        |                    |                   |                                   |
| OF-1               | 13.5                   | gage tank (AWT143) | headspace         | roof hatch                        |
| OF-2               | 13.5                   | well 406           | bag valve         |                                   |
| OF-3               | 13.5                   | well 406           | bag valve         | duplicate of OF 2                 |
| OF-4               | 13.5                   | shipping tank #40  | headspace         | roof hatch                        |
| OF-5               | 13.5                   | surge tank         | headspace         | roof hatch                        |
| OF-6               | 13.5                   | well 271           | bag valve         | well duplicate                    |
| <b>Elk Hills</b>   |                        |                    |                   |                                   |
| OF-10              | 23                     | tank 11105         | bag sampling port | headspace                         |
| OF-11              | 23                     | compressor FR1364  | canister direct   | vapor recovery:<br>NPT connection |
| OF-12              | 23                     | separator 11044    |                   |                                   |
| OF-13              | 36                     | tank 11470         | same as OF-10     | Stevens zone                      |
| OF-14              | 36                     | separator 14255    |                   |                                   |
| OF-15              | 36                     | tank 14217         | bag sampling port | headspace                         |
| OF-16              | 22                     | tank 53579         | bag 2" port       | steamflood operation              |
| OF-17              | 22                     | test separator     | bag meter valve   | steamflood<br>produced gas        |
| <b>Belridge</b>    |                        |                    |                   |                                   |
| OF-20              | 33                     | tank LOTS 201      | canister direct   | 20 well composite<br>vapor        |
| OF-21              | 33                     | well 548G-34       | bag valve         | casing gas                        |
| OF-22              | 26                     | tank LOTS 209      | canister direct   | 1/4 NPT gauge port                |
| OF-23              | 21                     | well 551-A33       | gas valve         | casing gas                        |
| OF-24              | 28                     | tank LOHF          | canister direct   | 20 LOTS composite                 |
| OF-25              | 13                     | tank DEHY #27      | canister direct   | heavy field composite             |
| OF-26              | 13                     | tank HOTS 113      | bag valve port    | 50 well heavy<br>composite        |
| OF-27              | 13                     | tank HOTS 192      | bag valve port    | 50 well heavy<br>composite        |
| <b>Cat Canyon</b>  |                        |                    |                   |                                   |
| OF-40              | 14                     | well 53            | bag valve         | casing gas                        |
| OF-41              | 14                     | well 53            | bag valve         | tubing gas                        |
| OF-42              | 14                     | vapor recovery     | bag valve         | composite of all tanks            |
| OF-43              | 14                     | sump, inlet end    | flux chamber      |                                   |
| OF-44              | 14                     | sump, outlet end   | flux chamber      |                                   |
| <b>Ventura</b>     |                        |                    |                   |                                   |
| OF-50              | 29                     | tank               | bag valve         | 100 well composite                |
| OF-51              | 29                     | well L-131         | bag valve         | casing gas                        |
| OF-52              | 29                     | vapor recovery     | canister direct   | field composite                   |
| OF-53              | 29                     | vapor recovery     | canister direct   | shipping tank                     |
| <b>Wilmington</b>  |                        |                    |                   |                                   |
| OF-60              | 18                     | Pier J sump        | flux chamber      |                                   |
| OF-61              | 18                     | tank TK 003        | headspace         | roof hatch                        |
| OF-62              | 18                     | FWKO tank #3       | canister direct   |                                   |
| OF-63              | 18                     | well J-341         | bag valve         | casing gas                        |
| <b>West Coyote</b> |                        |                    |                   |                                   |
| OF-70              | 28                     | AWT tank 105       | bag valve         |                                   |
| OF-71              | 28                     | work tank #1       | headspace         | roof vent                         |
| OF-72              | 28                     | stock tank         | bag port          | manometer port                    |
| OF-73              | 28                     | vapor recovery     | bag valve         | field vapor recovery              |

**Figure 10 - FUGITIVE EMISSIONS SAMPLING PLAN**

- STUDY FACILITY MAPS / DRAWINGS
- INVENTORY AND "SOAP TEST" COMPONENTS
- CHECK LEAKERS WITH OVA
- SAMPLE LEAKERS PER COMPONENT MIX
- DOCUMENT SAMPLED COMPONENTS

Figure 11 - Literature Sampling System



**Figure 12 - SCHEMATIC REPRESENTATION OF  
SAMPLING FOR VALVES AND FLANGES**






Figure 13 - Teflon Bag Construction

TEFLON SAMPLING BAG



FITTING DETAIL



brought to each oil field site. A manual control valve attached to the cylinder ensured contamination-free and reliable delivery of the zero air. In using this scheme, resources need not be spent on determining ambient concentrations in dilution air. Once the shroud has been filled with emissions, sampling from the shroud into an evacuated, SUMMA electropolished stainless steel canister (Figure 14) may be started. The long-term stability of hydrocarbons in these containers has been well-established<sup>1</sup>. Since no sampling pumps are needed in the field, contamination or degradation of the collected samples is virtually impossible. Pre- and post-sampling canister pressure checks were performed in the field, using a portable vacuum/pressure gauge. These pressures were verified at the analytical laboratory. In practice, purging of sampled components (indirect emission sampling) proved to be unnecessary, due to the large "leak rates" of components selected for sampling. Consistent with the objectives of the program, representative vapor samples were obtained at selected points in the overall process. While the exact method of sampling fugitive emissions depended on the source, several general methods were employed. In some instances, existing pipe fittings were connected to the evacuated stainless steel canisters by 0.25 inch diameter Teflon tubing equipped with stainless steel Swagelok fittings. Sampling flowrate could be controlled by the needle valve on the canister. For cases in which no suitable pipe fittings were available, pipe ends equipped with shutoff valves were often located. In these cases, the exposed pipe end was surrounded with a Teflon bag, secured with a large rubber band. The sampling bag was then purged and inflated with source emissions. This "buffer" volume was sampled into an evacuated canister connected to the bag by a length of 0.25 inch Teflon tubing. These approaches worked well for sources which were above atmospheric pressure. Samples ranging in pressure from 50 PSI to a few inches of water were successfully sampled by these methods. Sampling was normally continued until canister pressure, monitored by an attached pressure/vacuum gauge, reached atmospheric pressure.

## 2. Sampling for Sumps and Pits

In order to obtain samples of fugitive emissions from sumps and pits, some sort of emission isolation (flux) chamber is required. The U.S. EPA<sup>2</sup> and California ARB<sup>3</sup> have validated designs used for emission rate measurements. For the sump samples, an ARB sump sampler used in previous studies was modified. The existing acrylic flux box was removed. A new flux chamber, fabricated from a 14" diameter stainless steel hemisphere, was prepared, as shown in Figure 15. A latching valve was incorporated into the design to allow sampling to be initiated remotely. The sampling canister was located on the sump sampler to minimize the potential for contamination or losses in the sampling line. A circuit to produce pulses of the proper characteristics to operate the latching valve was constructed (See Figure 16). The circuit was powered by two 9 volt transistor batteries. These batteries provided several hundred activation cycles during testing without appreciable loss of working voltage. Pulses were approximately 50 milliseconds in duration. An umbilical was necessary to convey air and latching voltage pulses to the sampler. Three 1/4" Teflon lines, and one four conductor shielded cable were bundled together with nylon cable ties. One Teflon line was used with a zero air source to control the pneumatic pistons which ultimately raised and lowered the attached flux chamber. A second Teflon line provided the ultra-zero sweep air to the flux chamber. The third Teflon line returned the flux chamber purge gas to shore for testing. The total length of the umbilical was 50 feet. The aluminum pontoons of the ARB sampler were moved apart several inches to allow for the mounting of the new flux chamber. The assembled device was tested for buoyancy on an irrigation pond at Cal Poly. The final configuration proved to be stable and buoyant.

**Figure 14 -     Stainless Steel Canister Design**






Figure 15- Flux Chamber Design






Figure 16 VALVE LATCHING CIRCUIT

schematic



component placement



Sampling was conducted at a flow rate of 5 liters/minute, following the suggested EPA protocol. Chamber volume was roughly 15 liters, so the residence time at this flowrate was on the order of 3 minutes. According to the adopted protocol, sampling would begin after 4 chamber volumes had been purged (12 minutes). At the end of 12 minutes, a sample was pulled into an evacuated stainless steel canister, via the latching valve. In order to prevent the canister from drawing air at a greater rate than was provided (5 liter/minute), some method of flow control was required. Although the sampling canisters used were fitted with bellows valves, it proved impossible to reliably control flow by partially opening the valves. A limiting orifice was fabricated from an 18 gauge hypodermic needle. See Figure 17 for construction details. The canister metal bellows valve was kept in the fully open position at all times. The latching valve enabled/disabled flow, while the limiting orifice controlled the flow rate into the canister. This simple approach worked reliably in field tests. The canister thus equipped would fill in roughly 90 seconds, for an average flow rate of  $3.2 \text{ liters}/1.5 \text{ min} = 2.1 \text{ liters/min}$ .


Prior to use in the field, a test to explore possible pressure buildup inside the chamber at the anticipated flowrate was undertaken. The flux chamber was suspended in a basin of water, so that the lower lip was immersed about one inch below the liquid surface. Pressure inside the chamber was measured with a Magnehelic gauge while 5 liters/minute of sweep air was admitted to the chamber. The Magnehelic gauge indicated a differential pressure of less than 0.2 inches of water, which was deemed satisfactory. This sampling system utilized the same zero air source and stainless steel canisters as used for sampling fittings (vide supra). Samples presented to the laboratory for analysis thus had identical sample handling procedures, regardless of whether the samples were taken from shrouds, sumps/pits or storage tanks (vide infra). Since secondary sumps comprise approximately 99% of total sump areas, and since most secondary sumps have areas in excess of 1000 square feet, secondary sumps larger than 1000 square feet were used to satisfy sampling requirements for sumps. Previous work<sup>3</sup> involving the characterization of hydrocarbon emissions from sumps failed to show a clear dependence of emission rate or composition on location within a sump. Consequently, we proposed testing each sump at a single location. If accessibility permitted, a spot near the center of the sump was selected. The composition at the center of the sump is more likely to be representative of the average sump area than locations near a sump inlet or outlet. At each location, a sketch and photograph(s) were produced. Pertinent information about the sump, including temperature, oil depth, and size will be recorded on a data sheet prior to sampling. Detailed protocols for sampling these components will be found in Appendix C. The use of sumps in California petroleum fields has been declining dramatically in recent years. Consequently, only two sumps were sampled in this study.

### 3. Sampling from Storage Tanks

Storage tanks have long been recognized as potentially large sources of fugitive emissions. Consequently, extensive work on storage tank design has produced alternatives which attempt to reduce the quantity of fugitive emissions. Some of these schemes such as the floating roof, produce systems in which accurate sampling for fugitive emissions is quite difficult. Since this project is more concerned with emission composition than emission rate measurements, a conceptually simple approach to collecting accurate samples from tanks was discussed with ARB. Regardless of tank design, if it leaks at all, it will leak the headspace of the tank. Thus, sampling the headspace inside the tank should provide all the information needed for this study. Conversations with personnel (Hagist and Rutledge, Appendix A) in petroleum operations confirmed that access hatches are located on top of storage tanks, and are readily accessible for

# CRITICAL ORIFICE CONSTRUCTION

Figure 17 - Critical Orifice Design



sampling headspace. At the 2/9/89 meeting, the Board approved of headspace sampling for storage tanks. Most of the tanks sampled in this study were equipped with access hatches on the roof. If the tank headspace were at atmospheric pressure, its contents were sampled into an evacuated canister by means of a short 0.25 inch diameter stainless steel probe inserted through the access hatch. In several cases, the tanks were maintained above atmospheric pressure by the vapor recovery system. Opening the roof hatch on tanks so equipped would require venting appreciable amounts of vapor to the atmosphere. In these cases, a sampling port external to the tank was located. The pipe end was bagged, and the emissions were sampled from this bag, as described earlier.

Detailed protocols for sampling fugitive emissions from oil production facilities may be found in Appendix C.

#### D. Quality Assurance

Quality assurance (QA) activities for Category 1 sources may be divided into three categories:

1. Pre-field sampling QA
2. Field sampling QA
3. Analytical QA

Pre-field activities included a complete checkout of all sampling system components. Data on the analysis of gas cylinders to be used were compiled. Data forms, sample labels and containers were located and prepared. To verify proper operation of the sump sampler, the flux chamber was placed on top of a clean sheet of Teflon, and zero air was allowed to flow through the system. This purge air was collected and analyzed, to verify the absence of background contamination. Prior to sample collection, all sample lines were thoroughly flushed with zero air. Adherence to the written protocols found in Appendix C enhanced the overall reliability and reproducibility of data obtained. Quality assurance activities pertaining to analyses are described in Appendix D.

#### E. Analytical Methodologies

A variety of analytical techniques were needed to quantitate the hydrocarbon species present in the oil field samples. This section summarizes the analytical methodologies used by the Project Subcontractor, Environmental Analytical Service, Inc. (EAS). Details and standard operating procedures for the methods of analysis will be found in Appendix D.

Methane was analyzed using a molecular sieve 5A column, operated isothermally at 50 °C. Light hydrocarbons were separated using a ten foot column packed with phenylisocyanate on 80/100 mesh Durapack. Samples with high hydrocarbon content were analyzed on a 30 foot column containing 23 % SP-1700 on 80/100 mesh Chromosorb PAW. Heavy hydrocarbons were analyzed using a 100 meter fused silica capillary column.

Comparison of the light (packed column) and heavy hydrocarbon (capillary column) runs could be made using a number of peaks in the C2 to C4 range. The heavy stationary phase loading of the 100 meter capillary column allowed for the separation of the lighter hydrocarbons. In this project, values for the light hydrocarbons (from C2 on) obtained from the capillary column run were used for all calculations shown in the Results section of the report. Values obtained from the analyses of light hydrocarbons on the two columns (packed and capillary) were generally comparable (within 10% of each other). In many instances, the capillary column allowed for the identification of peaks which were listed as "OTHER" by the packed column method. It became operationally simpler to utilize data from the capillary run to quantitate all hydrocarbon species (other than

methane), and this procedure obviously eliminated the effect of compounding and propagating analysis errors from two different analytical methods.

## F. Oil Field Sampling

### 1. Kern River field

A site visit was planned to finalize sampling methodologies and location. The trip was conducted on May 12, 1989. Censullo and Eatough toured the facility with Tim Stoner of Texaco. Plans were made for sampling on July 10. The average API gravity of this field is 13.5°. Recovery method in this field is primarily steamflood. Six samples were taken, as outlined below.

| <b>Kern River</b> |                    |           |                   | air temp | source temp |
|-------------------|--------------------|-----------|-------------------|----------|-------------|
| OF-1              | gage tank (AWT143) | headspace | roof hatch        | 33° C    | 72° C       |
| OF-2              | well 406           | bag valve |                   | 35° C    | 100° C      |
| OF-3              | well 406           | bag valve | duplicate of OF 2 | 35° C    | 100° C      |
| OF-4              | shipping tank #40  | headspace | roof hatch        | 35° C    | 69° C       |
| OF-5              | surge tank         | headspace | roof hatch        | 35° C    | 36° C       |
| OF-6              | well 271           | bag valve | well duplicate    | 36° C    | 100° C      |

### 2. Elk Hills field

Sampling at this site was conducted on July 17, 1989. Two producing zones were sampled. The SOZ zone has an API gravity of 22-25°; the deeper Stevens zone contains oil in the range of 30-35° API. The waterflood method is used for recovery in most of the field. A small scale steamflood project was also operating at that time. Seven samples were taken, as outlined below.

| <b>Elk Hills</b> |                   |                      |                                | air temp | source temp |
|------------------|-------------------|----------------------|--------------------------------|----------|-------------|
| OF-10            | tank 11105        | bag sampling port    | headspace                      | 29° C    | 29° C       |
| OF-11            | compressor FR1364 | canister direct      | vapor recovery: NPT connection | 33° C    | 33° C       |
| OF-12            | separator 11044   |                      |                                | 30° C    | 30° C       |
| OF-13            | tank 11470        | same as OF-10        | Stevens zone                   | 36° C    | 36° C       |
| OF-14            | separator 14255   |                      |                                | 36° C    | 44° C       |
| OF-15            | tank 14217        | bag sampling port    | headspace                      | 35° C    | 35° C       |
| OF-16            | tank 53579        | bag 2" sampling port | steamflood operation           | 33° C    | 33° C       |
| OF-17            | test separator    | bag meter valve      | steamflood produced gas        | 33° C    | 46° C       |

### 3. Belridge Field

Sampling was performed on July 24, 1989. Light, medium and heavy crude is produced in this field. Eight samples originating from light crude of 33° API gravity, a medium crude of 26-28° and a heavy crude of 13° gravity were taken. A portion of recovery is by waterflood, with the balance being primary production. Samples taken are described in the following table.

| Belridge |               |                 |                         | air temp | source temp |
|----------|---------------|-----------------|-------------------------|----------|-------------|
| OF-20    | tank LOTS 201 | canister direct | 20 well composite vapor | 34° C    | 34° C       |
| OF-21    | well 548G-34  | bag valve       | casing gas              | 33° C    | 39° C       |
| OF-22    | tank LOTS 209 | canister direct | 1/4 NPT gauge port      | 37° C    | 37° C       |
| OF-23    | well 551-A33  | gas valve       | casing gas              | 35° C    | 37° C       |
| OF-24    | tank LOHF     | canister direct | 20 LOTS composite       | 35° C    | 35° C       |
| OF-25    | tank DEHY #27 | canister direct | heavy field composite   | 36° C    | 36° C       |
| OF-26    | tank HOTS 113 | bag valve port  | 50 well heavy composite | 37° C    | 110° C      |
| OF-27    | tank HOTS 192 | bag valve port  | 50 well heavy composite | 39° C    | 71° C       |

### 4. Cat Canyon Field

A pre-sampling visit was arranged for July 21, 1989. Sampling plans were discussed with Union Oil personnel, and facilities were toured. A sump was identified for testing. The sampling date was set for August 8. The field produces heavy crude, with an average API gravity of 14°. A total of 5 samples were obtained, as outlined below. Dr. Robert Grant (ARB) was present for this sampling episode.

| Cat Canyon |                  |              |                        | air temp | source temp |
|------------|------------------|--------------|------------------------|----------|-------------|
| OF-40      | well 53          | bag valve    | casing gas             | 28° C    | 28° C       |
| OF-41      | well 53          | bag valve    | tubing gas             | 22° C    | 22° C       |
| OF-42      | vapor recovery   | bag valve    | composite of all tanks | 27° C    | 27° C       |
| OF-43      | sump, inlet end  | flux chamber |                        | 30° C    | 39° C       |
| OF-44      | sump, outlet end | flux chamber |                        | 32° C    | 43° C       |

### 5. Ventura Field

Texaco's Ventura Avenue Field was sampled on August 11, 1989. The field produces 28-30° gravity oil, by waterflood recovery. Four samples were obtained, as outlined below.

| Ventura |                |                 |                    | air temp | source temp |
|---------|----------------|-----------------|--------------------|----------|-------------|
| OF-50   | tank           | bag valve       | 100 well composite | 25° C    | 40° C       |
| OF-51   | well L-131     | bag valve       | casing gas         | 22° C    | 27° C       |
| OF-52   | vapor recovery | canister direct | field composite    | 27° C    | 41° C       |
| OF-53   | vapor recovery | canister direct | shipping tank      | 30° C    | 35° C       |

## 6. Wilmington Field

Sampling was conducted at THUMS Pier J location on August 28, 1989. A secondary sump was sampled here, using the flux chamber described earlier. The pontoon system was not used. A 4' x 8' section of the sump covering was removed, and the flux chamber was lowered to the surface with a rope. Four samples were obtained at this location, as shown below. Average field gravity was 17.5° API.

| Wilmington |              |                 |            | air temp | source temp |
|------------|--------------|-----------------|------------|----------|-------------|
| OF-60      | Pier J sump  | flux chamber    |            | 18° C    | 34° C       |
| OF-61      | tank TK 003  | headspace       | roof hatch | 24° C    | 37° C       |
| OF-62      | FWKO tank #3 | canister direct |            | 23° C    | 26° C       |
| OF-63      | well J-341   | bag valve       | casing gas | 24° C    | 26° C       |

## 7. West Coyote Field

Sampling was conducted on August 28, 1989. This field produces crude oil in the 26-30° gravity range. Waterflood is the method of recovery. No heat treating is performed at this facility. Four samples were obtained, as shown below.

| West Coyote |                |           |                      | air temp | source temp |
|-------------|----------------|-----------|----------------------|----------|-------------|
| OF-70       | AWT tank 105   | bag valve |                      | 30° C    | 32° C       |
| OF-71       | work tank #1   | headspace | roof vent            | 34° C    | 40° C       |
| OF-72       | stock tank     | bag port  | manometer port       | 34° C    | 34° C       |
| OF-73       | vapor recovery | bag valve | field vapor recovery | 31° C    | 32° C       |

## 8. Other

The Union Oil HS&P facility supporting Platform Irene production was visited on May 19, 1989. This facility was recently built, and contains state-of-the-art emission controls. No readily accessible sampling points were available. This facility was not sampled.

On June 2, 1989, the San Ardo field was visited. A facility tour was conducted, and revealed very high H<sub>2</sub>S concentrations (in excess of 10,000 PPM) at most sampling locations. The operators (Texaco) indicated that self-contained breathing apparatus (SCBA) would be required for sampling. This site was omitted from further consideration. The Cat Canyon field satisfied the Coastal Crude sampling requirements.

## G. Format For Results

The analytical results are reported in a format illustrated by Table 6. The concentrations of all integrated peaks in the original sample were initially converted to mg/m<sup>3</sup>. These concentrations were summed with the methane concentration (expressed in mg/m<sup>3</sup>) and results were converted to a percentage of this total (expressed as % by mass). For most samples, the high resolution capillary column provided as many as several hundred resolvable peaks, as shown in Figure 18. Not all of these peaks could be positively identified. To aid in interpretation, each chromatogram was divided into regions bounded by a normal hydrocarbon., as shown in Figure 19. This



classification scheme results in assigning all unknown peaks as  $C_n$  if they appear between normal  $C_n$  and  $C_{n+1}$  hydrocarbons. By this method,  $C_5$  hydrocarbons are defined as having retention times between n-pentane and n-hexane. Another way of looking at this classification is based on the Kovats Retention Index (KRI). A compound listed as "OTHER  $C_n$ " will have a KRI between  $100 \cdot n$  and  $100 \cdot (n+1)$ . Those chromatographic peaks which could not be positively identified were placed in a carbon number category by this method. **It is important to note that these are operational definitions, and do not represent the actual number of carbon atoms in a given component.** Branching of a hydrocarbon tends to make it more volatile than its straight-chain homolog. Thus, unidentified branched hydrocarbons with n carbons will usually be assigned to the  $C_{n-1}$  carbon range.

Table 6- Format for Oil Field Results

## Hydrocarbon Species by % Mass

|                        | OF-63   |
|------------------------|---------|
| Methane                | 9.3724  |
| Ethane                 | 8.6278  |
| Propane                | 3.7709  |
| i-Butane               | 7.6645  |
| n-Butane               | 14.2861 |
| 2,2-dimethylpropane    | 0.1059  |
| i-Pentane              | 8.6462  |
| n-Pentane              | 5.4645  |
| 2,2-Dimethylbutane     | 0.1539  |
| Cyclopentane           | 0.5612  |
| 2,3-Dimethylbutane     | 0.0000  |
| 2-Methylpentane        | 2.6425  |
| 3-Methylpentane        | 1.9294  |
| n-Hexane               | 1.9154  |
| Methylcyclopentane     | 3.1383  |
| 2,4-Dimethylpentane    | 0.1542  |
| Benzene                | 0.5559  |
| Cyclohexane            | 0.0316  |
| 2-Methylhexane         | 0.5707  |
| 2,3-Dimethylpentane    | 0.5102  |
| 3-Methylhexane         | 0.8294  |
| n-Heptane              | 1.0401  |
| Methylcyclohexane      | 2.0397  |
| 2,4-Dimethylhexane     | 0.1030  |
| 2,3,4-Trimethylpentane | 0.0523  |
| Toluene                | 0.1805  |
| 2,3-Dimethylhexane     | 0.0840  |
| 2-Methylheptane        | 0.6672  |
| 3-Ethylhexane          | 0.3136  |
| n-Octane               | 0.6727  |
| Ethylbenzene           | 0.5052  |
| p-Xylene               | 0.0000  |
| m-Xylene               | 0.5832  |
| o-Xylene               | 0.2485  |
| n-Nonane               | 0.3525  |
| i-Propylbenzene        | 0.0516  |
| n-Propylbenzene        | 0.1527  |
| 3-Ethyltoluene         | 0.1630  |
| 1,3,5-Trimethylbenzene | 0.1066  |
| 2-Ethyltoluene         | 0.0694  |
| t-butylbenzene         | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.2217  |
| i-butylbenzene         | 0.0500  |
| s-butylbenzene         | 0.0608  |
| n-Decane               | 0.0000  |
| 1,2,3-Trimethylbenzene | 0.1393  |
| 1,3-Diethylbenzene     | 0.0486  |
| 1,4-Diethylbenzene     | 0.0457  |
| n-butylbenzene         | 0.0000  |
| 1,2-diethylbenzene     | 0.0000  |
| n-undecane             | 0.0000  |
| Other C4               | 0.0000  |
| Other C5               | 0.9634  |
| Other C6               | 5.6426  |
| Other C7               | 5.4870  |
| Other C8               | 5.4826  |
| Other C9               | 2.7415  |
| Other C10              | 0.6598  |
| Other C11              | 0.1404  |

## H. Results

Hydrocarbon speciation information is arranged by oil field. Tables 7 through 13 contain results for all samples listed in Table 6. Additionally, these data were organized into a LOTUS 1-2-3 database. The format of the database is actually the transpose of the results shown in Tables 7-13. Compound names are column headings (fields), and sample numbers are rows (records). A portion of the database is shown in Table 14. A copy of the database, named OF\_SUMRY.WK1, was copied to a 3.5 inch floppy disk, and sent to ARB along with this report.

Figure 18- Representative Chromatogram




Figure 19 - Hydrocarbon Classification by Carbon Number

TIMETABLE STOP

Error storing signal to M:SIGNAL .BNC  
ATTEMPTED WRITE PAST END OF FILE

RUN# 176 JUL 18, 1989 08:53:33

| AREA#          | RT     | AREA | TYPE | WIDTH | AREA%   |          |
|----------------|--------|------|------|-------|---------|----------|
|                | 9.387  | 528  | VP   | .053  | .15155  |          |
|                | 12.054 | 643  | VP   | .097  | .19456  |          |
|                | 21.567 | 1875 | VV   | .048  | .53817  |          |
|                | 24.438 | 1876 | PV   | .057  | .38884  |          |
|                | 33.467 | 1040 | BP   | .060  | .29050  |          |
| C <sub>7</sub> | 38.035 | 1261 | BP   | .063  | .36194  |          |
|                | 38.882 | 581  | PV   | .069  | .16676  |          |
|                | 39.416 | 3179 | BP   | .069  | .91244  |          |
|                | 40.810 | 628  | VV   | .075  | .18825  |          |
|                | 40.211 | 887  | VV   | .069  | .23163  |          |
|                | 42.100 | 559  | PV   | .098  | .16845  |          |
|                | 42.295 | 2904 | VV   | .068  | .83351  |          |
|                | 42.540 | 898  | VV   | .067  | .25545  |          |
|                | 43.840 | 928  | BP   | .067  | .22765  |          |
|                | 44.384 | 5823 | PV   | .067  | 1.67133 | n-octane |
|                | 45.019 | 2530 | VV   | .069  | .72617  |          |
|                | 45.301 | 873  | VV   | .098  | .25857  |          |
|                | 45.470 | 1953 | VV   | .079  | .56855  |          |
|                | 45.668 | 925  | VV   | .078  | .26550  |          |
|                | 46.400 | 917  | VV   | .115  | .26320  |          |
|                | 46.593 | 863  | VV   | .079  | .24770  |          |
|                | 46.834 | 1303 | VV   | .074  | .37399  |          |
|                | 47.081 | 1937 | VV   | .080  | .55596  |          |
| C <sub>8</sub> | 47.296 | 1757 | VV   | .082  | .58438  |          |
|                | 47.516 | 1286 | VP   | .081  | .36911  |          |
|                | 47.864 | 585  | BH   | .075  | .16791  |          |
|                | 48.212 | 6338 | HH   | .080  | 1.58884 | ETYL     |
|                | 48.498 | 832  | HH   | .107  | .23880  |          |
|                | 49.082 | 1594 | HH   | .090  | .45751  |          |
|                | 49.194 | 1239 | HH   | .090  | .35562  |          |
|                | 49.557 | 2624 | HH   | .095  | .75315  |          |
|                | 49.820 | 534  | HH   | .096  | .15327  |          |
|                | 49.984 | 2571 | HH   | .107  | .73793  |          |
|                | 50.245 | 2003 | HH   | .115  | .57491  |          |
|                | 50.595 | 2042 | HH   | .137  | .58610  |          |
|                | 50.680 | 1676 | HH   | .081  | .48185  |          |
|                | 50.926 | 5369 | HH   | .143  | 1.54182 |          |
|                | 51.183 | 664  | HH   | .071  | .19058  | 11192    |
|                | 51.286 | 1056 | HH   | .127  | .53271  |          |
|                | 51.731 | 2255 | HH   | .081  | .64724  |          |
|                | 51.815 | 3703 | HH   | .088  | 1.06284 |          |
|                | 52.005 | 1612 | HH   | .112  | .46268  |          |
|                | 52.239 | 6078 | HH   | .104  | 1.74452 |          |
|                | 52.637 | 1438 | HH   | .099  | .41274  |          |
|                | 53.009 | 2926 | HH   | .103  | .83983  |          |
| C <sub>9</sub> | 53.118 | 4369 | HH   | .138  | 1.25488 |          |
|                | 53.405 | 813  | HH   | .087  | .23335  |          |
|                | 53.526 | 2925 | HH   | .114  | .83954  |          |
|                | 53.741 | 7882 | HH   | .131  | 2.26231 |          |
|                | 54.022 | 5077 | HH   | .094  | 1.45721 |          |
|                | 54.186 | 3848 | HH   | .104  | 1.10446 |          |
|                | 54.288 | 2584 | HH   | .092  | .71878  |          |
|                | 54.525 | 2335 | HH   | .102  | .67028  |          |
|                | 54.640 | 1880 | HH   | .110  | .53960  |          |
|                | 54.958 | 3235 | HH   | .168  | .92852  |          |
|                | 55.111 | 2215 | HH   | .116  | .63575  |          |

**Data Summaries Follow**

Table 7 - Kern River Summary Hydrocarbon Species by % Mass

|                        | OF-01   | OF-02   | OF-03   | OF-04   | OF-05   | OF-06   |
|------------------------|---------|---------|---------|---------|---------|---------|
| Methane                | 0.1616  | 81.3998 | 62.0949 | 60.7789 | 95.9289 | 4.4862  |
| Ethane                 | 0.0931  | 0.1565  | 0.1214  | 1.3946  | 0.2717  | 0.4191  |
| Propane                | 0.1499  | 0.0955  | 0.0781  | 0.3922  | 0.0716  | 0.3025  |
| i-Butane               | 0.0000  | 0.0647  | 0.0531  | 0.1601  | 0.0542  | 0.3003  |
| n-Butane               | 0.1825  | 0.0842  | 0.0684  | 0.0914  | 0.0352  | 0.2139  |
| 2,2-dimethylpropane    | 0.0000  | 0.3083  | 0.2510  | 0.6376  | 0.1440  | 0.3897  |
| i-Pentane              | 0.0000  | 0.1803  | 0.1558  | 0.1549  | 0.0434  | 0.4758  |
| n-Pentane              | 0.0000  | 0.0321  | 0.0250  | 0.0234  | 0.0066  | 0.0696  |
| 2,2-Dimethylbutane     | 0.5323  | 0.3794  | 0.3487  | 0.2715  | 0.0599  | 0.9194  |
| Cyclopentane           | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.1704  | 0.0000  |
| 2,3-Dimethylbutane     | 0.3055  | 1.3302  | 1.2881  | 0.8293  | 0.0000  | 2.9941  |
| 2-Methylpentane        | 0.0000  | 0.0203  | 0.0174  | 0.0025  | 0.0000  | 0.0637  |
| 3-Methylpentane        | 0.0000  | 0.0737  | 0.0712  | 0.0696  | 0.0093  | 0.2005  |
| n-Hexane               | 0.0724  | 0.0194  | 0.0082  | 0.3656  | 0.0000  | 0.0370  |
| Methylcyclopentane     | 0.0000  | 0.0121  | 0.1412  | 0.0153  | 0.0000  | 0.3065  |
| 2,4-Dimethylpentane    | 0.0931  | 0.2317  | 0.2654  | 0.1847  | 0.0341  | 0.6060  |
| Benzene                | 0.1318  | 0.0137  | 0.0000  | 0.2571  | 0.0000  | 0.0177  |
| Cyclohexane            | 0.0000  | 0.1322  | 0.1564  | 0.1040  | 0.0000  | 0.3697  |
| 2-Methylhexane         | 0.2952  | 0.6399  | 0.7923  | 0.4250  | 0.0902  | 0.0281  |
| 2,3-Dimethylpentane    | 0.0000  | 0.0000  | 0.0000  | 0.0338  | 0.0088  | 2.0899  |
| 3-Methylhexane         | 0.0000  | 0.0223  | 0.0228  | 0.0332  | 0.0000  | 0.0844  |
| n-Heptane              | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Methylcyclohexane      | 0.0000  | 0.0158  | 0.0169  | 0.0162  | 0.0000  | 0.1434  |
| 2,4-Dimethylhexane     | 0.1649  | 0.1780  | 0.2580  | 0.1924  | 0.0000  | 0.6607  |
| 2,3,4-Trimethylpentane | 0.2291  | 0.1985  | 0.2951  | 0.2434  | 0.0341  | 0.6631  |
| Toluene                | 0.1059  | 0.0800  | 0.1192  | 0.1048  | 0.0141  | 0.2593  |
| 2,3-Dimethylhexane     | 0.0000  | 0.0466  | 0.0566  | 0.1007  | 0.0170  | 0.1882  |
| 2-Methylheptane        | 0.0000  | 0.0298  | 0.0513  | 0.0196  | 0.0115  | 0.0592  |
| 3-Ethylhexane          | 0.1587  | 0.1108  | 0.1775  | 0.9907  | 0.0154  | 0.5925  |
| n-Octane               | 1.6531  | 0.8900  | 1.4281  | 1.1606  | 0.0000  | 1.2543  |
| Ethylbenzene           | 1.4534  | 0.4798  | 0.7963  | 0.6379  | 0.1166  | 0.4558  |
| p-Xylene               | 0.0384  | 0.0155  | 0.0250  | 0.0187  | 0.0000  | 0.1605  |
| m-Xylene               | 0.0573  | 0.0091  | 0.0096  | 0.0393  | 0.0000  | 0.0462  |
| o-Xylene               | 0.5676  | 0.1397  | 0.2040  | 0.2463  | 0.0432  | 0.8641  |
| n-Nonane               | 0.5269  | 0.0804  | 0.1463  | 0.0154  | 0.0000  | 0.7433  |
| i-Propylbenzene        | 0.3997  | 0.0751  | 0.1261  | 0.0649  | 0.0157  | 0.2696  |
| n-Propylbenzene        | 0.5226  | 0.0704  | 0.1432  | 0.2459  | 0.0000  | 0.5119  |
| 3-Ethyltoluene         | 0.6157  | 0.0754  | 0.0701  | 0.3010  | 0.0459  | 0.2927  |
| 1,3,5-Trimethylbenzene | 1.1485  | 0.1059  | 0.2325  | 0.3917  | 0.0460  | 0.6053  |
| 2-Ethyltoluene         | 1.0170  | 0.1053  | 0.2072  | 0.4058  | 0.0187  | 0.6919  |
| t-butylbenzene         | 1.4128  | 0.1515  | 0.2642  | 0.2284  | 0.0781  | 0.6499  |
| 1,2,4-Trimethylbenzene | 1.8178  | 0.1777  | 0.3203  | 0.0673  | 0.0000  | 0.1576  |
| i-butylbenzene         | 0.6893  | 0.0000  | 0.0000  | 0.4387  | 0.0000  | 0.0000  |
| s-butylbenzene         | 1.5427  | 0.1154  | 0.2455  | 0.0827  | 0.0000  | 0.4963  |
| n-Decane               | 0.9377  | 0.0767  | 0.1528  | 0.0000  | 0.0255  | 0.3824  |
| 1,2,3-Trimethylbenzene | 1.2611  | 0.1167  | 0.2233  | 0.3045  | 0.0485  | 0.5393  |
| 1,3-Diethylbenzene     | 1.5037  | 0.0883  | 0.2133  | 0.3182  | 0.0000  | 0.3418  |
| 1,4-Diethylbenzene     | 1.2994  | 0.0874  | 0.2261  | 0.2255  | 0.0212  | 0.3497  |
| n-butylbenzene         | 1.0621  | 0.0273  | 0.1696  | 0.0000  | 0.0000  | 0.1890  |
| 1,2-diethylbenzene     | 0.9061  | 0.0729  | 0.1544  | 0.2284  | 0.0121  | 0.4960  |
| n-undecane             | 0.0000  | 0.0000  | 0.1151  | 0.0000  | 0.0000  | 0.0089  |
| Other C4               | 0.0000  | 0.0000  | 0.0000  | 0.1460  | 0.0000  | 0.0000  |
| Other C5               | 0.0000  | 0.0000  | 0.0000  | 0.0566  | 0.0000  | 0.0000  |
| Other C6               | 0.0000  | 0.6617  | 0.7074  | 0.6329  | 0.0000  | 3.0064  |
| Other C7               | 2.7537  | 2.7837  | 4.5832  | 2.6022  | 0.4848  | 21.5246 |
| Other C8               | 9.6620  | 3.1244  | 5.1639  | 5.9405  | 0.7901  | 22.4750 |
| Other C9               | 24.3261 | 2.7101  | 5.6391  | 10.3142 | 0.8362  | 19.7780 |
| Other C10              | 30.0711 | 1.8284  | 6.0923  | 6.6704  | 0.3693  | 6.7337  |
| Other C11              | 10.0782 | 0.0751  | 5.4074  | 0.3234  | 0.0275  | 0.0353  |

Table 8 - Elk Hills Summary

## Hydrocarbon Species by % Mass

|                        | OF-10   | OF-11   | OF-12   | OF-13   | OF-14   | OF-15   | OF-16   | OF-17   |
|------------------------|---------|---------|---------|---------|---------|---------|---------|---------|
| Methane                | 44.8895 | 37.7408 | 33.4312 | 11.8005 | 31.9680 | 19.4226 | 35.1586 | 26.7810 |
| Ethane                 | 7.9019  | 7.6800  | 12.7717 | 9.5479  | 15.4250 | 8.4997  | 3.7104  | 7.5402  |
| Propane                | 13.0885 | 14.8836 | 17.2663 | 17.0718 | 17.7471 | 15.3786 | 12.6201 | 14.1825 |
| i-Butane               | 3.1748  | 3.3993  | 3.4171  | 5.7194  | 3.8778  | 4.2802  | 3.2037  | 5.0340  |
| n-Butane               | 10.3318 | 6.7414  | 10.8072 | 17.3072 | 11.4358 | 3.3683  | 15.2084 | 13.2046 |
| 2,2-dimethylpropane    | 0.1106  | 0.1170  | 0.1195  | 0.0427  | 0.1169  | 0.6509  | 0.1633  | 0.0420  |
| i-Pentane              | 2.8767  | 1.5246  | 3.3797  | 2.0964  | 3.6524  | 1.6843  | 1.8193  | 4.4784  |
| n-Pentane              | 2.7182  | 1.4220  | 3.3991  | 3.2146  | 3.4792  | 1.5078  | 3.5079  | 3.0220  |
| 2,2-Dimethylbutane     | 0.1824  | 0.1976  | 0.1976  | 0.0925  | 0.1790  | 0.0966  | 0.3145  | 0.0877  |
| Cyclopentane           | 0.4262  | 0.4740  | 0.4656  | 0.2939  | 0.4103  | 0.1599  | 0.7297  | 0.2727  |
| 2,3-Dimethylbutane     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 2-Methylpentane        | 1.0121  | 1.1492  | 0.9909  | 1.7049  | 0.9906  | 1.0162  | 0.5465  | 1.2021  |
| 3-Methylpentane        | 0.6783  | 0.7795  | 0.6824  | 1.6037  | 0.1099  | 0.0000  | 0.4636  | 1.4428  |
| n-Hexane               | 1.0797  | 1.2686  | 1.0330  | 3.2012  | 0.9704  | 2.4788  | 0.8823  | 2.3533  |
| Methylcyclopentane     | 1.5561  | 1.9090  | 1.7244  | 2.7693  | 1.5368  | 1.4020  | 3.0811  | 2.4687  |
| 2,4-Dimethylpentane    | 0.0000  | 0.1213  | 0.1125  | 0.0910  | 0.0928  | 0.0923  | 0.1934  | 0.0791  |
| Benzene                | 0.0799  | 0.0912  | 0.0694  | 0.4320  | 0.0674  | 0.4661  | 0.0287  | 0.2989  |
| Cyclohexane            | 0.0255  | 0.0307  | 0.0293  | 0.0000  | 0.0237  | 0.0177  | 0.0486  | 0.0164  |
| 2-Methylhexane         | 0.2065  | 0.2603  | 0.2276  | 0.4923  | 0.1838  | 0.4907  | 0.1631  | 0.3990  |
| 2,3-Dimethylpentane    | 0.2107  | 0.2603  | 0.2397  | 0.2208  | 0.1905  | 0.2270  | 0.4335  | 0.1875  |
| 3-Methylhexane         | 0.2814  | 0.3573  | 0.2411  | 0.6209  | 0.2522  | 0.0000  | 0.3197  | 0.5050  |
| n-Heptane              | 0.3279  | 0.4367  | 0.3039  | 1.0452  | 0.2691  | 1.0439  | 0.1562  | 0.7316  |
| Methylcyclohexane      | 0.8685  | 1.1612  | 1.0033  | 1.3402  | 0.7933  | 1.3160  | 2.2377  | 1.1241  |
| 2,4-Dimethylhexane     | 0.1520  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0851  | 0.1298  |
| 2,3,4-Trimethylpentane | 0.3075  | 0.0000  | 0.3843  | 0.0000  | 0.0343  | 0.0163  | 0.0302  | 0.0124  |
| Toluene                | 0.1012  | 0.1382  | 0.0864  | 0.4755  | 0.0771  | 0.4887  | 0.0738  | 0.2453  |
| 2,3-Dimethylhexane     | 0.0000  | 0.0323  | 0.0273  | 0.0257  | 0.0000  | 0.0277  | 0.0548  | 0.0197  |
| 2-Methylheptane        | 0.0924  | 0.1416  | 0.0945  | 0.0000  | 0.0185  | 0.0000  | 0.0000  | 0.1889  |
| 3-Ethylhexane          | 0.0000  | 0.0825  | 0.0333  | 0.0000  | 0.0438  | 0.1267  | 0.0372  | 0.0000  |
| n-Octane               | 0.1923  | 0.3093  | 0.2305  | 0.2394  | 0.1645  | 0.2901  | 0.3371  | 0.1331  |
| Ethylbenzene           | 0.0741  | 0.1219  | 0.0938  | 0.0619  | 0.0506  | 0.0976  | 0.2080  | 0.0386  |
| p-Xylene               | 0.0195  | 0.0545  | 0.0310  | 0.0306  | 0.0207  | 0.0520  | 0.0467  | 0.0208  |
| m-Xylene               | 0.0311  | 0.0333  | 0.0210  | 0.1080  | 0.0302  | 0.1659  | 0.0572  | 0.0462  |
| o-Xylene               | 0.0221  | 0.0378  | 0.0258  | 0.0325  | 0.0183  | 0.0545  | 0.0504  | 0.0160  |
| n-Nonane               | 0.0260  | 0.0241  | 0.0186  | 0.0471  | 0.0281  | 0.0931  | 0.0408  | 0.0210  |
| i-Propylbenzene        | 0.0078  | 0.0000  | 0.0034  | 0.0000  | 0.0045  | 0.0071  | 0.0000  | 0.0000  |
| n-Propylbenzene        | 0.0190  | 0.0138  | 0.0110  | 0.0000  | 0.0125  | 0.0177  | 0.0000  | 0.0000  |
| 3-Ethyltoluene         | 0.0169  | 0.0107  | 0.0093  | 0.0000  | 0.0050  | 0.0000  | 0.0000  | 0.0000  |
| 1,3,5-Trimethylbenzene | 0.0137  | 0.0000  | 0.0000  | 0.0000  | 0.0092  | 0.0000  | 0.0000  | 0.0000  |
| 2-Ethyltoluene         | 0.0000  | 0.0097  | 0.0087  | 0.0000  | 0.0066  | 0.0000  | 0.0000  | 0.0000  |
| t-butylbenzene         | 0.0000  | 0.0115  | 0.0101  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.0350  | 0.0000  | 0.0055  | 0.0000  | 0.0000  | 0.0381  | 0.0000  | 0.0000  |
| i-butylbenzene         | 0.0000  | 0.0000  | 0.0049  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| s-butylbenzene         | 0.0000  | 0.0072  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-Decane               | 0.0075  | 0.0094  | 0.0064  | 0.0000  | 0.0041  | 0.0194  | 0.0451  | 0.0000  |
| 1,2,3-Trimethylbenzene | 0.0289  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 1,3-Diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 1,4-Diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-butylbenzene         | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 1,2-diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0380  | 0.0000  | 0.0000  |
| n-undecane             | 0.0065  | 0.0000  | 0.0000  | 0.0000  | 0.0092  | 0.0000  | 0.0000  | 0.0000  |
| Other C4               | 0.5783  | 6.1069  | 0.0000  | 5.2441  | 0.0577  | 13.7463 | 0.0000  | 2.5913  |
| Other C5               | 1.4612  | 3.0812  | 0.7107  | 6.5695  | 1.3404  | 9.1198  | 1.2993  | 6.2761  |
| Other C6               | 2.2153  | 3.3493  | 3.1000  | 3.6424  | 1.9094  | 6.4305  | 6.2250  | 3.0361  |
| Other C7               | 1.3296  | 2.3796  | 1.5896  | 2.0599  | 1.3557  | 4.3198  | 3.7814  | 1.2699  |
| Other C8               | 0.7813  | 1.3165  | 1.0459  | 0.6321  | 0.6379  | 0.9180  | 1.9979  | 0.4258  |
| Other C9               | 0.3196  | 0.6090  | 0.4462  | 0.1228  | 0.2824  | 0.3332  | 0.6220  | 0.0753  |
| Other C10              | 0.1121  | 0.1073  | 0.0851  | 0.0000  | 0.0975  | 0.0000  | 0.0177  | 0.0000  |
| Other C11              | 0.0219  | 0.0068  | 0.0040  | 0.0000  | 0.0098  | 0.0000  | 0.0000  | 0.0000  |



Table 9 - Belridge Summary

## Hydrocarbon Species by % Mass

|                        | OF-20   | OF-21   | OF-22   | OF-23   | OF-24   | OF-25   | OF-26   | OF-27   |
|------------------------|---------|---------|---------|---------|---------|---------|---------|---------|
| Methane                | 0.6309  | 47.8262 | 44.8636 | 45.7334 | 25.6069 | 2.7544  | 95.9626 | 98.1996 |
| Ethane                 | 13.8534 | 10.1622 | 6.8113  | 9.2589  | 7.9440  | 5.4703  | 0.5781  | 0.6958  |
| Propane                | 20.3860 | 13.5873 | 10.3987 | 13.3879 | 16.7611 | 4.5376  | 0.1836  | 0.1861  |
| i-Butane               | 1.9291  | 2.7121  | 2.5031  | 3.0755  | 4.2843  | 2.1106  | 0.0375  | 0.0213  |
| n-Butane               | 17.5464 | 7.7710  | 8.2760  | 9.7694  | 14.0011 | 6.6176  | 0.1228  | 0.0335  |
| 2,2-dimethylpropane    | 0.0456  | 0.0203  | 0.0185  | 0.0251  | 0.0415  | 0.2065  | 0.0794  | 0.0554  |
| i-Pentane              | 5.9460  | 2.9425  | 3.5109  | 3.7319  | 5.0878  | 5.3812  | 0.0535  | 0.0080  |
| n-Pentane              | 8.3204  | 3.3931  | 3.9112  | 3.8510  | 5.6848  | 4.3558  | 0.0456  | 0.0079  |
| 2,2-Dimethylbutane     | 0.0964  | 0.0438  | 0.0407  | 0.0409  | 0.0828  | 0.2502  | 0.0000  | 0.0050  |
| Cyclopentane           | 0.0000  | 0.0000  | 0.1801  | 0.1537  | 0.2917  | 0.6577  | 0.0000  | 0.0000  |
| 2,3-Dimethylbutane     | 0.3293  | 0.1474  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0191  | 0.0011  |
| 2-Methylpentane        | 1.7627  | 1.0353  | 1.3757  | 1.1674  | 1.0834  | 2.1277  | 0.0223  | 0.0031  |
| 3-Methylpentane        | 1.6061  | 0.6445  | 0.9477  | 0.7538  | 1.0913  | 1.4123  | 0.0000  | 0.0000  |
| n-Hexane               | 3.0647  | 1.1569  | 1.5742  | 1.1753  | 1.9673  | 2.3156  | 0.0206  | 0.0038  |
| Methylcyclopentane     | 3.4631  | 0.0164  | 0.0160  | 0.0137  | 2.8540  | 2.5628  | 0.0057  | 0.0000  |
| 2,4-Dimethylpentane    | 0.1121  | 0.0442  | 0.0595  | 0.0414  | 0.0880  | 0.2350  | 0.0000  | 0.0000  |
| Benzene                | 0.3862  | 0.1231  | 0.0872  | 0.0919  | 0.1998  | 0.2686  | 0.0000  | 0.0050  |
| Cyclohexane            | 0.0219  | 0.0085  | 0.0109  | 0.0075  | 0.0177  | 0.0000  | 0.0000  | 0.0000  |
| 2-Methylhexane         | 0.5507  | 0.1767  | 0.3242  | 0.0000  | 0.3533  | 0.6553  | 0.0000  | 0.0000  |
| 2,3-Dimethylpentane    | 0.3258  | 0.1429  | 0.2174  | 0.2020  | 0.2560  | 0.9489  | 0.0051  | 0.0000  |
| 3-Methylhexane         | 0.0000  | 0.2271  | 0.4621  | 0.2817  | 0.4480  | 0.9310  | 0.0000  | 0.0000  |
| n-Heptane              | 1.2952  | 0.3164  | 0.7085  | 0.3518  | 0.7147  | 1.3600  | 0.0000  | 0.0009  |
| Methylcyclohexane      | 0.1831  | 0.0000  | 0.0000  | 0.0840  | 0.0000  | 0.4621  | 0.0000  | 0.0012  |
| 2,4-Dimethylhexane     | 0.0550  | 0.1227  | 0.0364  | 0.1121  | 0.0376  | 0.2385  | 0.0061  | 0.0000  |
| 2,3,4-Trimethylpentane | 0.0309  | 0.2526  | 0.5542  | 0.2322  | 0.0216  | 0.3665  | 0.0799  | 0.0027  |
| Toluene                | 0.5882  | 0.0236  | 0.3102  | 0.1370  | 0.3313  | 0.4900  | 0.0000  | 0.0038  |
| 2,3-Dimethylhexane     | 0.0456  | 0.0175  | 0.0310  | 0.0137  | 0.0275  | 0.1998  | 0.0000  | 0.0000  |
| 2-Methylheptane        | 0.4294  | 0.0236  | 0.0439  | 0.0197  | 0.2050  | 0.7450  | 0.0078  | 0.0000  |
| 3-Ethylhexane          | 0.1786  | 0.0477  | 0.1203  | 0.0482  | 0.0935  | 0.3599  | 0.0000  | 0.0000  |
| n-Octane               | 0.4324  | 0.0814  | 0.0870  | 0.0351  | 0.0874  | 1.3665  | 0.0088  | 0.0039  |
| Ethylbenzene           | 0.1841  | 0.0755  | 0.1553  | 0.0472  | 0.0741  | 1.0917  | 0.0145  | 0.0051  |
| p-Xylene               | 0.0000  | 0.0045  | 0.1452  | 0.0592  | 0.0000  | 0.2763  | 0.0000  | 0.0046  |
| m-Xylene               | 0.2260  | 0.0334  | 0.0765  | 0.0250  | 0.0839  | 0.4733  | 0.0000  | 0.0000  |
| o-Xylene               | 0.0891  | 0.0056  | 0.0552  | 0.0220  | 0.0280  | 0.2783  | 0.0057  | 0.0035  |
| n-Nonane               | 0.1393  | 0.0186  | 0.0203  | 0.0370  | 0.0201  | 0.2195  | 0.0095  | 0.0074  |
| i-Propylbenzene        | 0.0000  | 0.0027  | 0.0034  | 0.0025  | 0.0039  | 0.0743  | 0.0000  | 0.0000  |
| n-Propylbenzene        | 0.0345  | 0.0234  | 0.0283  | 0.0061  | 0.0094  | 0.4000  | 0.0092  | 0.0064  |
| 3-Ethyltoluene         | 0.0133  | 0.0072  | 0.0116  | 0.0000  | 0.0093  | 0.2899  | 0.0211  | 0.0097  |
| 1,3,5-Trimethylbenzene | 0.0269  | 0.0057  | 0.0187  | 0.0041  | 0.0000  | 0.0000  | 0.0186  | 0.0116  |
| 2-Ethyltoluene         | 0.0258  | 0.0026  | 0.0182  | 0.0038  | 0.0036  | 0.1688  | 0.0118  | 0.0158  |
| t-butylbenzene         | 0.0143  | 0.0084  | 0.0132  | 0.0000  | 0.0000  | 0.2103  | 0.0000  | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.0066  | 0.0048  | 0.0046  | 0.0164  | 0.0042  | 0.4794  | 0.0000  | 0.0139  |
| i-butylbenzene         | 0.0058  | 0.0000  | 0.0042  | 0.0000  | 0.0000  | 0.0605  | 0.0101  | 0.0000  |
| s-butylbenzene         | 0.0074  | 0.0045  | 0.0045  | 0.0000  | 0.0021  | 0.0878  | 0.0000  | 0.0000  |
| n-Decane               | 0.0057  | 0.0011  | 0.0290  | 0.0112  | 0.0000  | 0.0599  | 0.0184  | 0.0244  |
| 1,2,3-Trimethylbenzene | 0.0054  | 0.0000  | 0.0000  | 0.0000  | 0.0051  | 0.0000  | 0.0490  | 0.0057  |
| 1,3-Diethylbenzene     | 0.0128  | 0.0000  | 0.0064  | 0.0000  | 0.0000  | 0.2104  | 0.0000  | 0.0015  |
| 1,4-Diethylbenzene     | 0.0000  | 0.0042  | 0.0095  | 0.0000  | 0.0038  | 0.2106  | 0.0192  | 0.0225  |
| n-butylbenzene         | 0.0078  | 0.0057  | 0.0049  | 0.0020  | 0.0000  | 0.0000  | 0.0000  | 0.0203  |
| 1,2-diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0041  |
| n-undecane             | 0.0000  | 0.0000  | 0.0093  | 0.0000  | 0.0000  | 0.0999  | 0.0219  | 0.0000  |
| Other C4               | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Other C5               | 2.8126  | 0.0000  | 0.6376  | 0.5484  | 1.6789  | 1.3806  | 0.0553  | 0.0126  |
| Other C6               | 6.9258  | 0.5288  | 5.9315  | 3.7219  | 4.2202  | 8.7054  | 0.0935  | 0.0171  |
| Other C7               | 3.0713  | 3.6994  | 2.9653  | 1.0916  | 3.0840  | 15.5060 | 0.1773  | 0.0106  |
| Other C8               | 1.8956  | 1.4513  | 1.6682  | 0.4752  | 0.9441  | 11.9369 | 0.6540  | 0.0655  |
| Other C9               | 0.7019  | 0.9881  | 0.6194  | 0.0943  | 0.1285  | 6.6643  | 0.8882  | 0.2110  |
| Other C10              | 0.1335  | 0.0484  | 0.0776  | 0.0302  | 0.0331  | 1.3815  | 0.5560  | 0.2885  |
| Other C11              | 0.0394  | 0.0092  | 0.0018  | 0.0056  | 0.0000  | 0.3470  | 0.1279  | 0.0000  |

Table 10 - Cat Canyon Summary Hydrocarbon Species by % Mass

| OF-40                  | OF-41   | OF-42   | OF-43   | OF-44   |         |
|------------------------|---------|---------|---------|---------|---------|
| Methane                | 40.6929 | 10.0741 | 8.0981  | 0.0000  | 0.0000  |
| Ethane                 | 8.8839  | 20.1940 | 1.5655  | 1.6118  | 0.0000  |
| Propane                | 14.1404 | 11.3004 | 4.9484  | 1.3702  | 0.0000  |
| i-Butane               | 3.1034  | 1.5022  | 4.5482  | 0.0000  | 1.0505  |
| n-Butane               | 8.2204  | 4.4444  | 16.7562 | 2.4984  | 0.0000  |
| 2,2-dimethylpropane    | 0.0114  | 0.0000  | 0.0443  | 0.0000  | 0.0000  |
| i-Pentane              | 2.8269  | 1.6489  | 18.5162 | 3.5461  | 4.3902  |
| n-Pentane              | 0.8501  | 1.6241  | 18.2855 | 4.3522  | 5.2835  |
| 2,2-Dimethylbutane     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Cyclopentane           | 0.2525  | 0.1323  | 0.0000  | 0.0000  | 1.0410  |
| 2,3-Dimethylbutane     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 2-Methylpentane        | 1.5351  | 0.6920  | 5.8657  | 4.0751  | 6.1335  |
| 3-Methylpentane        | 1.1323  | 0.6022  | 3.7394  | 0.0000  | 4.9084  |
| n-Hexane               | 1.7048  | 0.9060  | 4.8494  | 5.7627  | 6.6935  |
| Methylcyclopentane     | 1.1296  | 1.2395  | 2.9251  | 5.2924  | 5.9473  |
| 2,4-Dimethylpentane    | 0.0375  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Benzene                | 0.2509  | 1.8187  | 0.3463  | 9.1484  | 10.7339 |
| Cyclohexane            | 0.0000  | 0.0000  | 0.0122  | 0.0000  | 0.0000  |
| 2-Methylhexane         | 0.3618  | 0.2747  | 0.5003  | 0.0000  | 1.6592  |
| 2,3-Dimethylpentane    | 0.2302  | 0.1935  | 0.3006  | 0.0000  | 1.3305  |
| 3-Methylhexane         | 0.6061  | 0.5048  | 0.6828  | 0.0000  | 2.7133  |
| n-Heptane              | 0.9354  | 0.9240  | 0.7250  | 5.2258  | 3.2642  |
| Methylcyclohexane      | 0.6467  | 1.0305  | 0.5577  | 5.5640  | 3.2339  |
| 2,4-Dimethylhexane     | 0.0000  | 0.0461  | 0.0000  | 0.0000  | 1.0936  |
| 2,3,4-Trimethylpentane | 0.0155  | 0.0000  | 0.0075  | 0.0000  | 0.0000  |
| Toluene                | 0.4204  | 2.8143  | 0.1548  | 10.4338 | 6.7816  |
| 2,3-Dimethylhexane     | 0.0453  | 0.0744  | 0.0159  | 0.0000  | 0.0000  |
| 2-Methylheptane        | 0.3968  | 0.6905  | 0.0994  | 0.0000  | 0.0000  |
| 3-Ethylhexane          | 0.1649  | 0.3057  | 0.0108  | 0.0000  | 0.7464  |
| n-Octane               | 0.4462  | 1.1482  | 0.0601  | 4.3452  | 1.8149  |
| Ethylbenzene           | 0.1989  | 1.2698  | 0.0247  | 4.5312  | 1.9672  |
| p-Xylene               | 0.0800  | 0.3562  | 0.0077  | 4.9276  | 0.6668  |
| m-Xylene               | 0.1463  | 1.0711  | 0.0126  | 0.0000  | 1.6627  |
| o-Xylene               | 0.0813  | 0.7089  | 0.0080  | 4.5835  | 1.2487  |
| n-Nonane               | 0.1951  | 1.5824  | 0.0082  | 4.1871  | 1.1148  |
| i-Propylbenzene        | 0.0183  | 0.1644  | 0.0000  | 0.0000  | 0.0000  |
| n-Propylbenzene        | 0.0456  | 0.5008  | 0.0000  | 0.0000  | 0.0000  |
| 3-Ethyltoluene         | 0.0446  | 0.5516  | 0.0000  | 0.0000  | 0.0000  |
| 1,3,5-Trimethylbenzene | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 2-Ethyltoluene         | 0.0000  | 0.1692  | 0.0000  | 0.0000  | 0.0000  |
| t-butylbenzene         | 0.0337  | 0.2522  | 0.0000  | 0.0000  | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.0473  | 0.6815  | 0.0000  | 4.9369  | 0.0000  |
| i-butylbenzene         | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| s-butylbenzene         | 0.0000  | 0.2217  | 0.0000  | 0.0000  | 0.0000  |
| n-Decane               | 0.0060  | 0.0694  | 0.0000  | 0.0000  | 0.0000  |
| 1,2,3-Trimethylbenzene | 0.0299  | 0.3868  | 0.0000  | 0.0000  | 0.0000  |
| 1,3-Diethylbenzene     | 0.0246  | 0.4904  | 0.0000  | 0.0000  | 0.0000  |
| 1,4-Diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-butylbenzene         | 0.0000  | 0.1752  | 0.0000  | 0.0000  | 0.0000  |
| 1,2-diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-undecane             | 0.0000  | 1.2176  | 0.0000  | 0.0000  | 0.0000  |
| Other C4               | 1.1117  | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Other C5               | 3.3706  | 0.6062  | 2.7335  | 0.0000  | 1.3944  |
| Other C6               | 1.6494  | 2.0726  | 2.6472  | 0.0000  | 9.5263  |
| Other C7               | 1.3692  | 2.4995  | 0.8324  | 0.0000  | 5.7191  |
| Other C8               | 1.3995  | 5.4748  | 0.0995  | 5.4339  | 4.5759  |
| Other C9               | 0.6859  | 8.4377  | 0.0106  | 8.1739  | 1.7149  |
| Other C10              | 0.3521  | 5.1144  | 0.0000  | 0.0000  | 1.5896  |
| Other C11              | 0.0684  | 1.7402  | 0.0000  | 0.0000  | 0.0000  |

Table 11 - Ventura Field Summary

Hydrocarbon Species by % Mass

|                        | OF-50   | OF-51   | OF-52   | OF-53   |
|------------------------|---------|---------|---------|---------|
| Methane                | 26.3353 | 24.7704 | 12.8696 | 69.8572 |
| Ethane                 | 6.4585  | 7.5008  | 6.8363  | 9.0459  |
| Propane                | 18.9621 | 23.1831 | 25.1314 | 4.9068  |
| i-Butane               | 6.0712  | 7.6461  | 7.9999  | 0.6395  |
| n-Butane               | 14.4739 | 16.1895 | 19.0352 | 2.1218  |
| 2,2-dimethylpropane    | 0.0146  | 0.0162  | 0.0190  | 0.0000  |
| i-Pentane              | 5.8607  | 5.7925  | 6.7579  | 2.5646  |
| n-Pentane              | 5.1406  | 4.6708  | 5.8342  | 2.6707  |
| 2,2-Dimethylbutane     | 0.0000  | 0.0520  | 0.0000  | 0.0235  |
| Cyclopentane           | 0.0000  | 0.0000  | 0.0000  | 0.4227  |
| 2,3-Dimethylbutane     | 1.5218  | 1.1875  | 0.0000  | 0.0000  |
| 2-Methylpentane        | 0.0000  | 0.0071  | 0.0000  | 0.0000  |
| 3-Methylpentane        | 0.0000  | 0.8659  | 1.0630  | 0.0000  |
| n-Hexane               | 1.5428  | 1.1171  | 1.4054  | 0.6655  |
| Methylcyclopentane     | 1.9954  | 1.2884  | 1.8668  | 0.8751  |
| 2,4-Dimethylpentane    | 0.0469  | 0.0325  | 0.0415  | 0.0192  |
| Benzene                | 0.1318  | 0.3128  | 0.1360  | 0.0970  |
| Cyclohexane            | 0.0059  | 0.0000  | 0.0052  | 0.0000  |
| 2-Methylhexane         | 0.2858  | 0.1599  | 0.2234  | 0.0914  |
| 2,3-Dimethylpentane    | 0.1590  | 0.0843  | 0.1171  | 0.0511  |
| 3-Methylhexane         | 0.4622  | 0.2371  | 0.3428  | 0.1400  |
| n-Heptane              | 0.6540  | 0.2606  | 0.4833  | 0.1851  |
| Methylcyclohexane      | 0.8599  | 0.2270  | 0.6997  | 0.2890  |
| 2,4-Dimethylhexane     | 0.0282  | 0.0087  | 0.0000  | 0.0000  |
| 2,3,4-Trimethylpentane | 0.0126  | 0.0000  | 0.0084  | 0.0000  |
| Toluene                | 0.2022  | 0.2009  | 0.1689  | 0.1034  |
| 2,3-Dimethylhexane     | 0.0253  | 0.0071  | 0.0153  | 0.0000  |
| 2-Methylheptane        | 0.0378  | 0.0000  | 0.1659  | 0.0795  |
| 3-Ethylhexane          | 0.1086  | 0.0000  | 0.0819  | 0.0000  |
| n-Octane               | 0.2432  | 0.0797  | 0.1575  | 0.0881  |
| Ethylbenzene           | 0.1134  | 0.0976  | 0.0743  | 0.0492  |
| p-Xylene               | 0.0620  | 0.0787  | 0.0368  | 0.0336  |
| m-Xylene               | 0.0950  | 0.0000  | 0.0745  | 0.0652  |
| o-Xylene               | 0.0467  | 0.0461  | 0.0341  | 0.0502  |
| n-Nonane               | 0.1024  | 0.0383  | 0.0606  | 0.0629  |
| i-Propylbenzene        | 0.0078  | 0.0000  | 0.0000  | 0.0000  |
| n-Propylbenzene        | 0.0229  | 0.0174  | 0.0000  | 0.0191  |
| 3-Ethyltoluene         | 0.0000  | 0.0000  | 0.0166  | 0.0000  |
| 1,3,5-Trimethylbenzene | 0.0199  | 0.0000  | 0.0000  | 0.0000  |
| 2-Ethyltoluene         | 0.0093  | 0.0000  | 0.0000  | 0.0123  |
| t-butylbenzene         | 0.0117  | 0.0000  | 0.0062  | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.0351  | 0.0000  | 0.0228  | 0.0000  |
| i-butylbenzene         | 0.0000  | 0.0000  | 0.0000  | 0.0138  |
| s-butylbenzene         | 0.0000  | 0.0000  | 0.0000  | 0.0178  |
| n-Decane               | 0.0196  | 0.0000  | 0.0000  | 0.0100  |
| 1,2,3-Trimethylbenzene | 0.0068  | 0.0000  | 0.0000  | 0.0539  |
| 1,3-Diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0259  |
| 1,4-Diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-butylbenzene         | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| 1,2-diethylbenzene     | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| n-undecane             | 0.0205  | 0.0000  | 0.0000  | 0.0000  |
| Other C4               | 0.0000  | 0.0246  | 0.0060  | 0.0000  |
| Other C5               | 2.0335  | 1.4400  | 2.4045  | 1.3762  |
| Other C6               | 2.4888  | 1.2186  | 3.7835  | 0.9365  |
| Other C7               | 1.7315  | 0.5669  | 1.0877  | 0.6074  |
| Other C8               | 0.9871  | 0.3069  | 0.5952  | 0.5527  |
| Other C9               | 0.4512  | 0.2100  | 0.2615  | 0.8476  |
| Other C10              | 0.0890  | 0.0568  | 0.0577  | 0.3196  |
| Other C11              | 0.0056  | 0.0000  | 0.0123  | 0.0092  |

Table 12 - Wilmington Field Summary

## Hydrocarbon Species by % Mass

|                        | OF-60   | OF-61   | OF-62   | OF-63   |
|------------------------|---------|---------|---------|---------|
| Methane                | 0.0000  | 69.7258 | 86.2213 | 9.3724  |
| Ethane                 | 0.2429  | 3.4827  | 2.5933  | 8.6278  |
| Propane                | 0.8504  | 3.9190  | 1.9722  | 3.7709  |
| i-Butane               | 0.8152  | 2.2601  | 1.6328  | 7.6645  |
| n-Butane               | 2.1302  | 3.9861  | 1.9669  | 14.2861 |
| 2,2-dimethylpropane    | 0.0220  | 0.0256  | 0.0258  | 0.1059  |
| i-Pentane              | 2.2168  | 2.5187  | 1.1618  | 8.6462  |
| n-Pentane              | 2.2614  | 1.9546  | 0.7548  | 5.4645  |
| 2,2-Dimethylbutane     | 0.0338  | 0.0604  | 0.0351  | 0.1539  |
| Cyclopentane           | 0.4349  | 0.0000  | 0.0000  | 0.5612  |
| 2,3-Dimethylbutane     | 0.3434  | 0.2522  | 0.1145  | 0.0000  |
| 2-Methylpentane        | 1.2635  | 0.8062  | 0.2607  | 2.6425  |
| 3-Methylpentane        | 1.0717  | 0.6593  | 0.2066  | 1.9294  |
| n-Hexane               | 1.3441  | 0.6473  | 0.1832  | 1.9154  |
| Methylcyclopentane     | 2.5612  | 0.0000  | 0.3367  | 3.1383  |
| 2,4-Dimethylpentane    | 0.1425  | 0.0687  | 0.0243  | 0.1542  |
| Benzene                | 0.1265  | 0.0394  | 0.0052  | 0.5559  |
| Cyclohexane            | 0.0358  | 0.0177  | 0.0076  | 0.0316  |
| 2-Methylhexane         | 0.4420  | 0.1455  | 0.0371  | 0.5707  |
| 2,3-Dimethylpentane    | 0.7363  | 0.2629  | 0.0868  | 0.5102  |
| 3-Methylhexane         | 0.8066  | 0.2506  | 0.0661  | 0.8294  |
| n-Heptane              | 0.9793  | 0.2182  | 0.0454  | 1.0401  |
| Methylcyclohexane      | 0.5567  | 0.1322  | 0.0343  | 2.0397  |
| 2,4-Dimethylhexane     | 0.8914  | 0.0382  | 0.0473  | 0.1030  |
| 2,3,4-Trimethylpentane | 2.8710  | 0.0222  | 0.1755  | 0.0523  |
| Toluene                | 0.5115  | 0.0617  | 0.0127  | 0.1805  |
| 2,3-Dimethylhexane     | 0.1770  | 0.0270  | 0.0106  | 0.0840  |
| 2-Methylheptane        | 0.2675  | 0.0826  | 0.0169  | 0.6672  |
| 3-Ethylhexane          | 0.2710  | 0.0351  | 0.0097  | 0.3136  |
| n-Octane               | 1.7033  | 0.1645  | 0.0527  | 0.6727  |
| Ethylbenzene           | 1.5428  | 0.0704  | 0.0429  | 0.5052  |
| p-Xylene               | 0.7140  | 0.0002  | 0.0065  | 0.0000  |
| m-Xylene               | 0.6658  | 0.0293  | 0.0137  | 0.5832  |
| o-Xylene               | 0.4854  | 0.0184  | 0.0055  | 0.2485  |
| n-Nonane               | 0.1867  | 0.0000  | 0.0067  | 0.3525  |
| i-Propylbenzene        | 0.0700  | 0.0005  | 0.0000  | 0.0516  |
| n-Propylbenzene        | 0.4185  | 0.0134  | 0.0046  | 0.1527  |
| 3-Ethyltoluene         | 0.3413  | 0.0154  | 0.0000  | 0.1630  |
| 1,3,5-Trimethylbenzene | 0.4177  | 0.0006  | 0.0000  | 0.1066  |
| 2-Ethyltoluene         | 0.1949  | 0.0020  | 0.0000  | 0.0694  |
| t-butylbenzene         | 0.4297  | 0.0000  | 0.0000  | 0.0000  |
| 1,2,4-Trimethylbenzene | 0.3591  | 0.0009  | 0.0000  | 0.2217  |
| i-butylbenzene         | 0.3485  | 0.0007  | 0.0000  | 0.0500  |
| s-butylbenzene         | 0.2913  | 0.0007  | 0.0000  | 0.0608  |
| n-Decane               | 0.1863  | 0.0004  | 0.0000  | 0.0000  |
| 1,2,3-Trimethylbenzene | 0.2014  | 0.0208  | 0.0000  | 0.1393  |
| 1,3-Diethylbenzene     | 0.3057  | 0.0006  | 0.0000  | 0.0486  |
| 1,4-Diethylbenzene     | 0.4772  | 0.0000  | 0.0000  | 0.0457  |
| n-butylbenzene         | 0.4384  | 0.0012  | 0.0000  | 0.0000  |
| 1,2-diethylbenzene     | 0.2090  | 0.0000  | 0.0000  | 0.0000  |
| n-undecane             | 0.6217  | 0.0000  | 0.0000  | 0.0000  |
| Other C4               | 0.2737  | 0.0000  | 0.0000  | 0.0000  |
| Other C5               | 0.0574  | 0.3113  | 0.0918  | 0.9634  |
| Other C6               | 7.5924  | 3.7219  | 0.7104  | 5.6426  |
| Other C7               | 12.3951 | 2.5815  | 0.5625  | 5.4870  |
| Other C8               | 14.6463 | 1.0133  | 0.3413  | 5.4826  |
| Other C9               | 13.7861 | 0.2699  | 0.1006  | 2.7415  |
| Other C10              | 11.5726 | 0.0440  | 0.0157  | 0.6598  |
| Other C11              | 4.6614  | 0.0181  | 0.0000  | 0.1404  |

Table 13 - West Coyote Summary Hydrocarbon Species by % Mass

|                               | OF-70   | OF-71   | OF-72   | OF-73   |
|-------------------------------|---------|---------|---------|---------|
| Methane                       | 58.1224 | 35.6628 | 15.1756 | 33.8652 |
| Ethane                        | 4.7094  | 3.3726  | 5.6015  | 5.6250  |
| Propane                       | 5.4105  | 5.2351  | 10.5062 | 8.0447  |
| i-Butane                      | 3.2893  | 3.6774  | 6.7594  | 3.6714  |
| n-Butane                      | 5.4490  | 8.0761  | 12.7356 | 7.9733  |
| 2,2-dimethylpropane           | 0.0451  | 0.0556  | 0.0896  | 0.0445  |
| i-Pentane                     | 3.3785  | 6.4922  | 8.4747  | 5.6750  |
| n-Pentane                     | 2.2557  | 4.1816  | 5.4918  | 4.0613  |
| 2,2-Dimethylbutane            | 0.0626  | 0.0233  | 0.1885  | 0.0000  |
| Cyclopentane                  | 0.2334  | 0.0000  | 0.0000  | 0.9262  |
| ,3-Dimethylbutane             | 0.0000  | 0.5183  | 0.6525  | 0.4254  |
| 2-Methylpentane               | 1.1015  | 0.6451  | 2.6275  | 2.3633  |
| 3-Methylpentane               | 0.7976  | 0.8300  | 1.9876  | 1.7445  |
| n-Hexane                      | 0.8718  | 1.9254  | 1.9240  | 1.9775  |
| Methylcyclopentane            | 1.2895  | 3.4133  | 0.0000  | 3.2691  |
| 2,4-Dimethylpentane           | 0.0657  | 0.1657  | 0.1842  | 0.1464  |
| Benzene                       | 0.2862  | 1.0242  | 0.5061  | 0.7648  |
| Cyclohexane                   | 0.0141  | 0.0455  | 0.0430  | 0.0375  |
| 2-Methylhexane                | 0.2558  | 0.6520  | 0.5803  | 0.6403  |
| 2,3-Dimethylpentane           | 0.2155  | 0.4700  | 0.5827  | 0.4173  |
| 3-Methylhexane                | 0.3641  | 0.9465  | 0.8370  | 0.9254  |
| n-Heptane                     | 0.0516  | 1.0903  | 0.9119  | 1.2199  |
| Methylcyclohexane             | 0.8363  | 0.0000  | 0.0000  | 1.9907  |
| 2,4-Dimethylhexane            | 0.0436  | 0.3761  | 0.0963  | 0.6066  |
| 2,3,4-Trimethylpentane        | 0.4135  | 0.6770  | 0.9547  | 0.0362  |
| Toluene                       | 0.0930  | 0.2632  | 0.2392  | 0.4144  |
| 2,3-Dimethylhexane            | 0.0351  | 0.0644  | 0.0690  | 0.0570  |
| 2-Methylheptane               | 0.3157  | 0.0911  | 0.4542  | 0.0000  |
| 3-Ethylhexane                 | 0.1527  | 0.2564  | 0.2328  | 0.2375  |
| n-Octane                      | 0.1655  | 0.6430  | 0.2912  | 0.2312  |
| Ethylbenzene                  | 0.2061  | 0.2579  | 0.2439  | 0.2070  |
| p-Xylene                      | 0.2752  | 0.3141  | 0.2734  | 0.2357  |
| m-Xylene                      | 0.1314  | 0.0000  | 0.1329  | 0.0000  |
| o-Xylene                      | 0.1084  | 0.1187  | 0.1125  | 0.0911  |
| n-Nonane                      | 0.1806  | 0.0450  | 0.1687  | 0.0945  |
| i-Propylbenzene               | 0.0104  | 0.0099  | 0.0093  | 0.0072  |
| n-Propylbenzene               | 0.0494  | 0.0382  | 0.0499  | 0.0304  |
| 3-Ethyltoluene                | 0.0245  | 0.0187  | 0.0229  | 0.0145  |
| 1,3,5-Trimethylbenzene        | 0.0422  | 0.0000  | 0.0435  | 0.0000  |
| 2-Ethyltoluene                | 0.0419  | 0.0222  | 0.0441  | 0.0203  |
| t-butylbenzene                | 0.0231  | 0.0157  | 0.0226  | 0.0130  |
| 1,2,4-Trimethylbenzene 0.0150 | 0.0092  | 0.0126  | 0.0071  |         |
| i-butylbenzene                | 0.0000  | 0.0000  | 0.0000  | 0.0027  |
| s-butylbenzene                | 0.0000  | 0.0115  | 0.0000  | 0.0082  |
| n-Decane                      | 0.0000  | 0.0000  | 0.0933  | 0.0255  |
| 1,2,3-Trimethylbenzene        | 0.0156  | 0.0101  | 0.0161  | 0.0075  |
| 1,3-Diethylbenzene            | 0.0084  | 0.0000  | 0.0000  | 0.0018  |
| 1,4-Diethylbenzene            | 0.0000  | 0.0131  | 0.0000  | 0.0090  |
| n-butylbenzene                | 0.0146  | 0.0000  | 0.0150  | 0.0063  |
| 1,2-diethylbenzene            | 0.0046  | 0.0000  | 0.0000  | 0.0019  |
| n-undecane                    | 0.0000  | 0.0000  | 0.0000  | 0.0084  |
| Other C4                      | 0.0000  | 0.0000  | 0.0000  | 0.0000  |
| Other C5                      | 0.3807  | 4.2101  | 1.0699  | 0.1301  |
| Other C6                      | 2.3344  | 5.1428  | 9.4645  | 5.1712  |
| Other C7                      | 1.7070  | 5.1750  | 5.3237  | 3.2849  |
| Other C8                      | 2.4206  | 2.5361  | 2.8911  | 2.4562  |
| Other C9                      | 1.2098  | 1.0006  | 1.2675  | 0.6445  |
| Other C10                     | 0.4144  | 0.1483  | 0.4558  | 0.1150  |
| Other C11                     | 0.0571  | 0.0283  | 0.0696  | 0.0146  |

Table 14 - Database Format

|       | Methane | Ethane  | Propane | i-Butane | n-Butane | 2,2-dimethyl<br>i-Pentane | n-Pentane | 2,2-Dime | Cyclopent | 2,3-Dime | 2-Methyl | 3-Methyl | n-Hexane | Methyley | 2,4-Dime | Benzene | Cyclohex |
|-------|---------|---------|---------|----------|----------|---------------------------|-----------|----------|-----------|----------|----------|----------|----------|----------|----------|---------|----------|
| OF-01 | 0.1616  | 0.0931  | 0.1499  | 0.0000   | 0.1825   | 0.0000                    | 0.0000    | 0.5323   | 0.0000    | 0.3055   | 0.0000   | 0.0000   | 0.0724   | 0.0000   | 0.0931   | 0.1318  | 0.0000   |
| OF-02 | 81.3998 | 0.1565  | 0.0955  | 0.0647   | 0.0842   | 0.3083                    | 0.1803    | 0.3794   | 0.0000    | 1.3302   | 0.0203   | 0.0737   | 0.0194   | 0.0121   | 0.2317   | 0.1337  | 0.1322   |
| OF-03 | 62.0949 | 0.1214  | 0.0781  | 0.0531   | 0.0684   | 0.2510                    | 0.1558    | 0.3487   | 0.0000    | 1.2881   | 0.0174   | 0.0712   | 0.0082   | 0.1412   | 0.2654   | 0.0000  | 0.1564   |
| OF-04 | 60.7789 | 1.3946  | 0.3922  | 0.1601   | 0.0914   | 0.6376                    | 0.1549    | 0.2715   | 0.0000    | 0.8293   | 0.0025   | 0.0696   | 0.3656   | 0.0153   | 0.1847   | 0.2571  | 0.1040   |
| OF-05 | 95.9289 | 0.2717  | 0.0716  | 0.0542   | 0.0352   | 0.1440                    | 0.0434    | 0.0066   | 0.1704    | 0.0000   | 0.0000   | 0.0093   | 0.0000   | 0.0000   | 0.0341   | 0.0000  | 0.0000   |
| OF-06 | 4.4862  | 0.4191  | 0.3025  | 0.3003   | 0.2139   | 0.3897                    | 0.4758    | 0.0696   | 0.0000    | 2.9941   | 0.0637   | 0.2005   | 0.0370   | 0.3065   | 0.6060   | 0.0177  | 0.3697   |
| OF-10 | 44.8895 | 7.9019  | 13.0885 | 3.1748   | 10.3318  | 0.1106                    | 2.8767    | 0.1824   | 0.4262    | 0.0000   | 1.0121   | 0.6783   | 1.0797   | 1.5561   | 0.0000   | 0.0799  | 0.0255   |
| OF-11 | 37.7408 | 7.6800  | 14.8836 | 3.3993   | 6.7414   | 0.1170                    | 1.5246    | 0.1976   | 0.4740    | 0.0000   | 1.1492   | 0.7795   | 1.2686   | 1.9090   | 0.1213   | 0.0912  | 0.0307   |
| OF-12 | 33.4312 | 12.7717 | 17.2663 | 3.4171   | 10.8072  | 0.1195                    | 3.3797    | 0.1976   | 0.4656    | 0.0000   | 0.9909   | 0.6824   | 1.0330   | 1.7244   | 0.1125   | 0.0694  | 0.0293   |
| OF-13 | 11.8005 | 9.5479  | 17.0718 | 5.7194   | 17.3072  | 0.0427                    | 2.0964    | 0.0925   | 0.2939    | 0.0000   | 1.7049   | 1.6037   | 3.2012   | 2.7693   | 0.0910   | 0.4320  | 0.0000   |
| OF-14 | 31.9680 | 15.4250 | 17.7471 | 3.8778   | 11.4358  | 0.1169                    | 3.6524    | 0.1790   | 0.4103    | 0.0000   | 0.9906   | 0.1099   | 0.9704   | 1.5368   | 0.0928   | 0.0674  | 0.0237   |
| OF-15 | 19.4226 | 8.4997  | 15.3786 | 4.2802   | 3.3683   | 0.6509                    | 1.6843    | 0.0966   | 0.1599    | 0.0000   | 1.0162   | 0.0000   | 2.4788   | 1.4020   | 0.0923   | 0.4661  | 0.0177   |
| OF-16 | 35.1586 | 3.7104  | 12.6201 | 3.2037   | 15.2084  | 0.1633                    | 1.8193    | 0.3145   | 0.7297    | 0.0000   | 0.5465   | 0.4636   | 0.8823   | 3.0811   | 0.1934   | 0.0287  | 0.0486   |
| OF-17 | 26.7810 | 7.5402  | 14.1825 | 5.0340   | 13.2046  | 0.0420                    | 4.4784    | 0.0877   | 0.2727    | 0.0000   | 1.2021   | 1.4428   | 2.3533   | 2.4687   | 0.0791   | 0.2989  | 0.0164   |
| OF-20 | 6.309   | 13.8534 | 20.3860 | 1.9291   | 17.5464  | 0.0456                    | 5.9460    | 0.0964   | 0.0000    | 0.3293   | 1.7627   | 1.6061   | 3.0647   | 3.4631   | 0.1121   | 0.3862  | 0.0219   |
| OF-21 | 47.8262 | 10.1622 | 13.5873 | 2.7121   | 7.7710   | 0.0203                    | 2.9425    | 0.0438   | 0.0000    | 0.1474   | 1.0353   | 0.6445   | 1.1569   | 0.0164   | 0.0442   | 0.1231  | 0.0085   |
| OF-22 | 44.8636 | 6.8113  | 10.3987 | 2.5031   | 8.2760   | 0.0185                    | 3.5109    | 0.0407   | 0.1801    | 0.0000   | 1.3757   | 0.9477   | 1.5742   | 0.0160   | 0.0595   | 0.0872  | 0.0109   |
| OF-23 | 45.7334 | 9.2589  | 13.3879 | 3.0755   | 9.7694   | 0.0251                    | 3.7319    | 0.0409   | 0.1537    | 0.0000   | 1.1674   | 0.7538   | 1.1753   | 0.0137   | 0.0414   | 0.0919  | 0.0075   |
| OF-24 | 25.6069 | 7.9440  | 16.7611 | 4.2843   | 14.0011  | 0.0415                    | 5.0878    | 0.0828   | 0.2917    | 0.0000   | 1.0834   | 1.0913   | 1.9673   | 2.8540   | 0.0880   | 0.1998  | 0.0177   |
| OF-25 | 2.7544  | 5.4703  | 4.5376  | 2.1106   | 6.6176   | 0.2065                    | 5.3812    | 0.2502   | 0.6577    | 0.0000   | 2.1277   | 1.4123   | 2.3156   | 2.5628   | 0.2350   | 0.2686  | 0.0000   |
| OF-26 | 95.9626 | 0.5781  | 0.1836  | 0.0375   | 0.1228   | 0.0794                    | 0.0535    | 0.0000   | 0.0000    | 0.0191   | 0.0223   | 0.0000   | 0.0206   | 0.0057   | 0.0000   | 0.0000  | 0.0000   |
| OF-27 | 98.1996 | 0.6958  | 0.1861  | 0.0213   | 0.0335   | 0.0554                    | 0.0080    | 0.0050   | 0.0000    | 0.0011   | 0.0031   | 0.0000   | 0.0038   | 0.0000   | 0.0000   | 0.0050  | 0.0000   |
| OF-40 | 40.6929 | 8.8839  | 14.1404 | 3.1034   | 8.2204   | 0.0114                    | 2.8269    | 0.0000   | 0.2525    | 0.0000   | 1.5351   | 0.8659   | 1.7048   | 1.1296   | 0.0375   | 0.2509  | 0.0000   |
| OF-41 | 10.0741 | 20.1940 | 11.3004 | 1.5022   | 4.4444   | 0.0000                    | 1.6489    | 0.0000   | 0.1323    | 0.0000   | 0.6920   | 0.6022   | 0.9060   | 1.2395   | 0.0000   | 1.8187  | 0.0000   |
| OF-42 | 8.0981  | 1.5655  | 4.9484  | 4.5482   | 16.7562  | 0.0443                    | 18.2855   | 0.0000   | 0.0000    | 0.0000   | 5.8657   | 3.7394   | 4.8494   | 2.9251   | 0.0000   | 0.3463  | 0.0122   |
| OF-43 | 0.0000  | 1.6118  | 1.3702  | 0.0000   | 2.4984   | 0.0000                    | 3.5461    | 0.3522   | 0.0000    | 0.0000   | 4.0751   | 0.0000   | 5.7627   | 5.2924   | 0.0000   | 9.1484  | 0.0000   |
| OF-44 | 0.0000  | 0.0000  | 0.0000  | 1.0505   | 0.0000   | 0.0000                    | 4.3902    | 0.0000   | 0.0000    | 0.0000   | 6.1335   | 4.9084   | 6.6935   | 5.9473   | 0.0000   | 10.7339 | 0.0000   |
| OF-50 | 26.3353 | 6.4585  | 18.9621 | 6.0712   | 14.4739  | 0.0146                    | 5.8607    | 0.1406   | 0.0000    | 1.5218   | 0.0000   | 0.0000   | 1.5428   | 1.9954   | 0.0469   | 0.1318  | 0.0059   |
| OF-51 | 24.7704 | 7.5008  | 23.1831 | 7.6461   | 16.1895  | 0.0162                    | 5.7925    | 0.0520   | 0.0000    | 1.1875   | 0.0071   | 0.8659   | 1.1171   | 1.2884   | 0.0325   | 0.3128  | 0.0000   |
| OF-52 | 12.8696 | 6.8363  | 25.1314 | 7.9999   | 19.0352  | 0.0190                    | 6.7579    | 0.0000   | 0.0000    | 0.0000   | 0.0000   | 1.0630   | 1.4054   | 1.8668   | 0.0415   | 0.1360  | 0.0052   |
| OF-53 | 69.8572 | 9.0459  | 4.9068  | 0.6395   | 2.1218   | 0.0000                    | 2.5646    | 0.2707   | 0.4227    | 0.0000   | 0.0000   | 0.0000   | 0.6655   | 0.8751   | 0.0192   | 0.0970  | 0.0000   |
| OF-60 | 0.0000  | 0.2429  | 0.8504  | 0.8152   | 2.1302   | 0.0220                    | 2.2168    | 0.0338   | 0.4349    | 0.3434   | 1.2635   | 1.0717   | 1.3441   | 2.5612   | 0.1425   | 0.1265  | 0.0358   |
| OF-61 | 69.7258 | 3.4827  | 3.9190  | 2.2601   | 3.9861   | 0.0256                    | 2.5187    | 0.0604   | 0.0000    | 0.2522   | 0.8062   | 0.6593   | 0.6473   | 0.0000   | 0.0687   | 0.0394  | 0.0177   |
| OF-62 | 86.2213 | 2.5933  | 1.9722  | 1.6328   | 1.9669   | 0.0258                    | 1.1618    | 0.7548   | 0.0351    | 0.0000   | 0.1145   | 0.2607   | 0.2066   | 0.1832   | 0.3367   | 0.0243  | 0.0076   |
| OF-63 | 9.3724  | 8.6278  | 3.7709  | 7.6645   | 14.2861  | 0.1059                    | 8.6462    | 0.1539   | 0.5612    | 0.0000   | 2.6425   | 1.9294   | 1.9154   | 3.1383   | 0.1542   | 0.5559  | 0.0316   |
| OF-70 | 58.1224 | 4.7094  | 5.4105  | 3.2893   | 5.4490   | 0.0451                    | 3.3785    | 0.2557   | 0.2334    | 0.0000   | 1.1015   | 0.7976   | 0.8718   | 1.2895   | 0.0657   | 0.2862  | 0.0141   |
| OF-71 | 35.6628 | 3.3726  | 5.2351  | 3.6774   | 8.0761   | 0.0556                    | 6.4922    | 0.0233   | 0.0000    | 0.5183   | 0.6451   | 0.8300   | 1.9254   | 3.4133   | 0.1657   | 1.0242  | 0.0455   |
| OF-72 | 15.1756 | 5.6015  | 10.5062 | 6.7594   | 12.7356  | 0.0896                    | 8.4747    | 0.1885   | 0.0000    | 0.6525   | 2.6275   | 1.9876   | 1.9240   | 0.0000   | 0.1842   | 0.5061  | 0.0430   |
| OF-73 | 33.8652 | 5.6250  | 8.0447  | 3.6714   | 7.9733   | 0.0445                    | 5.6750    | 0.0000   | 0.9262    | 0.4254   | 2.3633   | 1.7445   | 1.9775   | 3.2691   | 0.1464   | 0.7648  | 0.0375   |

## I. Discussion of Results

To assess variability introduced by the sampling process, duplicate samples OF-2 and OF-3 were taken from the same point, within 30 minutes of each other. Table 15 shows that these samples agree fairly well with each other. The largest difference was in the methane values: 81.4 vs. 62.0 %. These samples were collected by bagging a valve, and capturing the bagged emissions into a stainless steel canister. It was impossible to keep the sampling time constant for these two runs. The "leak rate" of the sampled valve was not constant. Another potential source of variability is a compositional change in the emissions with respect to time. In any case, most constituents other than methane agreed within 0.1 % absolute, or 30 % relative. These values probably represent realistic estimates of the overall uncertainty in the values listed in the summary tables.

Three samples (OF-43,44 and 60) were found to contain no methane. These samples were obtained from open sumps. The methane content of samples taken directly from well heads at the Kern River Facility ranged from 5 to 80 % of the total hydrocarbons. Since methane was determined separately from the other hydrocarbons, a sensitivity study was undertaken, to estimate the effect of errors in the methane concentration on the overall results. The results of this study (Table 16) show that errors in the methane analysis should not unduly influence the overall results. In general, the overall uncertainty in the % composition values is proportional to the error in the methane concentration.

The analytical methods used in this study yielded chromatograms containing as many as several hundred peaks. As discussed earlier, some peaks remained unidentified, and were listed as "Other Cn". Table 17 shows information on these compounds. The study-wide average for "Others" was 17%. In other words, an average of 83 % of the total hydrocarbon mass was identified. There are a few notable deviations from this average. The average value for "others" in the Kern River field was 36 %, more than twice the overall average. Samples OF-1 and OF-6 show values of about 75 % unidentified compounds. This field produces heavy crude (API gravity: 13.6°) by steamflood. Sample OF-1 came from the headspace of a gage tank open to the atmosphere (no vapor recovery), in close proximity to well 406. The oil in the tank was at 72° C. These two conditions evidently resulted in a depletion of the lighter hydrocarbons, which contribute a fair fraction of the mass for samples taken at other fields. Unlike most other samples, OF-1 showed most of its hydrocarbon mass above the C7 range, with a number of "heavy" peaks not found in other samples. Well head samples taken at well 406 (OF-2 and OF-3) contained 60 - 80 % methane. It is likely that the elevated temperature of all samples in this field is responsible for the higher amounts of heavy hydrocarbons not identified.

Consistent with the original Request for Proposal, results from all light, medium and heavy samples have been summarized in Table 18.

Table 15 - Sampling Variability

|                                       | OF-02         | OF-03         | DIFFERENCE   |                    |
|---------------------------------------|---------------|---------------|--------------|--------------------|
|                                       |               |               | absolute     | % relative to mean |
| Methane                               | 81.3998       | 62.0949       | 19.30        | 26.91              |
| Ethane                                | 0.1565        | 0.1214        | 0.04         | 25.23              |
| Propane                               | 0.0955        | 0.0781        | 0.02         | 20.07              |
| i-Butane                              | 0.0647        | 0.0531        | 0.01         | 19.61              |
| <b>n-Butane</b>                       | <b>0.0842</b> | <b>0.0684</b> | <b>0.02</b>  | <b>20.80</b>       |
| 2,2-dimethylpropane                   | 0.3083        | 0.2510        | 0.06         | 20.50              |
| i-Pentane                             | 0.1803        | 0.1558        | 0.02         | 14.61              |
| <b>n-Pentane</b>                      | <b>0.0321</b> | <b>0.0250</b> | <b>0.01</b>  | <b>24.88</b>       |
| 2,2-Dimethylbutane                    | 0.3794        | 0.3487        | 0.03         | 8.44               |
| Cyclopentane                          | 0.0000        | 0.0000        | 0.00         | N/A                |
| 2,3-Dimethylbutane                    | 1.3302        | 1.2881        | 0.04         | 3.21               |
| 2-Methylpentane                       | 0.0203        | 0.0174        | 0.00         | 15.31              |
| 3-Methylpentane                       | 0.0737        | 0.0712        | 0.00         | 3.41               |
| <b>n-Hexane</b>                       | <b>0.0194</b> | <b>0.0082</b> | <b>0.01</b>  | <b>81.78</b>       |
| Methylcyclopentane                    | 0.0121        | 0.1412        | -0.13        | -168.42            |
| 2,4-Dimethylpentane                   | 0.2317        | 0.2654        | -0.03        | -13.54             |
| Benzene                               | 0.0137        | 0.0000        | 0.01         | N/A                |
| Cyclohexane                           | 0.1322        | 0.1564        | -0.02        | -16.75             |
| 2-Methylhexane                        | 0.6399        | 0.7923        | -0.15        | -21.28             |
| 2,3-Dimethylpentane                   | 0.0000        | 0.0000        | 0.00         | N/A                |
| 3-Methylhexane                        | 0.0223        | 0.0228        | -0.00        | -2.15              |
| <b>n-Heptane</b>                      | <b>0.0000</b> | <b>0.0000</b> | <b>0.00</b>  | <b>N/A</b>         |
| Methylcyclohexane                     | 0.0158        | 0.0169        | -0.00        | -6.24              |
| 2,4-Dimethylhexane                    | 0.1780        | 0.2580        | -0.08        | -36.68             |
| 2,3,4-Trimethylpentane                | 0.1985        | 0.2951        | -0.10        | -39.10             |
| Toluene                               | 0.0800        | 0.1192        | -0.04        | -39.29             |
| 2,3-Dimethylhexane                    | 0.0466        | 0.0566        | -0.01        | -19.50             |
| 2-Methylheptane                       | 0.0298        | 0.0513        | -0.02        | -52.97             |
| 3-Ethylhexane                         | 0.1108        | 0.1775        | -0.07        | -46.26             |
| <b>n-Octane</b>                       | <b>0.8900</b> | <b>1.4281</b> | <b>-0.54</b> | <b>-46.42</b>      |
| Ethylbenzene                          | 0.4798        | 0.7963        | -0.32        | -49.61             |
| p-Xylene                              | 0.0155        | 0.0250        | -0.01        | -46.99             |
| m-Xylene                              | 0.0091        | 0.0096        | -0.00        | -4.97              |
| o-Xylene                              | 0.1397        | 0.2040        | -0.06        | -37.39             |
| <b>n-Nonane</b>                       | <b>0.0804</b> | <b>0.1463</b> | <b>-0.07</b> | <b>-58.18</b>      |
| i-Propylbenzene                       | 0.0751        | 0.1261        | -0.05        | -50.64             |
| n-Propylbenzene                       | 0.0704        | 0.1432        | -0.07        | -68.25             |
| 3-Ethyltoluene                        | 0.0754        | 0.0701        | 0.01         | 7.34               |
| 1,3,5-Trimethylbenzene                | 0.1059        | 0.2325        | -0.13        | -74.84             |
| 2-Ethyltoluene                        | 0.1053        | 0.2072        | -0.10        | -65.23             |
| t-butylbenzene                        | 0.1515        | 0.2642        | -0.11        | -54.27             |
| 1,2,4-Trimethylbenzene                | 0.1777        | 0.3203        | -0.14        | -57.27             |
| i-butylbenzene                        | 0.0000        | 0.0000        | 0.00         | N/A                |
| s-butylbenzene                        | 0.1154        | 0.2455        | -0.13        | -72.06             |
| <b>n-Decane</b>                       | <b>0.0767</b> | <b>0.1528</b> | <b>-0.08</b> | <b>-66.30</b>      |
| 1,2,3-Trimethylbenzene                | 0.1167        | 0.2233        | -0.11        | -62.71             |
| 1,3-Diethylbenzene                    | 0.0883        | 0.2133        | -0.12        | -82.85             |
| 1,4-Diethylbenzene                    | 0.0874        | 0.2261        | -0.14        | -88.47             |
| n-butylbenzene                        | 0.0273        | 0.1696        | -0.14        | -144.46            |
| 1,2-diethylbenzene                    | 0.0729        | 0.1544        | -0.08        | -71.68             |
| <b>n-undecane</b>                     | <b>0.0000</b> | <b>0.1151</b> | <b>-0.12</b> | <b>N/A</b>         |
| Other C4                              | 0.0000        | 0.0000        | 0.00         | N/A                |
| Other C5                              | 0.0000        | 0.0000        | 0.00         | N/A                |
| Other C6                              | 0.6617        | 0.7074        | -0.05        | -6.67              |
| Other C7                              | 2.7837        | 4.5832        | -1.80        | -48.85             |
| Other C8                              | 3.1244        | 5.1639        | -2.04        | -49.21             |
| Other C9                              | 2.7101        | 5.6391        | -2.93        | -70.16             |
| Other C10                             | 1.8284        | 6.0923        | -4.26        | -107.67            |
| Other C11                             | 0.0751        | 5.4074        | -5.33        | -194.52            |
|                                       |               |               |              |                    |
| AVERAGE1 : all values                 | AVERAGE1      | -0.00         | -31.35       |                    |
| AVERAGE2 : excluding methane & OTHERs | AVERAGE2      | -0.06         | -27.99       |                    |



Table 16 - Methane Sensitivity Analysis Results

|       | Methane area, % relative to Nominal Value |        |        |        |        |        |        |
|-------|---|--------|--------|--------|--------|--------|--------|
|       | 100                                       | 90     | 110    | 125    | 75     | 150    | 50     |
| C1    | 87.038                                    | 85.803 | 88.076 | 89.355 | 83.433 | 90.969 | 77.051 |
| C2    | 2.194                                     | 2.403  | 2.018  | 1.802  | 2.804  | 1.529  | 3.885  |
| C3    | 1.507                                     | 1.651  | 1.387  | 1.238  | 1.926  | 1.050  | 2.668  |
| C4    | 5.126                                     | 5.614  | 4.715  | 4.210  | 6.551  | 3.571  | 9.075  |
| C5    | 0.970                                     | 1.063  | 0.893  | 0.797  | 1.240  | 0.676  | 1.718  |
| C6    | 1.901                                     | 2.082  | 1.749  | 1.561  | 2.429  | 1.324  | 3.365  |
| C7    | 0.939                                     | 1.028  | 0.864  | 0.771  | 1.200  | 0.654  | 1.662  |
| C8    | 0.292                                     | 0.320  | 0.268  | 0.240  | 0.373  | 0.203  | 0.517  |
| C9    | 0.033                                     | 0.036  | 0.031  | 0.027  | 0.042  | 0.023  | 0.059  |
| C10   | 0.000                                     | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| C11   | 0.000                                     | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| TOTAL | 100.00                                    | 100.00 | 100.00 | 100.00 | 100.00 | 100.00 | 100.00 |

| ERRORS |       |       |        |       |        |        |  |
|--------|-------|-------|--------|-------|--------|--------|--|
| C1     | -1.4% | 1.2%  | 2.7%   | -4.1% | 4.5%   | -11.5% |  |
| C2     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C3     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C4     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C5     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C6     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C7     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C8     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C9     | 9.5%  | -8.0% | -17.9% | 27.8% | -30.3% | 77.1%  |  |
| C10    | N/A   | N/A   | N/A    | N/A   | N/A    | N/A    |  |
| C11    | N/A   | N/A   | N/A    | N/A   | N/A    | N/A    |  |
| TOTAL  | 0.0%  | 0.0%  | 0.0%   | 0.0%  | 0.0%   | 0.0%   |  |

Table 17 - OIL FIELD SUMMARY - "OTHER Cn", by % Mass

|                     | Other C4 | Other C5 | Other C6 | Other C7 | Other C8 | Other C9 | Other C10 | Other C11 | TOTAL |
|---------------------|----------|----------|----------|----------|----------|----------|-----------|-----------|-------|
| OF-01               | 0.0000   | 0.0000   | 0.0000   | 2.7537   | 9.6620   | 24.3261  | 30.0711   | 10.0782   | 76.89 |
| OF-02               | 0.0000   | 0.0000   | 0.6617   | 2.7837   | 3.1244   | 2.7101   | 1.8284    | 0.0751    | 11.18 |
| OF-03               | 0.0000   | 0.0000   | 0.7074   | 4.5832   | 5.1639   | 5.6391   | 6.0923    | 5.4074    | 27.59 |
| OF-04               | 0.1460   | 0.0566   | 0.6329   | 2.6022   | 5.9405   | 10.3142  | 6.6704    | 0.3234    | 26.69 |
| OF-05               | 0.0000   | 0.0000   | 0.0000   | 0.4848   | 0.7901   | 0.8362   | 0.3693    | 0.0275    | 2.51  |
| OF-06               | 0.0000   | 0.0000   | 3.0064   | 21.5246  | 22.4750  | 19.7780  | 6.7337    | 0.0353    | 73.55 |
| Kern River Average  |          |          |          |          |          |          |           |           | 36.40 |
| OF-10               | 0.5783   | 1.4612   | 2.2153   | 1.3296   | 0.7813   | 0.3196   | 0.1121    | 0.0219    | 6.82  |
| OF-11               | 6.1069   | 3.0812   | 3.3493   | 2.3796   | 1.3165   | 0.6090   | 0.1073    | 0.0068    | 16.96 |
| OF-12               | 0.0000   | 0.7107   | 3.1000   | 1.5896   | 1.0459   | 0.4462   | 0.0851    | 0.0040    | 6.98  |
| OF-13               | 5.2441   | 6.5695   | 3.6424   | 2.0599   | 0.6321   | 0.1228   | 0.0000    | 0.0000    | 18.27 |
| OF-14               | 0.0577   | 1.3404   | 1.9094   | 1.3557   | 0.6379   | 0.2824   | 0.0975    | 0.0098    | 5.69  |
| OF-15               | 13.7463  | 9.1198   | 6.4305   | 4.3198   | 0.9180   | 0.3332   | 0.0000    | 0.0000    | 34.87 |
| OF-16               | 0.0000   | 1.2993   | 6.2250   | 3.7814   | 1.9979   | 0.6220   | 0.0177    | 0.0000    | 13.94 |
| OF-17               | 2.5913   | 6.2761   | 3.0361   | 1.2699   | 0.4258   | 0.0753   | 0.0000    | 0.0000    | 13.67 |
| Elk Hills Average   |          |          |          |          |          |          |           |           | 14.65 |
| OF-20               | 0.0000   | 2.8126   | 6.9258   | 3.0713   | 1.8956   | 0.7019   | 0.1335    | 0.0394    | 15.58 |
| OF-21               | 0.0000   | 0.0000   | 0.5288   | 3.6994   | 1.4513   | 0.9881   | 0.0484    | 0.0092    | 6.73  |
| OF-22               | 0.0000   | 0.6376   | 5.9315   | 2.9653   | 1.6682   | 0.6194   | 0.0776    | 0.0018    | 11.90 |
| OF-23               | 0.0000   | 0.5484   | 3.7219   | 1.0916   | 0.4752   | 0.0943   | 0.0302    | 0.0056    | 5.97  |
| OF-24               | 0.0000   | 1.6789   | 4.2202   | 3.0840   | 0.9441   | 0.1285   | 0.0331    | 0.0000    | 10.09 |
| OF-25               | 0.0000   | 1.3806   | 8.7054   | 15.5060  | 11.9369  | 6.6643   | 1.3815    | 0.3470    | 45.92 |
| OF-26               | 0.0000   | 0.0553   | 0.0935   | 0.1773   | 0.6540   | 0.8882   | 0.5560    | 0.1279    | 2.55  |
| OF-27               | 0.0000   | 0.0126   | 0.0171   | 0.0106   | 0.0655   | 0.2110   | 0.2885    | 0.0000    | 0.61  |
| Belridge Average    |          |          |          |          |          |          |           |           | 12.42 |
| OF-40               | 1.1117   | 3.3706   | 1.6494   | 1.3692   | 1.3995   | 0.6859   | 0.3521    | 0.0684    | 10.01 |
| OF-41               | 0.0000   | 0.6062   | 2.0726   | 2.4995   | 5.4748   | 8.4377   | 5.1144    | 1.7402    | 25.95 |
| OF-42               | 0.0000   | 2.7335   | 2.6472   | 0.8324   | 0.0995   | 0.0106   | 0.0000    | 0.0000    | 6.32  |
| OF-43               | 0.0000   | 0.0000   | 0.0000   | 0.0000   | 5.4339   | 8.1739   | 0.0000    | 0.0000    | 13.61 |
| OF-44               | 0.0000   | 1.3944   | 9.5263   | 5.7191   | 4.5759   | 1.7149   | 1.5896    | 0.0000    | 24.52 |
| Cat Canyon Average  |          |          |          |          |          |          |           |           | 16.08 |
| OF-50               | 0.0000   | 2.0335   | 2.4888   | 1.7315   | 0.9871   | 0.4512   | 0.0890    | 0.0056    | 7.79  |
| OF-51               | 0.0246   | 1.4400   | 1.2186   | 0.5669   | 0.3069   | 0.2100   | 0.0568    | 0.0000    | 3.82  |
| OF-52               | 0.0060   | 2.4045   | 3.7835   | 1.0877   | 0.5952   | 0.2615   | 0.0577    | 0.0123    | 8.21  |
| OF-53               | 0.0000   | 1.3762   | 0.9365   | 0.6074   | 0.5527   | 0.8476   | 0.3196    | 0.0092    | 4.65  |
| Ventura Average     |          |          |          |          |          |          |           |           | 6.12  |
| OF-60               | 0.2737   | 0.0574   | 7.5924   | 12.3951  | 14.6463  | 13.7861  | 11.5726   | 4.6614    | 64.98 |
| OF-61               | 0.0000   | 0.3113   | 3.7219   | 2.5815   | 1.0133   | 0.2699   | 0.0440    | 0.0181    | 7.96  |
| OF-62               | 0.0000   | 0.0918   | 0.7104   | 0.5625   | 0.3413   | 0.1006   | 0.0157    | 0.0000    | 1.82  |
| OF-63               | 0.0000   | 0.9634   | 5.6426   | 5.4870   | 5.4826   | 2.7415   | 0.6598    | 0.1404    | 21.12 |
| Wilmington Average  |          |          |          |          |          |          |           |           | 23.97 |
| OF-70               | 0.0000   | 0.3807   | 2.3344   | 1.7070   | 2.4206   | 1.2098   | 0.4144    | 0.0571    | 8.52  |
| OF-71               | 0.0000   | 4.2101   | 5.1428   | 5.1750   | 2.5361   | 1.0006   | 0.1483    | 0.0283    | 18.24 |
| OF-72               | 0.0000   | 1.0699   | 9.4645   | 5.3237   | 2.8911   | 1.2675   | 0.4558    | 0.0696    | 20.54 |
| OF-73               | 0.0000   | 0.1301   | 5.1712   | 3.2849   | 2.4562   | 0.6445   | 0.1150    | 0.0146    | 11.82 |
| West Coyote Average |          |          |          |          |          |          |           |           | 14.78 |
| ALL FIELD AVERAGE   |          |          |          |          |          |          |           |           | 17.77 |

Table 18 - OIL FIELD SUMMARY BY TYPE OF CRUDE

|                        | HEAVY   |          | MEDIUM  |          | LIGHT   |          |
|------------------------|---------|----------|---------|----------|---------|----------|
|                        | AVERAGE | $\sigma$ | AVERAGE | $\sigma$ | AVERAGE | $\sigma$ |
| Methane                | 40.3306 | 39.9900  | 35.6790 | 14.7932  | 22.3296 | 18.2560  |
| Ethane                 | 3.1335  | 5.0954   | 7.0480  | 2.2906   | 11.4976 | 2.9810   |
| Propane                | 2.6816  | 4.0563   | 13.3730 | 6.0151   | 16.8342 | 2.5576   |
| i-Butane               | 1.4099  | 2.0243   | 4.2404  | 1.9756   | 3.7037  | 1.4627   |
| n-Butane               | 3.4299  | 5.0578   | 10.8996 | 4.4188   | 11.4858 | 6.1301   |
| 2,2-dimethylpropane    | 0.1282  | 0.1730   | 0.0576  | 0.0477   | 0.1753  | 0.2683   |
| i-Pentane              | 2.8847  | 4.5520   | 4.4628  | 1.9424   | 3.2643  | 1.6812   |
| n-Pentane              | 2.5220  | 4.3954   | 3.8639  | 1.2808   | 3.9830  | 2.5560   |
| 2,2-Dimethylbutane     | 0.1694  | 0.2482   | 0.0934  | 0.0938   | 0.1017  | 0.0487   |
| Cyclopentane           | 0.1806  | 0.3014   | 0.2860  | 0.2773   | 0.1728  | 0.1809   |
| 2,3-Dimethylbutane     | 0.4154  | 0.7770   | 0.2691  | 0.4791   | 0.0953  | 0.1455   |
| 2-Methylpentane        | 1.4184  | 2.0159   | 0.9545  | 0.7764   | 1.3019  | 0.3951   |
| 3-Methylpentane        | 0.8937  | 1.3878   | 0.8830  | 0.5298   | 0.7929  | 0.7804   |
| n-Hexane               | 1.4916  | 2.1232   | 1.4227  | 0.4918   | 2.1744  | 1.0517   |
| Methylcyclopentane     | 1.4230  | 1.9021   | 1.7263  | 1.1250   | 1.8375  | 1.3330   |
| 2,4-Dimethylpentane    | 0.1154  | 0.1537   | 0.0873  | 0.0603   | 0.0865  | 0.0252   |
| Benzene                | 1.3177  | 3.1774   | 0.2629  | 0.2799   | 0.2950  | 0.1856   |
| Cyclohexane            | 0.0482  | 0.0941   | 0.0211  | 0.0164   | 0.0144  | 0.0100   |
| 2-Methylhexane         | 0.3843  | 0.4086   | 0.3014  | 0.1874   | 0.3788  | 0.1829   |
| 2,3-Dimethylpentane    | 0.3743  | 0.5728   | 0.2565  | 0.1468   | 0.2214  | 0.0672   |
| 3-Methylhexane         | 0.4196  | 0.6670   | 0.4470  | 0.2466   | 0.2200  | 0.2543   |
| n-Heptane              | 0.8177  | 1.3746   | 0.5367  | 0.3417   | 0.7939  | 0.4691   |
| Methylcyclohexane      | 0.8028  | 1.4618   | 0.7113  | 0.6985   | 0.7265  | 0.6228   |
| 2,4-Dimethylhexane     | 0.2177  | 0.3263   | 0.1070  | 0.1634   | 0.0356  | 0.0542   |
| 2,3,4-Trimethylpentane | 0.2920  | 0.6669   | 0.2278  | 0.2963   | 0.0668  | 0.1047   |
| Toluene                | 1.2527  | 2.8219   | 0.1943  | 0.1002   | 0.3306  | 0.2602   |
| 2,3-Dimethylhexane     | 0.0579  | 0.0676   | 0.0300  | 0.0217   | 0.0233  | 0.0166   |
| 2-Methylheptane        | 0.1747  | 0.2636   | 0.1206  | 0.1250   | 0.0943  | 0.1876   |
| 3-Ethylhexane          | 0.2368  | 0.2842   | 0.0928  | 0.0876   | 0.0794  | 0.0719   |
| n-Octane               | 1.0096  | 1.0595   | 0.2069  | 0.1473   | 0.2415  | 0.1326   |
| Ethylbenzene           | 0.8447  | 1.1022   | 0.1289  | 0.0737   | 0.0939  | 0.0534   |
| p-Xylene               | 0.4054  | 1.1508   | 0.1054  | 0.1068   | 0.0216  | 0.0210   |
| m-Xylene               | 0.2678  | 0.4639   | 0.0546  | 0.0429   | 0.1127  | 0.0849   |
| o-Xylene               | 0.5411  | 1.0675   | 0.0541  | 0.0344   | 0.0400  | 0.0329   |
| n-Nonane               | 0.5212  | 1.0144   | 0.0601  | 0.0515   | 0.0652  | 0.0504   |
| i-Propylbenzene        | 0.0739  | 0.1086   | 0.0041  | 0.0040   | 0.0029  | 0.0031   |
| n-Propylbenzene        | 0.1692  | 0.2054   | 0.0197  | 0.0161   | 0.0176  | 0.0128   |
| 3-Ethyltoluene         | 0.1576  | 0.1963   | 0.0097  | 0.0088   | 0.0051  | 0.0055   |
| 1,3,5-Trimethylbenzene | 0.1714  | 0.3033   | 0.0089  | 0.0150   | 0.0083  | 0.0111   |
| 2-Ethyltoluene         | 0.1710  | 0.2772   | 0.0121  | 0.0142   | 0.0070  | 0.0108   |
| t-butylbenzene         | 0.2062  | 0.3513   | 0.0079  | 0.0083   | 0.0045  | 0.0066   |
| 1,2,4-Trimethylbenzene | 0.5156  | 1.1864   | 0.0105  | 0.0118   | 0.0099  | 0.0161   |
| i-butylbenzene         | 0.0888  | 0.1961   | 0.0016  | 0.0036   | 0.0012  | 0.0026   |
| s-butylbenzene         | 0.1747  | 0.3680   | 0.0032  | 0.0053   | 0.0024  | 0.0034   |
| n-Decane               | 0.1078  | 0.2289   | 0.0161  | 0.0244   | 0.0061  | 0.0078   |
| 1,2,3-Trimethylbenzene | 0.1848  | 0.3104   | 0.0090  | 0.0146   | 0.0011  | 0.0024   |
| 1,3-Diethylbenzene     | 0.1971  | 0.3609   | 0.0027  | 0.0067   | 0.0026  | 0.0057   |
| 1,4-Diethylbenzene     | 0.1658  | 0.3163   | 0.0022  | 0.0043   | 0.0008  | 0.0019   |
| n-butylbenzene         | 0.1157  | 0.2629   | 0.0027  | 0.0051   | 0.0027  | 0.0038   |
| 1,2-diethylbenzene     | 0.1157  | 0.2365   | 0.0004  | 0.0012   | 0.0076  | 0.0170   |
| n-undecane             | 0.1158  | 0.3117   | 0.0028  | 0.0057   | 0.0018  | 0.0041   |
| Other C4               | 0.0851  | 0.2659   | 0.5817  | 1.6110   | 3.8096  | 5.9979   |
| Other C5               | 0.6130  | 1.0097   | 1.7962  | 1.5924   | 3.9684  | 3.7846   |
| Other C6               | 2.6326  | 3.1626   | 3.8962  | 2.1408   | 3.8874  | 2.7817   |
| Other C7               | 4.5485  | 5.9753   | 2.3109  | 1.4970   | 2.9012  | 1.2015   |
| Other C8               | 5.4600  | 5.9669   | 1.3375  | 0.8678   | 1.1070  | 0.5526   |
| Other C9               | 5.9605  | 7.1701   | 0.5505  | 0.3784   | 0.4857  | 0.3519   |
| Other C10              | 4.0744  | 7.2816   | 0.1325  | 0.1391   | 0.0559  | 0.0593   |
| Other C11              | 1.2806  | 2.7259   | 0.0148  | 0.0207   | 0.0117  | 0.0162   |

### III. References Cited

1. Oliver, Karen D., Joachim D. Pleil, *Atmos. Environ.*, **20**, 1403-1411 (1983)
2. Castronovo, Cynthia L., "Determination of Hydrocarbon Emissions From Oil Field Production Sumps", California Air Resources Board, Stationary Source Division, ARB/SS-87-05, December 1986
3. Measurement of Gaseous Emission Rates From Land Surfaces Using an Emission Isolation Flux Chamber -User's Guide", U.S. Environmental Protection Agency, Environmental Monitoring Systems Laboratory, Las Vegas (February 1986)

### Other References

- 1 Compendium of Methods for the Determination of Toxic Organic Compounds in Ambient Air, U.S. Environmental Protection Agency, Environmental Monitoring Systems Laboratory, Research Triangle Park, NC 27711
2. Procedures for the Sampling and Analysis of Atmospheric Toxic Compounds, California Air Resources Board, Haagen-Smit Laboratory Division

## APPENDIX A - Key Personnel Contacts

| Name                    | Company              | Telephone      |
|-------------------------|----------------------|----------------|
| =====                   |                      |                |
| Ron James, Div. Supt.   | Union Oil            | (805) 543-3108 |
| Steven Woodruff         | Chevron              | (805) 395-6312 |
| Steven Zeeman           | Chevron              | (415) 842-0025 |
| Michael Rutledge        | Texaco               | (805) 762-7331 |
| Fred Hagist, Env. Spec. | Kern River           | (805) 399-2961 |
| Mark Shimarian          | THUMS Long Beach Co. | (213) 436-9211 |
| Jack Caufield           | Bechtel              | (805) 763-6632 |
| Darryl Gunderson        | Shell                | (805) 326-5279 |
| Sam Duran               | Texaco               | (805) 648-8243 |


## APPENDIX B - PHOTOGRAPHS OF SELECTED SAMPLING SITES

### Key for Oil Field Photos


1. bagged valve sampling  
Kern River
2. tank roof hatch sampling  
Kern River
3. Teflon bag buffer  
Belridge
4. casing valve sampling  
Belridge
5. production header  
Belridge
6. vapor recovery compressor  
Elk Hills
7. sump sampler  
Cat Canyon
8. sump sampler  
Cat Canyon
9. sump cover  
Wilmington
10. sump sampling  
Wilmington
11. flux box on sump  
Wilmington
12. casing valve  
Wilmington



tank roof hatch sampling  
Kern River




casing valve sampling  
Rabridna




ugged valve sampling  
ern River




Teflon bag buffe



vapor recovery compressor  
Elk Hills



sump sampler  
Cat Canyon




production header  
Belridge




sump sampler  
Cat Canyon







sump sampling  
Wilmington



casing valve  
Wilmington



sump cover  
Wilmington



flux box on sump  
Wilmington

## APPENDIX C -Protocol for Sampling Fugitive Emissions from Oil Production Facilities

### 1. Applicability

- 1.1 The procedures described herein will be applied to sampling fugitive hydrocarbon emissions from a variety of sources found in California oil production fields.
- 1.2 Sources to be tested by this procedure will have been screened for positive leakage by a soap bubble test (if applicable), and screened for positive hydrocarbon content by a portable hydrocarbon analyzer (OVA 128 or Gastech Analyzer).

### 2. Method

- 2.1 Leaking components will be isolated by a Teflon shroud.
- 2.2 Emissions will be collected in evacuated, passivated stainless steel canisters.
  - 2.2.1 If component leak rate is high, emissions filling the shroud will be collected directly.
  - 2.2.2 If component leak rate is low, zero air will be permitted to flow into the shroud, and diluted emissions at the shroud outlet will be collected as above.
- 2.3 Sumps and pits will have a portion of their surface isolated by a flux chamber.
- 2.4 Zero air will be permitted to enter the chamber and mix with the emissions.
- 2.5 The diluted emissions at the chamber outlet will be collected in evacuated stainless steel canisters.
- 2.6 The headspace of storage tanks will be accessed via roof hatches.
- 2.7 Tank headspace will be collected in evacuated stainless steel canisters.
- 2.8 Analysis will be performed, using gas chromatography, with flame ionization or mass spectrometric detection, as appropriate.

### 3. Components

- 3.1 A cylinder of zero air, containing less than 0.1 PPM hydrocarbons.
  - 3.1.1 A size 3 cylinder (6" x 10", 30 ft<sup>3</sup> @ 2000 PSIG) of Ultra Zero Air, from Matheson, Cucamonga, CA.
  - 3.1.2 A non-contaminating manual central valve, #4351, CGA 590 from Matheson, Cucamonga, CA.
- 3.2 Teflon bags, various sizes from 3 liter to 20 liters, from Berghof, Inc. , Concord, CA.
- 3.3 A rotameter to monitor flow of zero air, from Ace Glass, Vineland, NJ.
- 3.4 Adhesive tapes in a variety of widths.
- 3.5 SUMMA-passivated stainless steel canisters, 3.2 liter.
- 3.6 Stainless steel or other inert flux chamber.
- 3.7 Combination pressure-vacuum gauge for field check of canister pressure.
- 3.8 Teflon tubing, for use in sampling lines, Berghof, Concord, CA.

### 4. Procedure

- 4.1 The leaking component is isolated, a Teflon bag of appropriate size, sealed with tape or an elastic band.
  - 4.1.1 The shroud is leak-checked by inflation with zero air. Leaking seams are identified and repaired.
  - 4.1.2 The contents of the shroud are expelled by compression of the Teflon bag.
  - 4.1.3 If the component leak rate is high, the shroud will re-inflate.

- 4.1.4 Perform another empty/fill cycle.
- 4.1.5 Complete sample ID sheet with component description, and canister number.
- 4.1.6 Attach vacuum gauge to sampling canister, open canister valve just long enough to note and record pressure.
- 4.1.7 Attach sampling canister to shroud exit part.
- 4.1.8 When shroud is fully inflated, slowly open canister valve, and allow sample to fill canister.
- 4.1.9 When canister contents are at atmospheric pressure, close canister valve and remove canister from shroud.
- 4.1.10 If component leak rate is low, fill shroud by metering in zero air at no more than 500 mL/min. Allow at least 3 shroud volumes of air to flow before sampling as above.
- 4.2 For sumps and pits, place emission isolation chamber on surface.
  - 4.2.1 Meter in zero air at 2-5 liters/min. Allow at least 3 chamber volumes of air to flow before sampling.
  - 4.2.2 Perform canister pressure check as in 4.1.6.
  - 4.2.3 Attach canister to chamber outlet port, and slowly open canister valve.
  - 4.2.4 When canister contents are at atmospheric pressure, close canister valve and remove canister.
- 4.3 For storage tanks, locate access hatch.
  - 4.3.1 Perform canister pressure check as in 4.1.6.

- 4.3.2 Attach 1/4" O.D. stainless steel sampling probe to canister.
- 4.3.3 Open access hatch enough to insert probe well into tank headspace.
- 4.3.4 Open canister valve, and allow sample to fill canister.
- 4.3.5 When canister contents are at atmospheric pressure, close canister valve, withdraw sampling probe and close hatch.

## APPENDIX D - ANALYTICAL METHODOLOGY AND CALIBRATION

## 5. ANALYTICAL METHODOLOGY AND CALIBRATION

### 5.1 Introduction to Analytical Methodology

Environmental Analytical Service, Inc. (EAS) performed the chemical analysis of diluted engine exhaust and bagged component samples using dedicated gas chromatographs (GC) equipped with flame ionization detectors (FID). The FID provides maximum sensitivity for hydrocarbons and has a selective response to hydrocarbon atoms. With proper gas chromatographic separation methods, the concentration of components in complex mixtures can be accurately determined. A GC equipped with a mass spectrometer detector (MSD) was used for confirmation of compound identities in collected samples. These methods provided complete compound speciation for all photochemically reactive organic compounds (PROC) as described in the EPA document Guidance for the Collection and use of Ambient Hydrocarbon Species Data in Development of Ozone Control Strategies (Singh, 1980). The following sections describe the analytical methods EAS used for the fugitive emissions study.

#### 5.1.1 Analysis of Methane

Methane in the collected samples was analyzed using a Carle AGC 100 isothermal gas chromatograph. The methane was separated from air and CO using a 6' Molecular Sieve 5A Column at 50 °C. The helium carrier gas flow rate used was 30 mL/min. Air pressure was maintained at 16 psig and hydrogen pressure at 22 psig, as recommended by the manufacturer. A 2.0 mL sampling loop was used to measure the sample size. The sample loop was kept in a thermostated oven to maintain constant volume. The peaks were integrated using a HP 3393A computing integrator which directly calculated the methane concentration in ppmC. The relative precision for methane at 1,725 ppbV is 0.2 to 0.4%. The response has been demonstrated to be linear to 20 ppmV.

#### 5.1.2 Light Hydrocarbon Analysis (C2 to C4) at Low Concentrations

The light hydrocarbons were analyzed using a GC/FID packed column procedure. The column and procedure used for analysis is recommended by EPA and described in California Air Resources Board Method 104. The column used was 1/8" by 10' stainless steel packed with phenyl-isocyanate on Durapack 80/100 mesh. The gas chromatograph used was an HP 5890 with a Model HP3393A computing integrator equipped with chart readout. A 100 to 500 mL gas sample was concentrated using a glass bead freezeout loop procedure. The column was operated isothermally at 28 °C.

A diagram for the instrumental set-up for light hydrocarbon analysis is shown in Figure 5.1.1. The sample canister is connected to a counterflow dryer made of Nafion tubing. The dryer removes water vapor from the sample before analysis. The sample loop is immersed in a Dewar flask filled with liquid oxygen, which traps out hydrocarbons from C2 to C10 quantitatively. The sample is pulled through the glass bead freezeout loop by vacuum. The volume of sample was determined by measuring the pressure drop in a 1.2 liter canister. A precision vacuum test gauge was used to measure the pressure change from which the volume of sample can be calculated (see Section 6.3.3). The system can be used to accurately measure a sample size of 100 to 500 mL.

Once the constituents are trapped, the six port valve is switched from <load> to <analyze>, and the freezeout loop is placed in 80 °C water to thermally desorb the hydrocarbons. The desorbed compounds flow to a 1/8" by 10' stainless steel column packed with phenylisocyanate on Durapack 80/100 mesh. Analysis is performed isothermally at 28 °C. The column flow is controlled by column head pressure and is maintained at 20 psig to give a flow of 40 mL/min. The hydrocarbons are analyzed on a FID detector. The operating conditions are summarized in Table 5.1.

## 5.1 LIGHT HYDROCARBON ANALYSIS SETUP






TABLE 5.1

## OPERATING CONDITIONS

## METHANE -

Flows -  
Helium 30 ml/min  
Hydrogen 30 ml/min  
Gas Pressures -  
Helium (Column Pressure) 40 psig  
Hydrogen (Flame) 24 psig  
Air (Flame) 15 psig  
Temperature Program - 50 C  
Detector Temperature - 150 C  
Sample Size - 1.0 ml

## LIGHT HYDROCARBONS -

Flows -  
Helium 29 ml/min  
Hydrogen 31 ml/min  
Air 340 ml/min  
Gas Pressures -  
Helium (Column Pressure) 40 psig  
Hydrogen (Flame) 17.5 psig  
Air (Flame) 34 psig  
Temperature Program - 30 C  
Detector Temperature - 250 C  
Sample Size - 500 ml

## HEAVY HYDROCARBONS -

Flows -  
Air 420 ml/min  
Nitrogen 43 ml/min  
Gas Pressures -  
Hydrogen (Column Pressure) 7 psig  
Hydrogen (Flame) 17 psig  
Air (Flame) 35 psig  
Nitrogen (Make-up Gas) 30 psig  
Temperature Program - -20C for 2 min, Program Rate 6 C/min  
Detector Temperature - 275 C  
Sample Size - 500 ml

The peak areas were integrated using an HP 3393A computing integrator with chart recorder. The charts were examined to verify proper system operation and chromatographic resolution. The integrated data were used to calculate the concentration of the constituents. These results were compared with standard runs, and quantified against a commercial propane standard that is traceable to NBS standards (see Section 5.4.2). Response factors of hydrocarbons other than propane are based on carbon number and checked experimentally and against literature values (Dietz, 1967). Hard copies of the chromatograms, and integrated data are EAS proprietary materials which are stored permanently at the laboratory for a five year period. These materials are available for inspection by the client at the EAS laboratory and are not released in copy form to the client.

#### Analysis of Light Hydrocarbons (C2 to C6) at High Concentrations.


Some light hydrocarbons from bagged component samples were present at high concentrations. These samples were analyzed on the Carle AGC 100 GC using a 1/8" x 30' column containing 23 % SP-1700 on 80/100 Chromosorb PAW operating at 75 °C, isothermal. A 1.0 mL sample loop with backflush was used for direct injection. Concentrations in the 0.1 percent to 100 percent range were measured using a thermal conductivity detector (TCD). The precision for this method at 5 percent concentration is 0.5 percent. For concentrations in the 1 to 1000 ppmvC range, a FID was used. The precision at 9.5 ppmv is 1.0 percent. EAS maintains a complete line of commercial light hydrocarbon standards spanning the range of 10 ppmv to 10 percent. The results were integrated using an HP 3393A integrator and the concentrations of the individual hydrocarbons were determined by transferring the integrated areas into a HP 150 computer using a LOTUS 1-2-3 spreadsheet.

#### 5.1.3 Heavy hydrocarbon and Oxygenates Analysis (C5 to C10)

The heavy hydrocarbons and oxygenates (aldehydes and ketones) were analyzed using an HP 5890 with a fused silica capillary column. This method was described in Sing (1980). This publication describes the use of a canister-based system in conjunction with a freezeout loop for the analysis of sub-par billion hydrocarbons and stable oxygenates. The analysis procedure is similar to that used by Westburg (1984) and Rasmussen (1987). The capillary column provides the required resolution to separately identify the individual reactive organic compounds. Major components that cannot be identified using FID were analyzed for confirmation on an HP 5890/5970 GC/MSD system as described in EPA Method TO-14. A diagram for the instrumental set-up is shown in Figure 5.1.2. The heavy hydrocarbons are analyzed by passing the sample through a Nafion dryer into the 8" glass bead freezeout loop immersed in liquid oxygen. The components are desorbed into a fused silica cryofocussing loop with 80 °C hot water. They are then desorbed from the cryofocus loop and the components are separated using a 100-meter 0.25-micron fused silica capillary column with a 0.5-micron coating. The column is programmed from -20 °C to 200 °C at 3 °C/min. Total analysis time is 60 minutes. The method detection limit for this method is about 0.1 ppbvC for most compounds and the analytical precision at 10 ppbvC is 5 percent. The compounds are detected on a FID set to operate at high sensitivity. A detailed description of the analytical procedure is given in section 5.2.3. Chromatograms were integrated using an HP 3393A computing integrator and stored on a HP 9114 disk drive for reintegration or further examination if required at a later date. Compounds were calibrated using an NBS-traceable propane/hexane/benzene standard. On the FID, hydrocarbons have a uniform response based on the number of carbon atoms. Data from the integrator were entered into a LOTUS 1-2-3 spreadsheet to generate the final report.

# HEAVY HYDROCARBON ANALYSIS SETUP

5.2



#### 5.1.4 Compound Analysis and Identification

The GC/MS method (EPA Method TO-14) uses a cryotrapping system and a high resolution capillary column to analyze for volatile organic compounds.

A diagram of the analytical system, with an HP 5970 MSD for the detector, is shown in Figure 5.1.3. A 100 to 1000 mL gaseous sample is introduced from the air sampling canister through a Nafion dryer to the freezeout loop. The freezeout loop is immersed in liquid oxygen and concentrates the air sample. After the sample is loaded, it is cryofocused onto the beginning of a 30 meter fused silica capillary column. The cryofocused loop is then warmed and the compounds are separated and enter the mass spectrometer. The GC/MS has a complete data system capable of collecting, storing, and interpreting the data collected. The GC/MS is tuned and operated according to the specifications outlined in EPA SW 846 Test Methods. Compounds were calibrated by the external standard procedure using a NBS traceable Scott-Marrin air standards. The relative standard deviation of the method is 20% at 5 ppbv and the MDL is 0.5 ppbv for most compounds.

#### 5.1.5 Permanent Gases (Nitrogen, Oxygen, Carbon Dioxide, Methane)

The permanent gases were analyzed by a SCAQMD method using a GC with a thermal conductivity detector and a FID on a Molecular Sieve 5A column a Poropak Q/N column mix. the system uses a 1 mL sample loop and is set-up with column backflush and bypassing to simultaneously measure the Carbon Dioxide and other fixed gases. The instrument is run isothermally at 70<sup>0</sup> C with helium carrier gas and has a detection limit of 0.05%. For low levels of Carbon Dioxide a catalyst is used to convert the Carbon Dioxide to Methane for analysis.

#### 5.1.6 Aldehydes by the DNPH method

The C1 to C4 aldehydes were analyzed by a modification of EPA Method TO5. This method is based on the reaction of low molecular weight aldehydes and ketones with 2,4-dinitrophenylhydrazine to form stable derivatives. The source gases were sampled using midjet impingers filled with acidified DNPH in acetonitrile. An aliquot of the impinger contents was analyzed using high performance liquid chromatography. The analytical column used was a Supelcosil LC18 reverse phase type, with a Supelco guard column. The system was run isocratically, using 70% methanol / 30% water as the eluant. The sample, typically 15 microliters, was injected with a Pressure-Lok syringe. The aldehydes were detected using a UV-visible detector operating at a wavelength of 360 nm, and quantified using an HP 3393A computing integrator.

### 5.2 Analytical Standard Operating Procedures


#### 5.2.1 Methane Analysis

##### 1. Standards

This procedure is used to load standards at high concentrations (5 ppmv) and have them diluted using calibrated loops to give GC responses equivalent to ambient concentrations. Dilution is 1/1000 with an uncertainty of less than 5%.

- a. Set system to operating parameters given in Table 5.1.b.
- b. Light FID, and place sample valve in load position.

FIGURE 5.1.3



- c. Connect standard cylinder to sampling line.
- d. Open valve on standard cylinder and let bubble for 3 seconds to flush loop. Close valve.
- e. Rotate sample valve to inject position, start integrator.
- f. At end of run turn sample valve to load position.
- g. Disconnect standard cylinder.

## 2. Ambient Air Samples

This procedure can be used to load low pressure samples in stainless steel sample canisters, and to load low pressure standards at simulated ambient concentrations.

- a. Set system to operating parameters given in Table 5.1.b.
- b. Light FID, turn sample valve to load position.
- c. Connect sample canister to sampling line.
- d. Open valve on sample canister, and let bubble for 3 seconds to flush loop. Close valve.
- e. Turn sample valve to inject, and start integrator.
- f. At the end of the run, turn sample valve to load.
- g. Disconnect sample canister from sample intake line, record can pressure, place cap on sample canister, and place on table for light hydrocarbon analysis.

### 5.2.2 Light Hydrocarbon Analysis

This procedure is used to load standards at high concentrations (5 ppmv) and have them diluted using calibrated loops to give GC responses equivalent to ambient concentrations. Dilution is 1/1000 with an uncertainty of less than 5%.

- a. Set system to operating parameters given in Table 6.1.b.
- b. Light FID, turn on vacuum pump, turn on hot water, pour one Dewar of liquid oxygen, and place sample valve in the load position.
- c. Open vacuum valve and evacuate volume measuring canister to 22.0".
- d. Turn air sampling valve to zero air position.
- e. Connect standard input line of 6 port standard valve to standard cylinder. Set regulator on standard cylinder to 10 psig. Open regulator valve.
- f. Flush sample loop with zero air by opening intake valve and turning selector to vacuum. After a drop of 2" vacuum turn standard valve to load position. Turn selector to off and close intake valve. Re-evacuate volume measuring canister to 22".

- g. Place freezeout loop in liquid oxygen Dewar.
- h. Open valve on standard cylinder and let bubble for 3 seconds to flush loop. Close valve.
- i. Rotate standard valve to inject position, turn selector to vacuum.
- j. Let pressure rise until it reaches 10". This corresponds to a zero air volume of 500 mL.
- k. Close intake valve first then turn selector to off. Close valve on sample can.
- l. Turn sample valve to inject, remove liquid oxygen and immediately place freezeout loop in hot water bath and start integrator.
- m. At end of run, turn sample valve to load position and remove hot water bath.
- n. Turn regulator on standard cylinder off, and close regulator valve. Disconnect standard cylinder.

## 2. Ambient Air Samples

This procedure can be used to load low pressure samples in stainless steel sample canisters, and to load low pressure standards at simulated ambient concentrations.

- a. Set system to operating parameters given in Table 5.1.b.
- b. Light FID, turn on vacuum pump, turn on hot water, pour a Dewar of liquid oxygen, and place sample valve in the load position. Turn sampling line open to sample position.
- c. Open vacuum valve and evacuate volume measuring canister to 22.0".
- d. Connect sample canister to intake line.
- e. Open intake valve and turn selector to vacuum and flush system and glass bead freezeout loop to 22" vacuum.
- f. Close intake valve, and turn selector to off. Re-evacuate volume measuring canister to 22.0". Flush system with small amount of sample by opening selector valve and sample canister and re-evacuate volume measuring canister to 22.0".
- g. Place freezeout loop in liquid oxygen Dewar.
- h. Open valve on sample canister.
- i. Turn selector to vacuum and open intake valve. Let pressure rise in volume measuring canister until it reaches 10". This corresponds to a sample size of 500 mL.
- j. Close intake valve first then turn selector to off. Close valve on sample canister.
- k. Turn sample valve to inject, remove liquid oxygen Dewar replace with hot water bath, and start integrator.

- l. At end of run turn sample valve to inject position, and remove hot water bath.
- m. Disconnect sample canister from sample intake line, record can pressure, place cap on sample canister, and place on table for heavy hydrocarbon analysis.

### 5.2.3 Heavy Hydrocarbon Analysis

#### 1. Hydrocarbon Standards

This procedure is used to load standards at high concentrations (5 ppmv) and have them diluted using calibrated loops to give GC responses equivalent to ambient concentrations. Dilution is 1/1000 with an uncertainty of less than 5%.

- a. Set system to operating parameters given in Table 5.1.b.
- b. Light FID, turn on vacuum pump, turn on hot water, pour two Dewars of liquid oxygen, and place sample valve in the load position.
- c. Open vacuum valve and evacuate volume measuring canister to 24.5".
- d. Turn intake valve to "zero air" position.
- e. Connect standard input line of 8 port standard valve to standard cylinder. Set regulator on standard cylinder to 10 psig. Open regulator valve.
- f. Flush both sample loops with zero air by opening intake valve and turning selector to vacuum. After a drop of 2" vacuum turn standard valve to flush other loop. After an additional 2" vacuum drop turn selector to off and close intake valve. Leave standard valve in position for desired loop size. Re-evacuate volume measuring canister to 24.5".
- g. Open valve on standard cylinder and let bubble for 3 seconds to flush loop. Close valve.
- h. Place freezeout loop in liquid oxygen Dewar.
- i. Rotate standard valve and turn selector to vacuum.
- j. Let pressure rise until it reaches 14". This corresponds to a zero air volume of 500 mL.
- k. Turn selector to off. Close valve on standard cylinder.
- l. Place capillary loop in liquid oxygen Dewar.
- m. Set timer for 2.5 min, and turn sample valve to inject.
- n. Remove liquid oxygen and place freezeout loop in hot water bath. Start timer.
- o. At 1.5 min set initial oven temperature to -20° C.
- p. After 2.5 min and oven temperature of -20° C, turn sample valve to load position, start integrator, and simultaneously pull out capillary loop.
- q. Remove hot water from freezeout loop.



- r. Turn cryo valve off at 25° C. CLEAR. ENTER OFF.
- s. Disconnect standard cylinder. Turn regulator on standard cylinder off, and close regulator valve.

## 2. Ambient Air Standards

This procedure can be used to load low pressure samples in stainless steel sample canisters, and to load low pressure standards at simulated ambient concentrations.

- a. Set system to operating parameters given in Table 5.1.b.
- b. Light FID, turn on vacuum pump, turn on hot water, pour two Dewars of liquid oxygen, and place sample valve in the load position.
- c. Open vacuum valve and evacuate volume measuring canister to 24.0".
- d. Turn intake valve to "sample" position.
- e. Open intake valve and turn selector to vacuum and flush system and glass bead freezeout loop to 22" vacuum.
- f. Close intake valve, and turn selector off. Re-evacuate volume measuring canister to 24.5".
- g. Flush system with a small amount of sample by turning selector to vacuum, open sample canister and let pressure rise to 22". Close sample canister, and turn selector to off. Re-evacuate volume measuring canister to 24.5".
- h. Place freezeout loop in liquid oxygen Dewar.
- i. Open valve on sample canister.
- j. Turn selector to vacuum and let pressure rise in volume measuring canister until it reaches 14". This corresponds to a sample size of 500 mL.
- k. Turn selector to off. Close valve on sample canister.
- l. Place capillary loop in liquid oxygen Dewar.
- m. Set timer for 2.5 min, and turn sample valve to inject.
- n. Remove liquid oxygen, place freezeout loop in hot water bath and simultaneously start timer.
- o. At 1.5 min set initial oven temperature to -20° C.
- p. After 2.5 min and oven temperature of -20° C, turn sample valve to load position, start integrator, and simultaneously pull out freezeout loop.
- q. Remove hot water from freezeout loop.
- r. Turn cryo valve off at 25° C. CLEAR. ENTER OFF.

- s. Disconnect sample canister from sample intake line, record can pressure, place cap on sample canister, and place on temporary storage shelf.

#### 5.2.4 Attachment 1 Compounds by GC/MS

##### 1. Standards

This procedure is used to load standards at high concentrations (5 ppmv) and have them diluted using calibrated loops to give GC responses equivalent to ambient concentrations. Dilution is 1/500 with an uncertainty of less than 5%.

- a. Set system to operating parameters.
- b. Turn on vacuum pump, turn on hot water, and pour two Dewars of liquid oxygen, and place Sample Valve in the load position.
- c. Open Vacuum Valve and evacuate Volume Measuring Canister to 24.5".
- d. Turn Intake Valve to "aero air" position.
- e. Connect Standard Input Line of 8 port Standard Valve to standard cylinder. Set regulator on standard cylinder to 10 psig. Open regulator valve.
- f. Flush both sample loops with zero air by opening Intake Valve and turning Selector to vacuum. After a drop of 2" vacuum turn standard valve to flush other loop. After an additional 2" vacuum drop turn Selector to off and close Intake Valve. Leave Standard Valve in position for desired loop size. Re-evacuate Volume Measuring Canister to 24.5".
- g. Open valve on standard cylinder and let bubble for 3 seconds to flush loop. Close valve.
- h. Place freezeout loop in liquid oxygen Dewar.
- i. Rotate Standard Valve and turn Selector to vacuum.
- j. Let pressure rise until it reaches 14". This corresponds to a zero air volume of 500 mL.
- k. Turn Selector to off. Close valve on standard cylinder.
- l. Place capillary loop in liquid oxygen Dewar.
- m. Set timer for 2.5 min, and turn Sample Valve to inject.
- n. Remove Liquid Oxygen and place freezeout loop in hot water bath. Start timer.
- o. On GC/MS computer enter the data acquisition program and set up data collection file for standard. Standard files are formatted as: S (Days Date) (Last digit of year) A (Run Number). D Turn on cryo option, and enter the Prepare To Inject Program.
- p. After 2.5 min and oven temperature of -20° C, turn Sample Valve to load position, hit the GO softkey on the computer, and simultaneously pull out capillary loop.

- q. Remove hot water from Freezeout loop.
- r. Turn cryo valve off at 25° C. CLEAR. ENTER OFF.
- s. Disconnect standard cylinder. Turn regulator on standard cylinder off, and close regulator valve.

## 2. Ambient Air Standards

This procedure can be used to load low pressure samples in stainless steel sample containers, and to load low pressure standards at simulated ambient concentrations.

- a. Set system to operating parameters given in Table 1.
- b. Open Vacuum Valve and evacuate Volume Measuring Canister to 24.0".
- c. Turn Intake Valve to "sample" position.
- d. Open Intake Valve and turn Selector to vacuum and flush system and glass bead Freezeout Loop at 22" vacuum.
- e. Close Intake Valve, and turn selector to off. Re-evacuate Volume Measuring Canister to 24.5".
- f. Flush system with a small amount of sample by turning Selector to vacuum, open Sample Canister and let pressure rise to 22". Close Sample Canister, and turn Selector to off. Re-evacuate Volume Measuring Canister to 24.5".
- g. Place Freezeout Loop in liquid oxygen Dewar.
- h. Open valve on Sample Canister.
- i. Turn Selector to vacuum and let pressure rise in Volume Measuring Canister until it reaches 14". This corresponds to a sample size of 500 mL.
- j. Turn Selector to off. Close valve on Sample Canister.
- k. Place Capillary Loop in liquid oxygen Dewar.
- l. Set timer for 2.5 min, and turn Sample Valve to inject.
- m. Remove liquid oxygen, place Freezeout Loop in hot water bath and simultaneously start timer.
- n. On GC/MS computer enter the data acquisition program and set up data collection file for standard. Standard files are formatted as: S(Days Date)(Last digit of year)A(Run Number).D Turn on cryo option, and enter the Prepare To Inject Program.
- o. After 2.5 min and oven temperature of -20°C, turn Sample Valve to load position, hit the GO softkey on the computer, and simultaneously pull out capillary loop. Min set initial oven temperature to -20° C.
- p. Remove hot water from Freezeout Loop.

- q. Turn cryo valve off at 25° C. CLEAR. ENTER OFF.
- r. Disconnect Sample Canister from Sample Intake Line, record can pressure, place cap on Sample Canister, and place on temporary storage shelf.

#### 5.2.5 Permanent Gases

##### 1. Standards

- a. Set system to operating parameters.
- b. Light FID, turn on TCD, and place sample valve in load position.
- c. Connect standard cylinder to sampling line.
- d. Open valve on standard cylinder and let bubble for 3 seconds to flush loop. Close valve.
- e. Rotate sample valve to inject position, start integrator.
- f. Turn second column valve to out position at 1.6 min.
- g. Turn second column valve to in position at 8.0 min.
- h. At end of run turn sample valve to load position.
- i. Disconnect standard cylinder.

##### 2. Ambient Air Samples

This procedure can be used to load low pressure samples in stainless steel sample canisters, and to load low pressure standards at simulated ambient concentrations.

- a. Set system to operating parameters.
- b. Light FID, turn on TCD, and turn sample valve to load position.
- c. Connect sample canister to sampling line.
- d. Open valve on sample canister, and let bubble for 3 seconds to flush loop. Close valve.
- e. Turn sample valve to inject, and start integrator.
- f. Turn second column valve to out position at 1.6 min.
- g. Turn second column valve to in position at 8.0 min.
- h. At the end of the run, turn sample valve to load.
- i. Disconnect sample canister from sample intake line, record can pressure, place cap on sample canister, and place on table for light hydrocarbon analysis.

### 5.3 Calibration Standards

There are two types of calibrations performed for the hydrocarbon analysis. One is for the amount of the various hydrocarbons present and the second is for the identification of the retention times of the different hydrocarbons species.

#### 5.3.1 Quantitative Standards

The concentrations of the individual hydrocarbons were determined by their uniform carbon response on the FID. This procedure is the recommended calibration procedure and has been shown to be accurate to 5 to 8% (Lonneman, 1979). The primary calibration standard used for the light and heavy hydrocarbons is a NBS traceable reference gas standard obtained from Scott-Marrin, Riverside, CA. The specifications of the standard are shown in Figure 5.3.1(a) the light hydrocarbon fraction is calibrated against propane and the non-aromatic fraction of the heavy hydrocarbons are calibrated against hexane. The aromatic hydrocarbons are calibrated against benzene. The standard cylinder is returned every year for recalibration by the manufacturer. The concentrations of the hydrocarbons in the standard are converted to parts per billion carbon (ppbC) using the procedure described by Westbert et. al. (1984).

The concentrations of the individual compounds are determined by using an External Calibration procedure, in which the compound's response is compared to the response of a standard. The primary calibration standard is an NIST traceable reference gas standard obtained from Scott-Marrin, Inc., Riverside, CA. The specifications of the standard are shown in Figure B.5.3.1(b) & (c) The standard cylinder is returned every six months for recalibration by the manufacturer. In addition, a standard containing toluene, o-xylene, ethene and propene is used to verify response for these compounds.

Standards for aldehyde determinations were prepared as described in ARB Method 110.

Intercomparison of the light and heavy hydrocarbon runs can be made using both the propane peak and the hexane peak. The propane peak can be used because the heavy loaded column is capable of separating the lighter hydrocarbons.

#### 5.3.2 Qualitative Calibration

The retention times were calibrated against commercial gas standard blends of different hydrocarbons and from laboratory standards prepared from neat materials.

The commercial gas blends are available from Ideal Gas Products and Scott Specialty Gases. These standards are used to establish retention times and to check concentrations obtained from the NBS traceable standard.

Laboratory standards are prepared from pure materials for those compounds not available in gas blends. Known quantities of the pure materials are diluted with a measured volume of "zero air". Dilutions are made in stainless steel canisters and are stable for use in retention time calibrations for several months.



**SCOTT-MARRIN, INC.**  
 2001 THIRD ST. • UNIT H • RIVERSIDE, CA 92507  
 TELEPHONE (714) 784-1240

## REPORT OF ANALYSIS

TO: Steve Hoyt  
 Environmental Analytical Science  
 3576 Empleo St., Suite 5  
 San Luis Obispo, CA 93401

DATE: 23 October 1986

CUSTOMER ORDER NUMBER: 1171

~~~~~

| CYLINDER NUMBER | CC121              |
|-----------------|--------------------|
| COMPONENT       | CONCENTRATION(v/v) |
| Propane         | 4.71 ± 0.05 ppm    |
| n-Hexane        | 5.12 ± 0.1 ppm     |
| Benzene         | 5.01 ± 0.1 ppm     |
| Nitrogen        | Balance            |

| CYLINDER NUMBER |                    |
|-----------------|--------------------|
| COMPONENT       | CONCENTRATION(v/v) |

\_\_\_\_\_  
 CYLINDER NUMBER \_\_\_\_\_  
 COMPONENT CONCENTRATION(v/v)

\_\_\_\_\_  
 CYLINDER NUMBER \_\_\_\_\_  
 COMPONENT CONCENTRATION(v/v)

ANALYST

*M. C. Dodd*  
 M. C. Dodd

APPROVED

*J.T. Marrin*  
 J.T. Marrin

<sup>76</sup>  
 The only liability of this company for gas which fails to comply with this analysis shall be replacement or reanalysis thereof by the company without extra cost.

FIGURE 5.3.1.(a2)



**SCOTT-MARRIN, INC.**  
2001 THIRD ST. • UNIT H • RIVERSIDE, CA 92507  
TELEPHONE (714) 784-1240

## REPORT OF ANALYSIS

TO:

Steve Hoyt  
Environmental Analytical Services  
3576 Empleo, Suite #5  
San Luis Obispo, CA 93401

DATE:

5 November 1987

CUSTOMER ORDER NUMBER: 1253

~~~~~  
CYLINDER NUMBER CC62416

| COMPONENT               | CONCENTRATION(v/v) |
|-------------------------|--------------------|
| Vinyl Chloride          | 5.14 ± 0.1 ppm     |
| Chloromethane           | 5.25 ± 0.1 ppm     |
| Trichloromethane        | 0.515 ± 0.01 ppm   |
| 1,1-Dichloroethane      | 5.20 ± 0.1 ppm     |
| 1,1,1-Trichloroethane   | 0.520 ± 0.01 ppm   |
| Tetrachloromethane      | 0.525 ± 0.01 ppm   |
| 1,2-Dichloroethylene    | 0.530 ± 0.01 ppm   |
| Benzene                 | 5.25 ± 0.1 ppm     |
| 1,2-Dibromoethane       | 5.29 ± 0.1 ppm     |
| 1,1,2-Trichloroethylene | 0.530 ± 0.01 ppm   |
| Nitrogen                | Balance            |

ANALYST

*M. Dodd*

M. Dodd

The only liability of this company for gas which fails to conform to specification shall be replacement or reanalysis thereof by the company without extra cost.

77 APPROVED

*J. T. Marrin*

J. T. Marrin

Analysis shall be replacement or reanalysis thereof by the company without extra cost.



**SCOTT-MARRIN, INC.**  
2001 THIRD ST. • UNIT H • RIVERSIDE, CA 92507  
TELEPHONE (714) 784-1240

## REPORT OF ANALYSIS

TO:

Steve Hoyt  
Environmental Analytical Services  
3576 Empleo Street, Ste. 5  
San Luis Obispo, CA 93401

DATE:

12 September 1988

CUSTOMER ORDER NUMBER: 1367

~~~~~  
CYLINDER NUMBER CC68692

| COMPONENT             | CONCENTRATION(w/v) |
|-----------------------|--------------------|
| Halocarbon-12         | 5.20 $\pm$ 0.1 ppm |
| Halocarbon-11         | 4.40 $\pm$ 0.1 ppm |
| 1,1-Dichloroethylene  | 4.87 $\pm$ 0.1 ppm |
| 1,1-Dichloroethane    | 5.05 $\pm$ 0.1 ppm |
| 1,1,2-Trichloroethane | 5.20 $\pm$ 0.1 ppm |
| Nitrogen              | Balance            |

ANALYST

  
J. W. Gay

The only liability of this company for gas which fails to co  
company without extra cost.

APPROVED

  
J. T. Marrin

analysis shall be replacement or reanalysis thereof by the



## 5.4 Calibration Procedures

### 5.4.1 Methane

The methane analyzer was calibrated by passing the methane standard through a 1.0 mL calibrated sample loop. The standard was then injected onto the column according to the standard operating procedures. The concentration of the methane is determined using the following formula.

$$\text{Methane (ppmC)} = \text{Standard Conc. (ppmv)} * 1 * (\text{Sample Area/Standard Area})$$

The factor of one accounts for the one carbon atom in methane.

### 5.4.2 Hydrocarbons

The light and heavy hydrocarbons were calibrated by using a dilution of the 5 ppm NBS traceable standard. A summary of the calibration procedures is shown in Table 5.4.2. The daily calibration consists of a zero point and two calibration points (10% and 100% of range). One calibration point is run at the beginning of the day and one at the end of the day. Weekly, a three point calibration is run to verify the linearity of the instrument. During the monthly internal audit of the analytical system a 5 point calibration curve is run to establish performance criteria for the system.

Standards were prepared using a gas dilution system on the gas chromatograph or by making static dilutions to atmospheric levels. The gas dilution system is constructed from an 8 port gas sampling valve with a 0.05 mL, 0.5 mL, and 5.0 sample loops. The loops are filled with the standard and flushed with "zero air" prepared with an AADCO Model 737 pure air generator. The three loop sizes are used to prepare a three point calibration of the system to check the linearity in the concentration range of interest. The gas dilution system is used for the daily instrument calibration. The concentration of the individual hydrocarbons is determined using the following formula:

$$\text{Hydrocarbon (ppbC)} = \text{Standard Conc. (ppbv)} * \text{number of carbons} * (\text{Sample Area/Standard Area})$$

Standards at atmospheric concentration levels were prepared by diluting the NBS traceable standard in stainless steel canisters. The standards are diluted by using a calibrated syringe to inject a measured volume of NBS traceable standard into a passivated stainless steel canister. The canister is filled with a known volume of zero air measured using a mass flow meter. The diluted standards are run in exactly the same manner as the samples and serve as a check of the sample concentration and injection system.

### 5.4.3 GC/MS Compounds

The GC/MS Compounds were calibrated using a dilution of the NBS traceable standard. The daily calibration consists of a zero point and two calibration points (10% and 100% of range). One calibration point is run at the beginning of the day and one at the end of the day. Weekly, a three point calibration is run to verify the linearity of the instrument. During the monthly internal audit of the analytical system a 5 point calibration curve is run to establish performance criteria for the system.

Standards were by using a gas dilution system on the gas chromatograph or by making static dilutions to atmospheric levels. The gas dilution system is constructed from an 8 port gas sampling valve with a 0.05 mL, 0.5 mL, and 5.0 sample loops. The loops are filled with the standard and flushed with "zero air" prepared with an AADCO Model 737 pure air generator. The three loop sizes are used to prepare a three point calibration of the system to check the linearity in the concentration range of interest. The gas dilution system is used for the daily instrument calibration.

The concentration of the individual hydrocarbons is determined using the following formula:

$$\text{Compound (ppbv)} = \text{Std. Conc. (ppbv)} * (\text{Sample Area/Std. Area}) * (\text{Std. Volume/Sample Volume})$$

Standards at atmospheric concentration levels were prepared by diluting the NBS traceable standard in stainless steel canisters. The standards were diluted using a calibrated syringe to inject a measured volume of the NBS traceable standard into a passivated stainless steel canister. The canister is filled with a known volume of zero air measured using a mass flow meter. This ambient level standard is sent to another laboratory for calibration against the NBS 5 ppbv VOC standard. The diluted standard is run in exactly the same manner as the samples and serves as a check of the sample concentration injection system.

| REPORT DOCUMENTATION PAGE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                                                          |                                                         | Form Approved<br>OMB No. 0704-0188                                |                                                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|---------------------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------|
| <small>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of the collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.</small> |                                                          |                                                         |                                                                   |                                                  |
| 1. AGENCY USE ONLY (Leave blank)<br>PB92-170026                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                          | 2. REPORT DATE<br>April 30, 1991                        |                                                                   | 3. REPORT TYPE AND DATES COVERED<br>Final Report |
| 4. TITLE AND SUBTITLE<br>Development of Species Profiles for Selected Organic Emissions Sources                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                          |                                                         | 5. FUNDING NUMBERS<br>A832-059 Volumes I and II                   |                                                  |
| 6. AUTHOR(S)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                          |                                                         |                                                                   |                                                  |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)<br>California Polytechnic State University<br>Chemistry Department                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                          |                                                         | 8. PERFORMING ORGANIZATION REPORT NUMBER                          |                                                  |
| 9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES)<br>California Air Resources Board<br>Research Division<br>1800 15th Street<br>Sacramento, CA 95814                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                          |                                                         | 10. SPONSORING / MONITORING AGENCY REPORT NUMBER<br>ARB/R-92/ 483 |                                                  |
| 11. SUPPLEMENTARY NOTES                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                          |                                                         |                                                                   |                                                  |
| 12a. DISTRIBUTION / AVAILABILITY STATEMENT<br>Release unlimited. Available from National Technical Information Service<br>5285 Port Royal Road, Springfield, VA 22161                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                          |                                                         | 12b. DISTRIBUTION CODE                                            |                                                  |
| 13. ABSTRACT (Maximum 200 words)<br>Hydrocarbon species profiles were developed for selected petroleum production equipment emissions and for exhaust from utility and heavy-duty engines. Emissions from petroleum production facilities were collected from wellheads, pipelines, and processing and storage systems. Engine exhaust emissions were collected using a portable dilution tunnel system. Analyses of C1 through C10 hydrocarbons were performed using gas chromatographic methods and aldehydes were analyzed by the dinitrophenyl hydrazine method.                                                                                                                                                                     |                                                          |                                                         |                                                                   |                                                  |
| 14. SUBJECT TERMS<br>Hydrocarbons, air pollution, gas chromatography<br>Petroleum production emissions<br>Utility equipment emissions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                          |                                                         | 15. NUMBER OF PAGES                                               |                                                  |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                          |                                                         | 16. PRICE CODE                                                    |                                                  |
| 17. SECURITY CLASSIFICATION OF REPORT<br>Unclassified                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 18. SECURITY CLASSIFICATION OF THIS PAGE<br>Unclassified | 19. SECURITY CLASSIFICATION OF ABSTRACT<br>Unclassified | 20. LIMITATION OF ABSTRACT<br>Unlimited                           |                                                  |