

Spillage Test Procedure

Current Procedure

Calibration at each fueling location

Three trials at each of 1, 5 and 25 ml

Ignores spills less than 1 ml in size

New Procedure

One calibration per facility

Three trials at 1, 2, 3, 4, 5, 10, 25 and 50 ml

All spills of 1 drop or more included

“Dripless” Nozzles

No more than 1 drop per fueling.

Proposed Test Methodology

- ◆ Customer asked if fueling is to be a fill-up
- ◆ If yes, CARB staff requests to fuel vehicle
- ◆ Fueling is at high clip or, if no clip, fully open
- ◆ When nozzle shuts off, wait (timed) 5 secs.
- ◆ Remove nozzle from fillpipe
- ◆ Away from car, point nozzle downward
- ◆ Observe and record drips

Spillage, Liquid Retention, and “Dripless” Nozzles

Concern About the Magnitude of the
Emissions from these Sources

14.2 Billion Gallons per Year in California

6.24 pounds per gallon of gasoline

20 drops = **1** ml

3785 ml = **1** gallon

1 drop/10 gal fueling = **58.4 TPY** in CA

Spillage, Liquid Retention, and “Dripless” Nozzles

Dripless Nozzles: 1 drop / fueling
= 58.4 TPY

Liquid Retention: 100 ml / 1,000 gals.
= 1ml / 10 gals
= 1080 TPY = 2.96 TPD

Nozzle “Spitting” \leq 1ml / nozzle / fueling

Spillage: 0.42 lbs / 1,000 gals
= 11.9 TPD

Proposed Revisions to the Certification Procedure

- ◆ More Stringent Standards and Specifications
- ◆ Operational Test of at Least 180 Days
- ◆ Efficiency Test on 200 Vehicles
- ◆ Limits on Emissions from Processors
(CO, NOx and HAPS)
- ◆ Limited Term Certifications

Performance Standards and Performance Specifications

- ◆ Evidence of compliance with the standards and specifications shall be provided in the application for certification, along with the results of tests demonstrating compliance.
- ◆ The system shall demonstrate ongoing compliance with all applicable standards and specifications throughout certification testing.
- ◆ Systems and components shall comply with all performance standards and specifications throughout the warranty period.

Performance Standards and Specifications Tables

- ◆ Table 3-1 Phase I Systems
- ◆ Table 4-1 All Phase II Systems
- ◆ Table 5-1 Additional - Balance Systems
- ◆ Table 6-1 Additional - All Assist Systems
- ◆ Table 7-1 Additional - Common Collection Unit
- ◆ Table 8-1 Additional - Destructive Processor
- ◆ Table 8-2 Additional - Non-Destructive Processor

Performance Standards and Specifications Tables

- ◆ More than One Table Will Apply

- ◆ Examples:

 - ◆ Balance: Tables 3-1, 4-1, 5-1

 - ◆ Dispenser-based Systems (Gilbarco, Wayne, etc): Tables 3-1, 4-1, 6-1

 - ◆ Central Vacuum Systems:

 - Healy: Tables 3-1, 4-1, 6-1, 7-1

 - Hirt/Hasstech: Tables: all except 5-1, 8-2

All Phase I Systems

- ◆ Phase I Efficiency $\geq 98\%$
- ◆ Emission Factor $\text{HC} \leq 0.17 \text{ \#/1000 gals}$
- ◆ Product Adaptor Rotatable 360° or equivalent
- ◆ Drop tube with
 - Overfill Protection $\leq 0.17 \text{ CFH at } 2.0 \text{ '' wc}$
- ◆ Vapor Adaptor $\leq 0.17 \text{ CFH at } 2.0 \text{ '' wc}$
 - Rotatable 360° or equivalent
 - Poppeted
- ◆ Criteria for Pressure/Vacuum Vent Valves

All Phase II Systems

- ◆ Emission Factor HC ≤ 0.42 #/1,000 gals
- ◆ “Dripless” Nozzles ≤ 1 drop per fueling
- ◆ Spillage ≤ 0.42 #/1,000 gals
(including drips from spout)
- ◆ Liquid Retention ≤ 100 ml/1,000 gals
- ◆ More Stringent Component Integrity
- ◆ Compatible with ORVR-equipped vehicles
- ◆ Compatible with Phase I systems

All Phase II Systems

UST Pressure

- ◆ **Balance** ≤ 0.00 " H₂O for Minimum of 16 hr/day
 ≤ 0.25 " H₂O Ave. of Positive Pressure
Maximum of 1.5 " H₂O for 1 hour/day
- ◆ **Assist** Negative Pressure Maintained
 -0.25 " H₂O $\geq P \geq -4.5$ " H₂O
- ◆ **Innovative** - System does not comply with an identified Standard or Specification, but can meet intent of the requirement in another way.

In-Station Diagnostics (ISD)

- ◆ Shall activate visible and audible alarms, and/or prohibit dispensing, in response to certain failures, and shall monitor and create a record of performance for the last 12 months.
- ◆ Parameters to be monitored:
 - ◆ UST Pressure
 - ◆ Balance System Vapor Return Line (no blockage)
 - ◆ Assist System Air to Liquid (A/L) Ratio, or equivalent
 - ◆ Processor function

Questions?